



SPA06MA-O User's Guide

R004





SPA06MA-O User's Guide

Notice

Every effort was made to ensure that the information in this manual was accurate at the time of printing. However, information is subject to change without notice, and VIAVI reserves the right to provide an addendum to this manual with information not available at the time that this manual was created.

Copyright/Trademarks

© Copyright 2020 Viavi Solutions Inc. All rights reserved. No part of this guide may be reproduced or transmitted, electronically or otherwise, without written permission of the publisher. VIAVI Solutions and the VIAVI logo are trademarks of Viavi Solutions Inc. ("VIAVI").

The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Viavi is under license.

All other trademarks and registered trademarks are the property of their respective owners.

Copyright release

Reproduction and distribution of this guide is authorized for US Government purposes only.

Terms and conditions

Specifications, terms, and conditions are subject to change without notice. The provision of hardware, services, and/or software are subject to VIAVI's standard terms and conditions, available at www.viavisolutions.com/en/terms-and-conditions.

Open Source Disclaimer - IMPORTANT READ CAREFULLY

The ONA-800 includes third party software licensed under the terms of separate open source software licenses. By using this software you agree to comply with the terms and conditions of the applicable open source software licenses. Software originated by VIAVI is not subject to third party licenses. Terms of the VIAVI Software License different from applicable third party licenses are offered by VIAVI alone.



Table of Contents

About this User Guide	vii
Purpose and scope	viii
Assumptions	viii
Terminology	viii
Related Information	viii
Conventions	ix
Safety and compliance information	xi
Technical assistance	xi
 Chapter 1 Overview	 1
SPA06MA-O overview	2
Exploring the module	2
Module installation	3
 Chapter 2 Using Spectrum Analyzer	 7
Introduction	8
Selecting mode and measure	8
Configuring spectrum measurements	9
Setting frequency	9
Frequency and span	10
Setting channel	11
Channel number, channel step, and channel standard	11
Setting amplitude	11
Setting BW/AVG	13
Selecting sweep	14
Setting trigger	15
Setting trace	16
Trace type	16
Trace detection	17
Trace math	17
Setting limit	18

Using marker	20
Using marker table	21
Conducting spectrum measurements	22
Conducting RF measurements	22
Channel Power	23
Spectrum emission mask (SEM)	25
Adjacent channel power (ACP)	27
Multi adjacent channel power	29
Spurious emissions	31
Field strength meter	33
Utility	34
Gate sweep spectrum	34
Route map	36

Chapter 3 Using Interference Analyzer

39

Introduction	40
Selecting mode and measure	40
Conducting spectrum measurements	41
Spectrum	41
Spectrogram	42
Conducting interference measurements	44
RSSI	44
Interference finder	45
Radar chart	50
Obtaining RSSI data	52
Utility	55
Spectrum Replayer	55
PIM detection	56

Chapter 4 Using Real-Time Spectrum Analyzer

59

Introduction	60
Selecting mode and measure	60
Conducting spectrum measurements	60
Persistent spectrum	61
Persistent spectrogram	63
Conducting interference analysis	66
Persistent RSSI	66
Persistent interference finder	68
Persistent radar chart	74
Utility	79
Real-time spectrum replayer	79

Chapter 5 Using LTE/LTE-A FDD Analyzer

81

Introduction	82
Selecting mode and measure	82
Conducting spectrum measurement	82
Spectrum	82

Conducting RF measurement	84	
Channel power	84	
Conducting OTA measurement	85	
OTA channel scanner	85	
OTA ID Scanner	86	
OTA route map	88	
Freq/Time/Power variation	93	
 Chapter 6 Using LTE/LTE-A TDD Analyzer		97
Introduction	98	
Selecting mode and measure	98	
Conducting spectrum measurement	98	
Spectrum	98	
Conducting RF measurement	100	
Channel power	100	
Conducting OTA measurement	102	
OTA channel scanner	102	
OTA ID Scanner	103	
OTA route map	104	
Freq/Time/Power variation	109	
 Chapter 7 Using 5G NR Signal Analyzer		113
Introduction	114	
Selecting mode and measure	114	
Conducting spectrum measurements	114	
Trigger spectrum	115	
Conducting RF measurements	118	
Channel power	118	
Conducting OTA measurement	123	
Beam analyzer	123	
Carrier scanner	127	
Route map	130	
Freq/Time/Power variation	138	
 Chapter 8 Using 5G DSS Signal Analyzer		143
Introduction	144	
Selecting mode and measure	144	
Conducting spectrum measurements	144	
Spectrum	145	
Conducting RF measurements	146	
Channel power	146	
Occupied bandwidth	147	
Conducting Power vs Time measurements	149	
Power vs Time (Frame)	149	
Power vs Time (Slot)	150	
Conducting OTA measurement	152	
OTA Channel Scanner	152	

OTA ID Scanner	156
OTA Multipath Profile	159
OTA Control Channel	162
OTA Route Map	166
Freq/Time/Power Variation	173
 Chapter 9 Using RFoCIPRI Analyzer	 177
Introduction	178
Selecting mode and measure	178
Connecting cables	179
Selecting port	179
Configuring test parameters	180
Setting frequency	180
Setting reference level	180
Setting scale per division	181
Setting external offset	181
Enabling auto leveling	182
Setting RBW	183
Setting average	184
Setting sweep mode	184
Setting trace	185
Selecting network technology	186
Configuring Rx parameters	186
Setting measure setup	188
Conducting spectrum measurement	189
Conducting spectrogram	191
Using the spectrum replayer	192
Setting display	193
 Chapter 10 Using EMF Analyzer	 195
Introduction	196
Connecting antenna	196
Selecting mode and measure	198
Conducting spectrum measurement	198
Spectrum	199
Conducting signal measurement	203
5G NR beam analysis	203
 Appendix A Physical specifications	 209



About this User Guide

This prefix explains how to use this *User Guide*.

- “Purpose and scope” on page viii
- “Assumptions” on page viii
- “Terminology” on page viii
- “Related Information” on page viii
- “Conventions” on page ix
- “Safety and compliance information” on page xi
- “Technical assistance” on page xi

Purpose and scope

This manual is intended to help you use the capabilities of the SPA06MA-O/SPA06MA, and used in conjunction with the *ONA-800 Getting Started Guide*.

These manuals includes task-based instructions that describe how to configure, use, and troubleshoot the test capabilities available on your instrument, assuming it is configured and optioned to support the capabilities.

Assumptions

This manual is intended for novice, intermediate, and experienced users who want to use their instrument effectively and efficiently. We are assuming that you have basic computer experience and are familiar with basic telecommunication concepts, terminology, and safety.

Terminology

The following items are used throughout this manual and appear on the user interface when performing testing. Some terms are also used to label the ports (connectors) on instrument connector panels.

- **5G** — Fifth Generation
- **CPRI** — Common Public Radio Interface
- **FDD** — Frequency Division Duplex
- **LTE** — Long Term Evolution
- **LTE Line** — Termination Equipment
- **RF** — Radio Frequency
- **RFoCPRI** — Radio Frequency over Common Public Radio Interface
- **RTSA** — Real Time Spectrum Analyzer
- **SPA06MA** — Spectrum Analysis module without RFoCPRI
- **SPA06MA-O** — Spectrum Analysis module with RFoCPRI
- **TDD** — Time Division Duplex

Related Information

This is the This manual is application-oriented and contains information about using these instruments to test service carried on each of the listed networks. It includes an overview of testing features, instructions for using the instruments to generate and transmit traffic over a circuit, and detailed test result descriptions. This manual also provides contact information for VIAVI's Technical Assistance Center (TAC).

Conventions

This manual uses conventions and symbols, as described in the following tables.

Table 1 Text formatting and other typographical conventions

Item(s)	Example(s)
Buttons, keys, or switches that you press or flip on a physical device.	Press the On button. – Press the Enter key. – Flip the Power switch to the on position.
Buttons, links, menus, menu options, tabs, or fields on a PC-based or Web-based user interface that you click, select, or type information into.	Click Start – Click File > Properties . – Click the Properties tab. – Type the name of the probe in the Probe Name field.
Directory names, file names, and code and output messages that appear in a command line interface or in some graphical user interfaces (GUIs).	<code>\$NANGT_DATA_DIR/results</code> (directory) – <code>test_products/users/defaultUser.xml</code> (file name) – <code>All results okay.</code> (output message)
Text you must type exactly as shown into a command line interface, text file, or a GUI text field.	– Restart the applications on the server using the following command: <code>\$BASEDIR/startup/npui_init restart</code> Type: <code>a:\set.exe</code> in the dialog box.
References to guides, books, and other publications appear in <i>this typeface</i> .	Refer to <i>Newton's Telecom Dictionary</i> .
Command line option separators.	<code>platform [a b e]</code>
Optional arguments (text variables in code).	<code>login [platform name]</code>
Required arguments (text variables in code).	<code><password></code>

Table 2 Symbol conventions




	This symbol indicates a note that includes important supplemental information or tips related to the main text.
	This symbol represents a general hazard. It may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 3 for more information.
	This symbol represents an alert. It indicates that there is an action that must be performed in order to protect equipment and data or to avoid software damage and service interruption.

Table 2 Symbol conventions (Continued)






	This symbol represents hazardous voltages. It may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 3 for more information.
	This symbol represents a risk of explosion. It may be associated with either a DANGER, WARNING, CAUTION or ALERT message. See Table 3 for more information.
	This symbol represents a risk of a hot surface. It may be associated with either a DANGER, WARNING, CAUTION, or ALERT message. See Table 3 for more information.
	This symbol represents a risk associated with fiber optic lasers. It may be associated with either a DANGER, WARNING, CAUTION or ALERT message. See Table 3 for more information.
	This symbol, located on the equipment, battery, or the packaging indicates that the equipment or battery must not be disposed of in a land-fill site or as municipal waste, and should be disposed of according to your national regulations.

Table 3 Safety definitions

Term	Definition
DANGER	Indicates a potentially hazardous situation that, if not avoided, <i>will</i> result in death or serious injury. It may be associated with either a general hazard, high voltage, or other symbol. See Table 2 for more information.
WARNING	Indicates a potentially hazardous situation that, if not avoided, <i>could</i> result in death or serious injury. It may be associated with either a general hazard, high voltage, or other symbol. See Table 2 for more information.
CAUTION	Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury and/or damage to equipment. It may be associated with either a general hazard, high voltage, or risk of explosion symbol. See Table 2 for more information. When applied to software actions, indicates a situation that, if not avoided, could result in loss of data or a disruption of software operation.
ALERT	Indicates that there is an action that must be performed in order to protect equipment and data or to avoid software damage and service interruption.

Safety and compliance information

Safety and compliance information for the instrument are provided in printed form and ship with your instrument.

Technical assistance

If you require technical assistance, call 1-844-GO-VIAVI. For the latest TAC information, go to <http://www.viavisolutions.com/en/services-and-support/support/technical-assistance>.

Overview

This chapter provides a description of the SPA06MA-O. Topics covered in this chapter include:

- [“SPA06MA-O overview” on page 2](#)
- [“Exploring the module” on page 2](#)
- [“Module installation” on page 3](#)

SPA06MA-O overview

The SPA06MA-O module is equipped with 6 GHz RF and 25 Gbps Optical hardware. SPA06MA is a variant that has 6 GHz RF hardware only.

6 Ghz RF hardware allows:

- Spectrum Analysis from 9 kHz to 6 GHz
- Real-time Spectrum Analysis with up to 100MHz persistent display
- LTE-FDD/TDD and 5G NR OTA Signal Analysis

25 Gbps optical hardware allows:

- RFoCPRI Interference Analysis up to 10.1 Gbps.

Exploring the module

Figure 1 SPA06MA-O module



1	RF Input port	Used as the input signal port for spectrum analysis, signal analysis, and RF power measurement.
2	Ext Ref.	SMA type female connector to receive 10 MHz, 13 MHz, or 15 MHz reference clock signals from an external frequency source.
3	Trigger Out	SMB connector to send 1 PPS clock or 10 ms synchronization signals from an internal timing reference. Digital CMOS Input DC Coupled Input signal requirements: Minimum logic high. 2.4V, Maximum logic high $\geq 3.3V$.

4	Trigger In	SMB connector to receive 1PPS clock or 10 ms synchronization signals. Digital CMOS Input DC Coupled Input signal requirements: Minimum logic high. 2.4V, Maximum logic high $\geq 3.3V$.
5	GNSS Antenna	SMA connector for GNSS antenna.
6 ¹	SFP+/SFP28	You can use these ports to connect SFP modules to test CPRI protocols, detect an error or alarm, perform interference analysis, and transmit test pattern over fiber link.
7 ¹		
8 ¹	QSFP+/QSFP28	You can use these ports to connect QSFP modules to test CPRI protocols, detect an error or alarm, perform interference analysis, and transmit test pattern over fiber link.

1. Not supported on SPA06MA.


Module installation

The following procedure describes how to install the module to the base.

To connect the module to the ONA-800

- 1 Verify that the power is OFF on your ONA-800 and the power adapter is unplugged.
- 2 Remove the back termination cover or CAA/OTDR modules.
- 3 Remove the screen from the ONA-800 base:
 - a Set the unit so you have access to the back. Using the hex key located in the groove on the back of the ONA-800, loosen the four fasteners, as shown in [Figure 2](#).


Figure 2 Fastener locations



b Lift the ONA-800 base off of the screen.


- 4** Set the module onto the screen, ensuring the mating connectors between the two pieces are aligned, as shown in [Figure 3](#).

Figure 3 Module to screen alignment



- 5** Insert the hex key in the brass fittings on the rear of the module and tighten the internal captive fasteners to secure the module to the display.
- 6** Set the ONA-800 base to the module, ensuring the mating connectors are aligned, as shown in [Figure 4](#).

Figure 4 Base to module alignment



- 7 Set the unit so you have access to the back. Using the hex key, tighten the fasteners.
- 8 Replace the back termination cover or CAA/OTDR modules.

Using Spectrum Analyzer

This chapter describes how to use the Spectrum Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 8](#)
- [“Selecting mode and measure” on page 8](#)
- [“Configuring spectrum measurements” on page 9](#)
- [“Setting frequency” on page 9](#)
- [“Setting channel” on page 11](#)
- [“Setting amplitude” on page 11](#)
- [“Setting BW/AVG” on page 13](#)
- [“Selecting sweep” on page 14](#)
- [“Setting trigger” on page 15](#)
- [“Setting trace” on page 16](#)
- [“Setting limit” on page 18](#)
- [“Using marker” on page 20](#)
- [“Conducting spectrum measurements” on page 22](#)
- [“Conducting RF measurements” on page 22](#)
- [“Utility” on page 34](#)

Introduction

The advantage of using the Spectrum Analyzer is easy to verify the presence of unwanted signals such as spurious and harmonics, which are normally very hard to identify in time domain analysis.

Performance assurance in wireless communication systems includes the observation of the out-of-band signal characteristics in order to identify the presence of harmonic signals. Harmonic signals of a carrier may interfere with other signals far out of the transmission band, or harmonic signals from other transmitter may interfere with in band signals affecting the spectral integrity.

In these days when wide variety of wireless communication services are provided in frequency bands assigned very closely to each other, it is critical to ensure that each communication service is carried out within their assigned frequency band minimizing interference with adjacent frequency bands. The Adjacent Channel Power Ratio (ACPR) characteristic of a power amplifier or other RF components is an important factor in evaluating the system performance.

Spectrum analyzer has measure categories as the following:

- Spectrum Analysis
 - Sweep Tuned Spectrum
- RF Analysis
 - Channel Power
 - Occupied Bandwidth
 - Spectrum Emission Mask
 - Adjacent Channel Power (ACP)
 - Multi Adjacent Channel Power (multi-ACP)
 - Spurious Emissions
 - Total Harmonic Distortion (THD)
 - Field Strength
- Utility
 - Gated Sweep
 - Route Map

Selecting mode and measure

The following procedure describes how to start measurement.

To start measurement

- 1 Tap **Spectrum Analyzer** on the **MODE** panel.

2 Tap any measurement mode from the following choices:

Table 1 Measurement modes

Mode	Measurement
Spectrum Analysis	Sweep Tuned Spectrum
RF Analysis	Channel Power Occupied Bandwidth
	Spectrum Emission Mask
	Adjacent Channel Power
	Multi-Adjacent Channel Power
	Spurious Emissions
	Total Harmonic Distortion
Utility	Field Strength
	Gated Sweep
	Route Map

Configuring spectrum measurements

The Quick Access and Display tab contains all necessary functions to configure the horizontal axis, vertical axis, and to configure and trigger the sweep for spectrum measurements. The Quick Access and Display tab also allows you to set traces, markers, display lines, and limit lines. The contents of the menu vary by the currently selected measurement.

The horizontal axis contains frequency information in spectrum mode. You can specify the frequency in terms of the center frequency or by defining a start and stop frequency for a particular span. The settings related to the vertical access can be accessed using the Amp/Scale menu.

Setting frequency

You need to set the frequency range to be measured with either the center frequency/ span or the start/stop frequencies. You can also set the frequency with the channel number and span. The center frequency or start and stop frequency values appear below the graticule on the display.

If you are aware of the frequency of the signal you are going to measure, the best option is to match the center frequency to the signal's frequency. If you are investigating signals that are within a particular frequency range, it is best to enter a start and stop frequency to define the span.

Frequency and span

Table 2 describes each key function.

Table 2 Key Frequency Functions.

Parameter	Description
Center Frequency	Sets the horizontal center of the display to a specific frequency using the on-screen keyboard. The left and right sides of the graticule correspond to the start and stop frequencies using the on-screen keyboard. Access: Menu> Frequency> Center Frequency
Start Frequency	Sets the frequency starting at the left side of the graticule. Access: Menu> Frequency> Start Frequency
Stop Frequency	Sets the frequency starting at the right side of the graticule. The right sides of the graticule correspond to the stop frequency using the on-screen keyboard. Access: Menu > Frequency > Stop Frequency
Frequency Step	Sets the step size for the frequency setting. The step size function is useful for finding harmonics and sidebands beyond the current frequency span of the instrument using the on-screen keyboard. Access: Menu > Frequency > Stop Frequency
Frequency Offset	Allows you to set a frequency offset value that is added to the frequency readout of the marker, to account for frequency conversions external to the instrument using the on-screen keyboard. Offset entries are added to all frequency readouts including marker, start frequency, and stop frequency. Offsets are not added to the span or frequency count readouts. Setting and offset does not affect the trace display. Access: Menu > Frequency > Frequency Offset
Span Frequency	Sets frequency range symmetrically about the center frequency using the on-screen keyboard. The span frequency readout describes the total displayed frequency range. To determine span frequency per horizontal graticule division, divide the frequency span by 10. Access: Menu > Frequency > Span Frequency
Full Span	Sets the span to full span, showing the full frequency range of the instrument. Access: Menu > Frequency > Full Span
Zero Span	Sets the frequency span to zero. In this mode, the current center frequency is displayed in the time domain. It is only available in the spectrum mode. If you have selected Zero Span, select Trigger> Free, External, GNSS, or Video . Access: Menu > Frequency > Last Span

Table 2 Key Frequency Functions.

Parameter	Description
Last Span	Sets the span to the previous span setting. Access: Menu > Frequency > Last Span

Setting channel

Almost all transmission systems divide their assigned frequency ranges into channels. Each channel corresponds to a specific frequency. To operate such systems, you can use a channel standard table instead of setting frequencies manually. You can set the frequency with either frequency or channel number.

Channel number, channel step, and channel standard

Table 3 describes each function.

Table 3 Channel functions

Parameter	Definition
Channel Number	Sets the channel number using the on-screen keyboard. You can set the center frequency as channel number instead of setting frequency. In order to set the accurate frequency, you need to set the channel standard and link first. Access: Menu > Channel > Channel Number
Channel Step	Sets the channel step using the on-screen keyboard. Access: Menu > Channel > Channel Step
Link	You can toggle between Uplink and Downlink . Access: Menu > Channel > Link Uplink/Downlink
Channel Standard	Shows a list of technology, Band Class, Channel Range, and Frequency Range (MHz). Tap to set the channel standard. Access: Menu > Channel > Channel Standard

Setting amplitude

You can set the reference and attenuation levels automatically or manually to optimize the display of the traces measured.

Table 4 describes each function.

Table 4 Amplitude functions

Parameter	Definition
Reference Level	Sets the horizontal bar that can be placed at any graticule. Enter a value using the on-screen keyboard. Access: Menu > Amp/Scale > Reference Level
Attenuation	Tap to set the attenuation value using the on-screen keyboard. Access: Menu > Amp/Scale > Attenuation
Attenuation Auto/Couple/Manual	Tap to select the attenuation option from Auto , Manual , or Couple . <ul style="list-style-type: none"> – Auto: sets the input attenuator's level automatically; you must select a lower attenuation. – Manual: sets the input attenuation manually up to 55 dB to optimize S/N – Couple: couples the input attenuator's level with your reference level setting Access: Menu > Amp/Scale > Attenuation/Manual
Scale Division	Allows you to use the Scale/Div feature available for the total harmonic distortion screen. It represents the value of one division on the horizontal scale. The default setting is 10 dB per division and the maximum value can be set up to 20 dB. Set the value using the on-screen keyboard. Access: Menu > Amp/Scale > Scale Division
Scale Unit	Tap to change the scale unit of the display scale: dBm, dBV, dBmV, dBμV, V, or W. Access: Menu > Amp/Scale > Scale Unit
Preamp On/Off	Allows you to turn the internal pre-amplifier on to correct and compensate for the gain of the preamp so that amplitude readings show the value at the input connector. It is the first Preamp for the FR1 Band and operated when the input level is -50 dBm or below. Access: Menu > Amp/Scale > Preamp On/Off
External Offset Mode On/Off	Tap to turn the external offset mode on or off. Access: Menu > Amp/Scale > External Offset On/Off
External Offset	Tap to manually set the external offset value form -120 to 120 using the on-screen keyboard. When you compensate for the external loss, input the negative values. when you compensate for the external gain, input the positive values. Access: Menu > Amp/Scale > External Offset
Auto Scale	Tap to automatically set the reference and attenuation level. Each time you tap this, both of the Y-Axis scale and input attenuation level change to be optimized with some margin. Access: Menu > Amp/Scale > Auto Scale

**NOTE**

It is recommended that you set the Attenuation to Auto in most situations, so that the level of the input attenuator can be set automatically according to your input signal level.

Setting BW/AVG

You can manually set the Resolution Bandwidth (RBW), Video Bandwidth (VBW), and the proportional VBW based on the designated RBW. Selecting Auto changes the value to correspond to your frequency span setting for RBW and VBW/AVG settings for VBW.

Table 5 describes the key functions.

Table 5 BW/AVG functions

Parameter	Description
RBW	Tap RBW to set it manually. Tap a value between 1 Hz to 3 MHz. The RBW setting automatically changes to Manual. Access: Menu > BW/AVG > RBW
RBW Mode Manual/Auto	Toggle the RBW Mode to Manual or Auto. When you select Auto, it will be automatically set to an approximate value for Span/100. Access: Menu > BW/AVG > RBW (Manual/Auto)
VBW	Tap VBW to set it manually. Tap a value between 1 Hz to 3 MHz. The VBW setting automatically changes to Manual. Access: Menu > BW/AVG > VBW
VBW Mode Manual/Auto	Toggle the RBW Mode to Manual or Auto. Access: Menu > BW/AVG > VBW (Manual/Auto)
VBW/RBW	Sets the proportional VBW based on the designated RBW. Select the ratio: 1, 0.3, 0.1, 0.03, 0.01, 0.001, or 0.003. Toggle the VBW and RBW to Auto. Access: Menu > BW/AVG > VBW/RBW
Average	Sets the number of measurements to be averaged for the trace presentation. Access: Menu > BW/AVG > Average

Table 6 provides a VBW/RBW ratio example.

Table 6 VBW/RBW ratio example

RBW	Ratio (VBW/RBW)	VBW
30 kHz	1:1	30 kHz
	1:0.3	10 kHz

Table 6 VBW/RBW ratio example

RBW	Ratio (VBW/RBW)	VBW
	1:0.1	3 kHz
	1:0.03	1 kHz
	1:0.01	300 kHz
	1:0.003	100 Hz

Selecting sweep

You can set the length of time that the instrument takes to tune across the displayed frequency span or, in zero span, the time that the instrument takes to sweep the full screen. Reducing the sweep time increases the sweep rate. The default setting so the sweep mode are **Continue** and **Normal** to sweep continuously at a normal speed for most on-going measurements. If you want to hold the measurement or get a single sweep, you can change the sweep mode.

Table 7 describes each key function.

Table 7 Sweep functions

Parameter	Definition
Sweep Time	Shows the sweep time when the sweep time is set to Auto . If the sweep time is set to Manual , you can manually input the sweep time using the on-screen keyboard. Access: Menu > Sweep > Sweep Time
Sweep Time Mode Manual/Auto	Select the sweep time mode to Manual to set it manually or to Auto to set it automatically. Access: Menu > Sweep > Sweep Time Manual/Auto
Sweep Mode Single/Continue	Tap to switch the sweep mode to Single or Continue . Access: Menu > Sweep > Sweep Mode Single/Continue
Sweep Once	Tap to get a new measurement in Single mode. If Continue is set in Sweep Mode , the sweep mode will be changed to Single after tapping it. Access: Menu > Sweep > Sweep Once
Sweep Speed	Tap the sweep speed to Fast to speed up sweeping. You can set the parameter to Fast when the RBW range is from 1 kHz to 3 MHz. Access: Menu > Sweep > Sweep Mode Fast/Normal
Zero Span Time	Enabled when you select Zero Span . Adjusts Sweep Time to allow enough time for a cycle. Access: Menu > Sweep > Zero Span Time

Table 7 Sweep functions

Parameter	Definition
Period Time	Enabled when you select Zero Span . Tap to set Period Time using the on-screen keyboard. Access: Menu > Sweep > Period Time
Period Type Manual/Standard	Enabled when you select Zero Span . Tap to switch Period Type to Manual or Standard. Access: Menu > Sweep > Period Type Manual/Standard
Standard Signal	Enabled when you select Zero Span . Tap to select Standard Signal from: GSM, WCDMA, LTE, EV-DO, TD-SCDMA, or WiMAX . Access: Menu > Sweep > Standard Signal

Setting trigger

If you have to perform measurements according to certain signal conditions, you can use a trigger. A trigger responds to certain events. When a trigger source other than Free, the Spectrum Analyzer starts to sweep only when the selected trigger conditions are met. The trigger can be generated either externally or internally.

[Table 8](#) describes each function.

Table 8 Trigger functions

Parameter	Description
Free	Select Free to start a new sweep immediately after the current sweep ends. This is the default state of the Spectrum Analyzer module. Access: Menu > Trigger > Free
Internal	Select Internal to start a sweep using the internal reference clock and creating a trigger. Access: Menu > Trigger > Internal
External	Select External to start a sweep based on the external input trigger. Access: Menu > Trigger > External
GNSS	If you use a GNSS receiver while performing measurements on a base station, you can synchronize the sweep via the GNSS receiver. Access: Menu > Trigger > GNSS
Video	A sweep starts when the video voltage exceeds a particular level. The video trigger is only available in the time domain (when it is Zero Span = 0).

Setting trace

The Spectrum Analyzer module provides display of up to 6 traces. Each trace consists of a series of points where amplitude data is stored. The module updates the information for any active trace with each sweep.

[Table 9](#) describes the functions.

Table 9 Trace functions

Parameter	Definition
Select Trace	Tap to select trace from the following options: Trace 1, Trace 2, Trace 3 Access: Menu > Trace > Select Trace
Trace View On/Off	Select the Trace View to On or Off . Once you have selected On, you can see the selected trace with its dedicated color on the chart. When Off, the Trace Legend is indicated on the Quick Access and display tab for Trace. Access: Menu > Trace > Trace View On/Off
Trace Type	Tap to select the Trace Type from the following options: Clear Write, Capture, Max, Min, or Load. For details, see “Trace type” on page 16 . Access: Menu > Trace > Trace Type
Trace Hold Time	Tap to set the Trace hold Time using the on-screen keyboard. Access: Menu > Trace > Trace Hold Time
Select Trace Info	Tap to select the trace information from the following options: None, Trace 1, Trace 2, Trace 3, Trace 4, Trace 5, or Trace 6 . Access: Menu > Trace > Select Trace Info
Detectors	Tap to select the detection mode from the following options: Normal, Peak, RMS, Negative Peak, or Sample . See “Trace type” on page 16 for more information. Access: Menu > Trace > Detectors
Trace Clear All	Tap to remove all the traces and initialize the trace settings. Access: Menu > Trace > Trace Clear All
T1-T2 → T5	If Trace 1 and Trace 2 are active, this menu is activated.
T2-T1 → T5	If Trace 1 and Trace 2 are active, this menu is activated.

Trace type

The following **Trace Types** are available:

- **Clear Write:** Clears current data and display with new measurements. Once selected, the Trace Legend, W is indicated on the Quick Access and display tab for Trace.

- **Capture:** Captures the selected trace and compares traces. Once selected, the Trace Legend C is indicated on the Quick Access and display tab for Trace.
- **Max Hold:** Displays the input signal's maximum response only (unlimited or for a certain amount of time). Once selected, the Trace legend M is indicated on the Quick Access and display tab for Trace.
- **Min Hold:** Display the input signal's minimum response only (unlimited or for a certain amount of time). Once selected, the Trace legend m is indicated on the Quick Access and display tab for Trace.
- **Load:** Loads a saved trace. Once selected, the Trace Legend L is indicated on the Quick Access and display tab for Trace.

**NOTE:**

For the Max Hold and Min Hold, your instrument compares newly acquired data with the active trace and displays larger maximum values or smaller minimum values on the screen.

Trace detection


The following Trace detections are available:

- **Normal:** Displays random noise better than the peak without missing signals.
- **Peak:** Displays the highest value in each data point.
- **RMS:** Displays root mean squared average power across the spectrum.
- **Negative Peak:** Displays lowest value in each data point.
- **Sample:** Displays the center value in each data point.

Trace math

The trace math shows the difference of Trace 1 and Trace 2 measurement results. If Trace 1 and Trace 2 are active, the menu, $T1 - T2 \rightarrow T5$ or $T2 - T1 \rightarrow T6$ become available and you can perform trace math. When performing the trace math, the scale is automatically set and the display of scale for the trace math is on the right side of the screen, as shown in [Figure 5](#).

Figure 5 Trace 1 and Trace 2 measurement results



Setting limit

A limit value can be set to alert you that the measured value exceeds the value that is specified. If the span is selected as Zero Span, the line is not displayed.

Table 10 describes each function.

Table 10 Limit functions

Parameter	Description
Display Line	Tap to set values for the reference line using the on-screen keyboard. Access: Menu > Limit > Display Line
Display Line Mode On/Off	Tap to set the Display Line Mode to On or Off to display or dismiss the reference line. The inactive vertical move bar on the left edge with straight line appears across the screen to be used as a visual reference only. To adjust the display line, tap and drag the move bar up or down. The vertical move bar then becomes activated. If there is no touch operation for 2 seconds, the move bar becomes inactive again. The display line does not indicate Pass/Fail. Access: Menu > Limit > Display Line Mode On/Off
Multi Segment Line	Tap Multi Segment Line for Pass/Fail indication. Access: Menu > Limit > Multi Segment Line

To configure Multi Segment Line

- 1 Tap **Menu > Limit**
- 2 Tap **Multi Segment Line**.

- 3 Tap to switch the selected side to **Upper** or **Lower**.
- 4 Tap the **# of Line** to set the number of segments for the selected side for upper or lower up to 50 segments using the on-screen keyboard.
- 5 Tap the **Autoset** soft key to automatically set the limit for each segment and display the line.
- 6 Tap **Offset Up/Down** or **Offset Left/Right** to move the limit line using the on-screen keyboard.

Table 11 describes the parameters displayed for the multi segment line.

Table 11 Multi Segment Line parameters

Parameter	Description
Autoset	Tap to autoset the limit for each segment and display line. Access: Menu > Limit > Multi Segment Line > Autoset
Select Side	Tap to set the Select Side to Lower or Upper to select the one to be displayed. Access: Menu > Limit > Multi Segment Line > Select Side Lower/Upper
Limit	Tap to select the Limit to On or Off, Once the Autoset is selected, the Limit changes to On. Access: Menu > Limit > Multi Segment Line > Limit On/Off
# of Line	Tap to set the # of Line up to 50 segments for the upper or lower limit line using the on-screen keyboard. Access: Menu > Limit > Multi Segment Line > # of Line
Offset Up/Down (dB)	Tap to set the Offset Up/Down to move the limit line up or down when the Display Line Mode is set to On using the on-screen keyboard. Access: Menu > Limit > Multi Segment Line > Offset Up/Down
Offset Left/Right	Tap to set the Offset Left/Right parameter left or right when the Display Line Mode is set to On using the on-screen keyboard. Access: Menu > Limit > Multi Segment Line > Offset Left/Right
Edge Limit Table	Tap to edit the Limit Table . The Limit Table appears on the bottom of the chart screen. Access: Menu > Limit > Multi Segment Line > Edit Limit Table

Editing limit table

- 1 Tap to switch the select side to **Upper** or **Lower**.
- 2 Tap **Select Display Plot** to select the segment that you want to edit.
- 3 Tap the switch to switch the selected segment line to **On** or **Off**.

To remove the selected segment line, select **Off**.

- 4 Tap **Add Point** to add a new segment line
- 5 Tap **Delete Point** to delete the selected point.
- 6 Tap **Frequency** or **Amplitude** to change the position and input the value using the on-screen keyboard.



NOTE
If the **Upper** and **Lower** are set to **Off** in the **Select** side menu, **Edit Limit Table** mode is not available.

Using marker

Marker is used to get the information about a specific trace. Six markers can be set on the display, and each marker can be used independently. The X and Y coordinates of the trace are displayed when the marker is placed on any position of the trace. The position of the trace. The position displaying the marker's X and Y coordinates may be slightly different for each measurement mode and refer to the description of each measurement. There are three different marker types available: Normal, Delta, and Delta Pair. Marker position can be set manually by entering numeric values (frequency) or using the purple move bar when one of the marker types is selected.

Table 12 describes the functions.

Table 12 Marker functions


Parameter	Definition
Frequency Count On/Off	Used when a highly accurate reading of the frequency is needed for the active marker on the signal, then measurement of the signal peak with 1 Hz resolution in background. Select to switch the Frequency Count between On and Off to enable or disable the frequency count for the selected marker. Access: Menu > Marker > Frequency Count On/Off
Noise Marker On/Off	Used to measure a noise adjacent to a signal by an average in several data points to calculate the readout for the Noise marker as if making a measurement using a 1 Hz bandwidth. Select to switch the Noise Marker between On and Off to enable or disable the Noise Marker function for the selected active marker. Access: Menu > Marker > Noise Marker On/Off



NOTE
Frequency Count and Noise Marker functions are only used in the Spectrum Analyzer mode.

Using marker table

The following describes the marker table.

- **Select Marker:** Selects an active marker whose position can be changed by tapping and switching marker from M1 to M6. Each marker has a different color. The assigned number of the active marker is displayed in the Marker Table box, and the active marker number is displayed next to the active marker on the trace. When tapping the Active Marker Off () icon, the selected marker disappears.
- **Normal:** Provides the reading of a marker position on the trace, along with the marker number between one and six.
- **Delta:** This Delta marker type is associated with a Normal marker. A Normal marker must be set before a Delta marker is set. When the Delta marker is set, the position set by the Delta marker becomes the reference position of the Normal marker, and the marker's X and Y values display the difference compared with the Delta marker.
- **Delta Pair:** This marker type is associated with a Normal marker. A Normal Marker must be set before a Delta pair marker is set. When the Delta Pair marker is set, the position set by the Delta Pair marker becomes the reference position of the Normal marker, and the marker's X and Y values display the difference compared with the Delta Pair marker. The reference position will be varied in accordance with trace change.
- **Marker All Off:** Turns all markers on the screen off. When the Marker View is selected for those marker's the instrument displays those markers at the previous position. If a measurement mode is changed, the current settings are not restored.
- **Start:** Sets the frequency of the active marker to the start frequency of the spectrum analyzer.
- **Center:** Sets the frequency of the active marker to the center frequency of the spectrum analyzer.
- **Stop:** Sets the frequency of the active marker to the stop frequency of the spectrum analyzer.
- **Peak Search:** Moves the active marker to the highest peak of the trace. You can also tap the hot key icon to use this function.
- **Min Search:** Moves the active marker to the lowest peak of the trace.
- **Next Peak:** Moves the active marker to the second highest peak of the trace.
- **Left Peak:** Moves the active marker to the highest peak to the left of its current position.
- **Right Peak:** Moves the active marker to the highest peak to the right of its current position.
- **Always Peak:** When Always Peak is set to On, the instrument moves the active marker automatically to the highest peak of the trace every time the trace is refreshed.

To move a marker to a selected trace

- 1 Tap **Menu > Trace**

- 2 Tap Select **Trace**, and select the trace from **Trace 1** to **Trace 6**.
 - 3 Tap **Trace View** and select **On**.
- The selected marker moves to the selected trace.




NOTE

If the marker is beyond the frequency range, the purple horizontal move bar appears on the left and right edge of the chart screen. You can move the marker by moving the bar right and left.

Conducting spectrum measurements

If you have configured test patterns as described in “[Configuring spectrum measurements](#)” on page 9, your measurement is displayed on the screen, as shown in [Figure 6](#) on page 22. You can change **Center Frequency** and **Span** by tapping the icons below the result chart screen.

Figure 6 Sweep tuned spectrum measurement with spectrum analyzer.



NOTE

If the sweep mode is set to Normal and RBW is 300 Hz or below, the Sweep Type changes to FFT. If the Sweep Mode is set to Fast and RBW is 30 kHz or below, the Sweep Type changes to FFT.

Conducting RF measurements

The following sections describe how to conduct RF measurements.

Channel Power


The Channel Power measurement is a common test used in the wireless industry to measure the total transmitted power of a radio within a defined frequency channel. It acquires a number of points representing the input signal in the time domain, transforms this information into the frequency domain using Fast Fourier Transform (FFT), and then calculates the channel power. The effective resolution bandwidth of the frequency domain trace is proportional to the number of points acquired for the FFT.

The channel power measurement identifies the total RF power, power spectral density, and Peak to Average Ratio (PAR) of the signal within the channel bandwidth.

Setting measure setup

After configuring the spectrum measurement as described in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting **File Type** as Setup, and load the file onto the instrument using the Save/Load icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Integrated BW** and input the value using the on-screen keyboard.
You can also tap the rectangle with the value under the chart screen and input the value using the on-screen keyboard.
- 3 Tap Span 50.000 000 MHz to set the frequency range over which the instrument will sweep using the on-screen keyboard.
- 4 Tap **Menu > Sweep > Gated Sweep** to set the Gated Sweep On or Off.
- 5 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the on-screen keyboard. The input value range is from 1 to 100.



NOTE

Ensure the Detector is configured as RMS when you perform the channel power measurement.

To set the Setting limit


- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication.
The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 Tap **Low Limit** to set the lower threshold using the on-screen keyboard.

- 5 *Optional:* Tap the **Save** hot key on the side bar and select the save option from the choices available for your measurement mode.

Channel power measurement

Channel Power Measurement result shows channel power and spectrum density in a user specified channel bandwidth. The peak to average ratio (PAR) is shown at the bottom of the screen as well. The shaded area on the display indicates the channel bandwidth. [Figure 7](#) shows an example of Channel Power Measurement.

Figure 7 Channel power measurement



NOTE


If the Trace View is set to Off, the Channel Power, Spectral Density, and Peak to Average Ratio is shown with value and “*” at the end of the value.

Occupied bandwidth with spectrum analyzer

Occupied Bandwidth measures the percentage of the transmitted power within a specified bandwidth. The percentage is typically 99%.

After configuring spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting the File Type as Setup, and load the file onto the instrument using the Save/Load icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Occupied BW% Power** and input the value using the on-screen keyboard. You can also tap the rectangle with value located under the chart screen and input the value using the on-screen keyboard.
- 3 Tap **x dB** to input a value using the on-screen keyboard. The input value range is from -50 to 0 dB.

- 4 Tap Span to set the frequency range over which the instrument will sweep using the on-screen keyboard.
- 5 Tap Menu > BW/AVG > Average to set the number of measurements to be averaged using the on-screen keyboard.
- 6 The input value range is from 1 to 100.
- 7 Tap Menu > Sweep > Gated Sweep to set the Gated Sweep On or Off.

To set Limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication.
The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 *Optional:* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Spectrum emission mask (SEM)

The Spectrum Emission Mask (SEM) measurement identifies and determines the power level of out-of-band spurious emission outside the necessary channel bandwidth and modulated signal. It measures the power ratio between in-band and adjacent channels. The instrument indicates either Pass or Fail based on the specified limit of the signal.

Setting measure setup

After configuring spectrum measurement as described in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the Save/Load icons on the sidebar.

To set measure setup


- 1 Tap the Setup () icon on the side bar.
- 2 Tap Main Channel BW to set the main channel bandwidth and input the value using the on-screen keyboard.
You can also tap the rectangle with value under the chart screen and input the value using the on-screen keyboard
- 3 Tap Configuration to configure an offset, up to five. The SEM offset configuration table appears, as shown in [Figure 8](#).

Figure 8 SEM offset configuration table

Offset	Offset Frequency	Start Limit	Stop Limit	Measurement BW	Reference
1 <input checked="" type="checkbox"/>	869.000 kHz	-13.00 dBm	-13.00 dBm	30 kHz	Relative Absolute

- Select **Offset** from 1 to 5 and switch each to **On** to display or **Off** to hide the active offset.
 - Select **Offset Frequency** to start the frequency of SEM using the on-screen keyboard.
 - Select Measurement Bandwidth to set the bandwidth for the selected offset using the on-screen keyboard.
 - Switch the Reference to Relative or Absolute, depending on how you are using the reference.
 - Select Start Limit to set the start point of the mask.
 - Select Stop Limit to set the stop point of the mask.
- 4 Tap **Menu > Sweep > Gated Sweep** to set the **Gated Sweep On** or **Off**.

To set the limit

- Tap **Menu > Limit**.
- Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication.
The result table color is green for Pass, and red for Fail.
- Optional:* Tap the Save hot key on the side bar and select the save option from the choices available for your measurement mode.

Figure 9 Spectrum emission mask measurement with spectrum analyzer



If Lower Peak or Upper Peak indicates Fail, the mask line becomes red.



NOTE

If the Trace View is set to Off, the Reference Power, Lower Peak, and Upper Peak is not shown. If the Trace View is set to On and the Trace Type is selected other than Clear Write, the Reference Power, Lower Peak, and Upper Peak is shown with value and “*” at the end of the value.

Adjacent channel power (ACP)

The Adjacent Channel Power (ACP) is the power contained in a specified frequency channel bandwidth relative to the total carrier power. It may also be expressed as a ratio of power spectral densities between the carrier and the specified offset frequency band.

The ACP measures the power of a carrier channel and the power in its adjacent (offset) channels. The measurement results allow you to determine whether the carrier power is set correctly and whether the transmitter filter is working properly. You can measure the channel power in from one to five adjacent (offset) channels on the lower frequency band.

Setting measure setup

After configuring spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the Save/Load icons on the side bar.

To set measure setup



- 1 Tap the Setup () icon on the side bar.
- 2 Tap **Main Channel BW** to set the main channel bandwidth and input the value using the on-screen keyboard.
You can also tap the rectangle with value under the chart screen and input the value using the on-screen keyboard.
- 3 Tap Configuration to configure an offset, up to five. The table appears as shown in [Figure 10](#).

Figure 10 ACP offset configuration table

Offset	Offset Frequency	Integration BW	Lower	Upper	
1	 869.000 kHz	30.000 kHz	-45.00 dBm	-45.00 dBm	X

- a Select **Offset** from 1 to 5 and switch each to **On** to display or **Off** to hide the offset.
 - b Select **Offset Frequency** to set the center frequency of the offset using the on-screen keyboard.
 - c Select **Integration BW** to set the channel power bandwidth for the selected offset using the on-screen keyboard.
 - d Select **Lower** to set the threshold for the power difference between the main channel bandwidth and the selected offset bandwidth on the left using the on-screen keyboard.
 - e Select **Upper** to set the threshold for the power difference between the main channel bandwidth and the selected offset bandwidth on the right using the on-screen keyboard.
- 4 Tap **Menu > Sweep > Gated Sweep** to set the Gated Sweep **On** or **Off**.
 - 5 Tap **Menu > Trace > Threshold RMS** to switch **On** or **Off**. The Threshold RMS function detects RMS above a certain level of power and make sample detecting for the power below that level. When switched **On**, Average is automatically set to 100. When switched **Off**, Average is automatically set to 1. Threshold can also be adjusted by the menu under **Trace, Threshold Auto**, and **Threshold RMS Level**.

An offset represents a difference in center frequencies of the carrier channel and its adjacent channel to be measured. The frequency range for each offset is specified with an Offset Frequency and Integration BW. Each offset that is created has a Lower and Upper set of frequencies.



NOTE

Make sure the Detector is selected to RMS when you perform the adjacent channel power measurement.

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the Test Limits to On or Off to enable or disable Pass/Fail indication. The result table color is green for Pass, and red for Fail.
- 3 *Optional:* Tap the Save hot key on the side bar and select the Save option from the choices available.

Figure 11 Adjacent channel power measurement with Spectrum Analyzer




Multi adjacent channel power

The Multi-ACP measurement is used to do multi-channel ACP testing. It helps you to measure ACP in multichannel transmitting base station environment.

Setting measure setup

After configuring spectrum measurement in “[Configuring spectrum measurements](#)” on [page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the Save/Load icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon on the sidebar.
- 2 Tap **Main Channel BW** to set the main channel bandwidth and input the value using the on-screen keyboard.
You can also tap the rectangle with value under the chart screen and input the value using the on-screen keyboard.
- 3 Configure the channel settings:
 - a Tap **Lowest Channel Number** and input the value using the on-screen keyboard.
 - b Tap **Highest Channel Number** and input the value using the on-screen keyboard.
- 4 Configure the **Frequency** settings:
 - a Tap **Lowest Frequency** and input the value using the on-screen keyboard.
You can also tap the rectangle with value under the chard screen and input the value using the on-screen keyboard.
 - b Tap **Highest Frequency** and input the value using the on-screen keyboard.
You can also tap the rectangle with value under the chard screen and input the value using the on-screen keyboard.

- 5 Tap **Configuration** to configure up to five offsets. The configuration table appears, as shown in Figure 12.

You can also tap the **Configuration** icon under the chart screen.

Figure 12 Multi-ACP offset configuration table

Offset	Offset Frequency	Integration BW	Lower	Upper
1	100.000 MHz	90.000 MHz	17.43 dBc	-82.16 dBc


- a Select **Offset** from 1 to 5 and switch each to On to display or Off to hide the active offset.
 - b Select **Offset** Frequency to set the offset frequency using the on-screen keyboard.
 - c Select **Upper** to set the threshold for the power difference between the main channel bandwidth and the selected offset bandwidth on the right using the on-screen keyboard.
- 6 Tap **Span** to set the frequency range over which the instrument will sweep using the on-screen keyboard.
 - 7 Tap **Menu > Sweep > Gated Sweep** to set the Gated Sweep On or Off.

NOTE
Make sure that RM is selected when you perform the multi-adjacent channel power measurement.

To set limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable **Pass/Fail** indication.
The result table color is green for Pass and red for Fail.
- 3 *Optional:* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Figure 13 Multi-adjacent channel power measurement with spectrum analyzer.




Spurious emissions

The Spurious Emissions measurement identifies or determines the power level of in-band or out-of-band spurious emissions within the necessary channel bandwidth and modulated signal. The instrument indicates either Pass or Fail based on the specified limit of the signal.

Setting measure setup

After configuring spectrum measurement in “[Configuring spectrum measurements](#)” on [page 9](#), you can set the measure setup to continue your measurement. The frequency setting is not used in Spurious Emissions mode. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the Save/Load icons on the side bar.

To set measure setup


- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap to switch the **Measure Type** to **Full** or **Examine**.
- 3 Tap **Configuration** to set up the range table and parameters.
 - a Select **Range** from 1 to 20 and switch each to **On** to display the selected range in the result table, or **Off** to hide it from the table.
 - b Select **Start Frequency** to specify the start frequency for the selected range using the on-screen keyboard.
 - c Select **Stop Frequency** to specify the stop frequency for the selected range using the on-screen keyboard.
 - d Select **Start Limit** and **Stop Limit** to specify the upper limit for Pass/Fail indication using the on-screen keyboard. You can set the threshold line by setting the start/stop limit.
 - e Select **Attenuation** and specify a value as a multiple of five using the on-screen keyboard.
 - f Select **RBW** to specify an RBW value using the on-screen keyboard.
 - g Select **VBW** to specify a VBW value using the on-screen keyboard.
- 4 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the on-screen keyboard. The input value range is 1 to 100.

To set limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication.
- 3 *Optional:* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

[Figure 14](#) shows a spurious emissions measurement with the spectrum analyzer.

Figure 14 Spurious emissions measurement with spectrum analyzer



NOTE

If you select the first icon next to the Range table above, it only shows the selected range. If you select the second icon next to the Range table, it keeps moving from the first selected range to the final selected range.

Total harmonic distortion (THD)

You can measure the Total Harmonic Distortion (THD) using the spectrum analyzer. THD is defined as the ratio of RMS voltage of the harmonics to that of the fundamental component. This is accomplished by using a spectrum analyzer to obtain the level of each harmonic with peak detector.

To set measure setup

You need to set the fundamental frequency to measure the total harmonic distortion. Once you set up, it will automatically collect the harmonic outputs up to the tenth harmonics from the spectrum analyzer and calculate the corresponding THD value (%) and the distortion attenuation (dB).




- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Fundamental Frequency** and input the value using the on-screen keyboard. The total harmonic distortion screen changes accordingly.
- 3 Tap **Menu > Amp/Scale** to set the related parameters such as **Reference Level**, **Attenuation**, **Preamp**, **External Offset**, and **Scale Division**. See [“Setting amplitude” on page 11](#) for more information.

Figure 15 Total harmonic distortion measurement with spectrum analyzer

Field strength meter

The Field Strength Meter measures the field strength over the frequency range of a connected antenna, which is known with its specific bandwidth and gain characteristics. A standard or user-defined antenna can be selected from the antenna list in the instrument. After configuring spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement.


To set measure setup

- 1 Connect an antenna to be used with your instrument.
- 2 Tap the **Setup** () icon on the side bar.
- 3 Tap **Antenna List** to select antennas to be used for field strength measurement from the list stored in the instrument.
The antenna list window appears.
- 4 Tap the **Apply** button to apply the selection.
- 5 Tap **Antenna Start Frequency** to edit the start frequency of the connected antenna using the on-screen keyboard.
- 6 Tap **Antenna Stop Frequency** to edit the stop frequency of the connected antenna using the on-screen keyboard.
- 7 Tap **Gain** to input the gain information of the antenna using the on-screen keyboard.

To set the limit

You can show or hide the display line on the screen that is used as a visual reference only. You can also use the multiple segment limit line to set up different limits for different frequency ranges for Pass/Fail indication. See [“Setting limit” on page 18](#) for more information.

Figure 16 Field strength measurement with spectrum analyzer



Utility

The following sections describe the utility functions of the Spectrum Analyzer.

Gate sweep spectrum


To get appropriate gate sweep spectrum, you have to set the gate delay and gate length in a way that the measurement is active during the interesting part of the signal. You can also modify the sweep time in order to match the horizontal axis to the length of the signal and thus set the gate delay and gate length parameters more accurately.

The gate delay parameter means the time between the trigger event and the beginning of the actual measurement. The gate length means the duration of the measurement before it is interrupted, and the next gate signal is expected to resume the measurement.

Measurement settings can be saved and recalled as a file by selecting Setup as the File Type and load the file onto the instrument using the Save/Load icons on the side bar.

[Figure 17](#) shows the Gate Sweep Spectrum Setup screen.


Figure 17 Gate Sweep Spectrum Setup screen



To set Gate Sweep Spectrum

- 1 Tap **Gate Delay** on the setup table and input a value using the on-screen keyboard.
When the gate delay changes, the gate length line also changes accordingly with the same interval.
- 2 Tap **Gate Length** on the setup table and input a value using the on-screen keyboard. The gate length cannot be moved on the left side of the gate delay.
- 3 Tap **Zero Span Time** on the setup table and input a value using the on-screen keyboard.
- 4 Tap **StdSignal** to select a **Standard Signal** from the pop-up list.
- 5 Tap **Period** and switch it to **Standard** or **Manual** and input a value using the on-screen keyboard.
- 6 Tap the **X** button on the setup table. **Gate Sweep** becomes On.
The setup table disappears and the edit mode icon appears on the right edge of the chart screen, as shown in [Figure 18](#).

Figure 18 Gate Sweep Spectrum with spectrum analyzer



- 7 When the judged **Triggering** is not valid, for example a **Delay** set larger than **Trigger Period**, the "Trigger Not Detected" message appears on the screen.

Route map

The module provides a Route Map function that allows you to collect data pf points in an indoor or outdoor environment and track the received signals and coverage of RF transmitters by plotting data real time directly on top of a loaded floor plan or a map.

Figure 19 shows an example of the Route Map.

Figure 19 Route Map with spectrum analyzer



Loading a map

To use any features related to maps, you need to download and install the maps on the instrument. The JDMaPCreator will help you download maps. Make sure the JDMaPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JDMaPCreator. For more information on how to use the JDMaPCreator, see the *JDMaPCreator 2.0 User Guide*.

To load a map






- 1 Plug in your USB flash drive that has a map with a file type of .mcf created in JDMaPCreator.
- 2 Tap the **Load** icon on the side bar.
- 3 Navigate to the map file that you want to open.

The **File Information** pane displays the file properties, including its name, size, type, and date modified.

- 4 Tap the **Load** button on the screen.


- 5 Once you have loaded the map, you can also control the map using the following icons on the map.

Table 13 Map icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, a purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in on the map.
	Tap to zoom out on the map.
	Tap and select the area that you want to expand.

To set measurement setup

Before starting the Route Map measurement, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more information.

- 1 If required, connect a GNSS receiver to your instrument for outdoor mapping. Indoor mapping does not necessarily need a GNSS antenna.
- 2 Tap the Setup () icon on the side bar.
- 3 Tap to switch the Plot Point to GNSS, Position, or Time.
 - a To collect data/plot points automatically as you move around in a vehicle or outside, select **GNSS**, then tap to switch the **Screen Mode** between **Map** and **Full**. With the **Map** setting, you can view only the collected points that can be seen within the boundary of the loaded map. With the **Full** setting, you can view all the collected points of the route without the loaded map.
 - b To collect data/plot points manually in an indoor layout without a GNSS antenna, select **Position**.
 - c To collect data/plot points based on time, select **Time**.
- 4 Tap to switch **Plot Item** to **RSSI** or **ACP**.

- 5 *Optional:* If **ACP** is selected, set the **Main Channel BW** and **Offset Limit**.
 - a Tap **Main Channel BW** and input a value using the on-screen keyboard.
 - b Tap **Offset Limit** and tap to switch the Offset to **On** to display or **Off** to hide the offset.
 - c Tap **Integration Bandwidth** and input a value using the on-screen keyboard.
 - d Tap **Offset Frequency** and input a value using the on-screen keyboard.
 - e Tap **Offset Limit** and input a value using the on-screen keyboard.
- 6 Tap the **Start** button on the right panel of the map to start plotting for the Position or Time setting.
- 7 Touch directly on the screen and tap to collect data and plot points on the loaded map. For the Position setting, you can change the direction of the route with screen touch. For the Time setting, when you first touch screen a purple triangle appears on the point and the "Number of n" appears in the bottom left of the map. The instrument interpolates points in between two enters on a straight dotted line. The max count is 2560, and the time interval is 0.5 s.
- 8 Tap the **Pause** button to pause plotting. The **Pause** button turns blue and GNSS cannot be plotted.
- 9 Tap to switch **Plot** to **Stop** to stop plotting.
- 10 Tap **Menu > Sweep > Gated Sweep** to set the Gated Sweep **On** or **Off**.
- 11 If you start testing and select **Setup > Plot Point > Position**, you can undo by tapping the **Start** button.
- 12 If you select the **Stop** button, the **Plot Stop** popup window appears.



NOTE

The instrument does not automatically save the collected data. It is recommended that you save the result. If not, you will lose all the collected data.

To set limit

You can set the thresholds for the four different color indicators.

- 1 Tap **Menu > Limit**.
- 2 Tap **Excellent** and set a value using the on-screen keyboard.
- 3 Tap **Very Good** and set a value using the on-screen keyboard.
- 4 Tap **Good** and set a value using the on-screen keyboard.
- 5 Tap **Poor** and set a value using the on-screen keyboard.

Using Interference Analyzer

This chapter describes how to use the Interference Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 40](#)
- [“Selecting mode and measure” on page 40](#)
- [“Conducting spectrum measurements” on page 41](#)
- [“Conducting interference measurements” on page 44](#)
- [“Utility” on page 55](#)

Introduction

Interference is becoming more prevalent in the wireless community with the increasing number of transmitters coming on the air. Wireless service providers have traditionally used spectrum analyzers to monitor service channels, frequencies, and adjacent spectrum and to locate sources of interference. A spectrum analyzer can only show you an interfering signal and you require determining the source of the interference. To solve interference problems, you must understand the RF environment, know adjacent operating transmitters, and identify any new or unlicensed emitters.

Once a potential interfering signal is identified in the Spectrum Analyzer mode, you can monitor the signal further in the Interference Analyzer mode. The Interference Analyzer provides two different methodologies to identify and determine interference signals: Spectrogram and Received Signal Strength Indicator (RSSI). Locating the source of interference signal can be done with geographical information received from the built-in GNSS receiver.

The Interference Analyzer provides following measurements for interference analysis:

- Spectrum Analysis
 - Spectrum
 - Spectrogram
- Interference Analysis
 - RSSI (Received Signal Strength Indicator)
 - Interference Finder
 - Radar Chart
- Utility
 - Spectrum Replayer
 - PIM Detection Single Carrier
 - PIM Detection Multi Carrier

Using a set of the AntennaAdvisor Handle that holds a broadband directional antenna is mandatory in the Reider Chart mode and its built-in compass, GNSS antenna, gyro sensor, and low-noise amplifier (LNA) benefits you to determine the direction of the interference.

Selecting mode and measure

The following procedure describes how to start measurement.

To select mode and measure

- 1 Tap Interference Analyzer on the MODE panel.

- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Spectrum** or **Spectrogram**
 - **Interference Analysis > RSSI, Interference Finder** or **Radar Chart**
 - **Utility > Spectrum Replayer > PIM Detection Single Carrier** or **PIM Detection Multi Carrier**



NOTE

You can choose **RF Source On** or **Off** in setup menu after tapping **CAA RF Power On** if you have **RF Source** option in your CAA (Cable and Antenna Analyzer.)

Conducting spectrum measurements


The following sections describe how to conduct spectrum measurements.

Spectrum

Most spectrum measurements of the interference analyzer are also available in Spectrum mode. Using these measurements allows you to located interferences in the frequency spectrum. You can configure the measurements just as in Spectrum mode. For more information, see [“Configuring spectrum measurements” on page 9](#).


The spectrum measurement with an audible indicator is especially useful for locating interferer sources with a directional antenna.

To set measure setup for sound indicator

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Sound Indicator**.
 - a Tap to switch the **Sound** between **On** and **Off** to enable and disable the alarm sound.
 - b Tap to switch the **Alarm Reference** to **Marker** to set the active marker position as the alarm reference.
 - c Tap to switch the **Alarm Reference** to **Line** to set the limit as the alarm reference.
 - d Select **Reference Line** to specify a threshold for the reference line using the on-screen keyboard.
 - e *Optional:* To adjust the volume for alarm sound, tap **Volume** and input a value from 1 to 10 using the on-screen keyboard.

To set measure setup for Interference ID

The Interference ID automatically classifies interfering signals over a designated spectrum and displays the list of possible signal types corresponding to the selected signal.

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Interference ID**.
 - a Tap to switch the **Interference ID** between **On** and **Off** to turn the Interference ID on or off.
 - b Tap **Threshold** and input a value using the on-screen keyboard.



NOTE

You can go to **Menu > Limit** to analyze your measurements with the display line, multi-segment line, and channel limit table. See


Spectrogram

The Spectrogram is particularly useful when attempting to identify periodic or intermittent signals as it captures spectrum activity over time and uses various colors to differentiate spectrum power levels. When the directional antenna is used to receive the signal, you will see a change in the amplitude of the tracked signal as you change the direction of the antenna and see a change in the Spectrogram colors. The source of the signal is located in the direction that results in the highest signal strength.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement.

To set measure setup

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Time Interval** to set the amount of time between each trace measurement using the on-screen keyboard.
- 3 Tap **time Cursor** to **On** to set the time cursor on a specific trace position. The **Position** menu becomes activated.
- 4 Tap **Position** to move the time cursor by inputting a value using the on-screen keyboard.

You can also move the time cursor up and down using the move bar on the left edge.
- 5 Tap **Type** to switch the chart view type to **3d Display** or **Normal**. You can also change the chart view type by using the icon on the chart screen.

6 Tap **Reset/Restart** to start a new measurement.



NOTE

Enabling the time cursor puts the measurement on hold, allowing you to make post-processing analysis for each measurement over time using the time cursor.

Interference measurement in spectrogram

The Spectrogram shows a vertical line on the chart when the marker is enabled on the screen. Figure 20 shows the Normal chart view, and Figure 21 shows the Waterfall (3D display) chart view.

Figure 20 Interference measurement in spectrogram- Normal view





Figure 21 Interference measurement in spectrogram- Waterfall (3D Display) view



In the spectrogram chart:

- The horizontal line (X-axis) indicates frequency.
- The vertical line (Y-axis) indicates time.
- The color identification (Spectrogram) indicates the power level of the tracked signal. As the signal strength increases, the color on the spectrogram changes accordingly.

- Once you set the reference line to On, the purple move bar becomes active and the green line appears. You can set the reference line by moving up or down in the spectrum chart below the spectrogram chart.
- You can set the GNSS by selecting **Frequency Reference** as GNSS on the System Settings page.

Conducting interference measurements

The following sections describe how to conduct interference measurements.


RSSI

The Received Signal Strength Indicator (RSSI) is a multi-signal tracking metric that is particularly useful for measuring power-level variations over time. The RSSI measurement allows you to assign power limit lines for audible alarms, and increase alarm counters every time a signal exceeds a defined limit line. The spectrogram and RSSI measurements can be automatically saved to an external USB drive for long term analysis.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Alarm** to set the alarm parameters.
- 3 Tap **Alarm at** and select the marker number from Marker 1 to Marker 6.
- 4 Tap **Reference Line** to set a threshold for the alarm, and input a value using the on-screen keyboard.
- 5 Tap to switch **Alarm** to **On** or **Off** to turn the alarm feature on or off.
- 6 *Optional:* Tap **Volume** to adjust the volume from 1 to 10 using the on-screen keyboard.




NOTE

You must set the marker(s) for the alarm as this feature use the marker position to sound alarm. See [“Using marker” on page 20](#) for more information.

Interference measurement in RSSI

[Figure 22](#) shows an example of interference measurement in RSSI.

Figure 22 Interference measurement in RSSI



You can go to **Menu > Limit** to analyze your measurements with the display line, multi-segment line, and channel limit. See [“Setting limit” on page 18](#) for more information.

Interference finder

The Interface Finder is an automatic triangulation algorithm that uses GNSS coordinates to locate possible interference sources based on the three measurements. The interference finder calculates possible interference locations using its inscribed circle or circumscribed circle based on measured intersection points. You can plot up to seven measurement points and select three that are more representative for triangulation. The SPA06MA-O automatically logs measurement positions so as to prevent their loss while changing measurement modes. You can switch the main screen from spectrum view to map view and vice versa using the icon on the spectrum view screen. Before starting the Interference Finder, you need to set spectrum measurements, as described in [“Configuring spectrum measurements” on page 9](#).

To make full use of the functions available in map mode, you will need a GNSS receiver and antenna.

Antenna connection

Before starting the measurement, you need to connect the Omni or Log periodic antenna to your instrument. In the Interference Finder and the Radar Chart modes, you can perform interference hunting using the optional AntennaAdvisor Handle after attaching a broadband directional antenna to it. The handle is a device that has a built-in GNSS antenna and LNA. The following are examples of the antenna connection.

To connect an antenna

- 1 Mount a broadband antenna to your AntennaAdvisor Handle.
- 2 Connect the **RF Type-N Jack** of the handle to the **RF In** port of the instrument.

- 3 Connect the **GNSS SMA** jack of the handle to the **GNSS port** of the instrument. The GNSS status indicator appears on the instrument screen.
- 4 Connect the **USB plug** of the handle to the **USB Host port** of the instrument. The device icon appears in the system status bar on the screen.




NOTE

The AntennaAdvisor Handle is an optional item. It is recommended that you use a log periodic antenna with AntennaAdvisor handle to search more exact directional information. You can use a log periodic antenna or Omni antenna alone as well.

Figure 23 shows an example of an antenna connection.

Figure 23 Antenna connection example



Loading a map






To use any features related to maps, you need to download and install the maps on the instrument. The **VIAVI JDMaPCreator** will help you to download maps. Ensure the JDMaPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the **Send to EQP** menu in JDMaPCreator. For information about how to use the JDMaPCreator, see the *JDMaPCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map file in .mcf file type created in JDMap-Creator.
- 2 Tap the **Load** icon on the side bar.
- 3 Navigate to the map you want to open. The **File Information** pane displays the file properties, including name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.

Once you have loaded the map, you can also control the map using the following icons on the map.

Table 14 Map control icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, the purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in the map.
	Tap to zoom out the map.
	Tap and select the area where you want to expand.

Initializing AntennaAdvisor

Once you have connected the AntennaAdvisor Handle to your instrument, antenna initialization is required to get the right azimuth data. You need to initialize the antenna handle to calibrate the built-in compass by completing the following steps. Note that you can adjust Bandwidth based on the center frequency of the interfering signal that you have identified in the Spectrum view by tapping **Measure Setup > Bandwidth**. A message appears at the bottom of the screen to alert you if you have not performed initialization of your connected the antenna handle set.

To initialize AntennaAdvisor

- 1 Hold your antenna handle horizontally in its upright position.
To avoid the unnecessary impact of an external magnetic field, position yourself at the location where the value of the magnetic field strength displayed on the instrument screen is green.
- 2 Point the antenna to the north and tap **Measure Setup > Initialize AntennaAdvisor**.
The message disappears and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization has completed successfully.

Setting geographic location

A point is a particular location that contains information about that location. This information includes, for example, GNSS coordinates, the time of the measurement or level that has been measured. You can evaluate the Point information directly on-site or save the information for later evaluation.

With this functionality, you can mark locations where you have performed a measurement. Thus, you can analyze the geographical distribution of the received signal strength. This allows you to analyze, for example, the coverage conditions around a base station's coverage area.

In the map view, a point is displayed as a dot with a number. The straight line represents the direction you are facing.

To set the geographic location

- 1 Tap the **Point 1**, **Point 2** and **Point 3** on the map. Make sure to set three location points so that the straight lines started from the point can create three intersections.
- 2 Tap each point and use the **Degree** bar or button to change degrees.
Make sure you set three location points so that the straight lines started from the point and can create three intersections.
- 3 Tap the **GNSS** icon to automatically get the selected point's location information.
The instrument displays the latitude and longitude information of the signal received by the GNSS antenna. This function is only available when the GNSS antenna is connected.
- 4 Tap the **Latitude** and **Longitude** icon and enter the value using the on-screen keyboard to manually define a position.
The input values are in decimal degrees.
- 5 Tap the **Apply** button.

Setting azimuth

There are three methods available for setting azimuth:

Method 1: AntennaAdvisor Handle

You can use the Antenna Advisor handle. Make sure you initialize AntennaAdvisor first to get more accurate directional information.

- 1 Press and hold the **TRIGGER** button on the handle and pan the antenna handle to scan through until you find the strongest RSSI value.
RSSI, polarization, elevation, and azimuth readings are continuously updated on the screen while pressing the physical button.
- 2 Release the **TRIGGER** button to stop scanning.

Method 2: Degree bar

The **Degree Bar** functions as a compass. You can use it to set azimuth by moving it right and left.

Tap the circle on the Degree bar and move it gently until you get the right azimuth.

Method 3: Log-periodic antenna

You can use the log-periodic antenna.

Pan your log-periodic antenna to find a signal with the highest RSSI value and measure an azimuth of the interfering signal.



NOTE

The AntennaAdvisor has a built-in low-noise amplifier (LNA) that can be turned on and off using the physical On/Off button located on the rear side of the handle unit. For example, if the received signal is weak, you can turn on the switch to improve S/N.

To save the defined position

- 1 Tap any point on the map where you want to save the position information.
- 2 Tap the **Save Position** icon.
The instrument stores the saved location points in the internal memory, allowing you to load them by using the **Load Position** icon. You can save and load up to 10 positions.

Setting display mode


When the triangulation is done with three location points and azimuth for each point, you can view a circumscribed circle by default. You can change the display mode to inscribed circle or double circles to view a narrower area. The center of the green-shaded circle is determined to be where the source of the interfering signal resides.

To set display mode

- 1 Tap **Measure Setup > Display**.
- 2 Select the option from the following choices:
 - **Circum**: displays a circumscribed circle that meets three vertices of the triangle.
 - **Inscribed**: displays an inscribed circle that meets the three vertices of the triangle.
 - **Double**: displays both circumscribed and inscribed circles.
- 3 Tap **Measure Setup > Screen Mode**.
- 4 Tap the **Screen Mode** to select **Map** or **Full**.
 - **Map**: displays what is inside the base map with the map image.
 - **Full**: displays three location points and defined circle without the map image.

Figure 24 shows an example of the Interference Finder measurement in map view.

Figure 24 Interference Finder measurement in map view



Radar chart

If you have identified an interfering signal in your spectrum view, you can move to the Radar Chart mode and measure RSSI power level through 360° at a location received by the connected broadband directional antenna so that you can determine the direction of the source of the interference. Using a set of the AntennaAdvisor Handle that holds a broadband directional antenna is mandatory in the Radar Chart mode. The built-in compass, GNSS antenna, and built-in low-noise amplifier (LNA) allow you to determine the direction of the interference. You can switch the main screen from spectrum view to map view and vice versa using the icon on the spectrum view screen. Before starting the Interference Finder, you need to set Spectrum measurements. See [“Configuring spectrum measurements” on page 9](#) for more information.

For information about connecting the antenna, see [“Antenna connection” on page 45](#).

Loading a map






To use any features related to maps, you need to download and install the maps on the instrument. The **VIavi JMapCreator** will help you to download maps. Ensure the JMapCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the **Send to EQP** menu in JMapCreator. For information about how to use the JMapCreator, see the *JMapCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map file in .mcf file type created in JMapCreator.
- 2 Tap the **Load** icon on the side bar,
- 3 Navigate to the map you want to open. The **File Information** pane displays the file properties, including name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.

Once you have loaded the map, you can also control the map using the following icons on the map.

Table 15 Map control icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, the purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in the map.
	Tap to zoom out the map.
	Tap and select the area where you want to expand.

Initializing AntennaAdvisor

Once you have connected the AntennaAdvisor Handle to your instrument, antenna initialization is required to obtain the correct azimuth data. You need to initialize the antenna handle to calibrate the built-in compass by completing the following procedure. You can adjust bandwidth based on the center frequency of the interfering signal that you have identified in the Spectrum view by tapping **Setup > Bandwidth**. A message appears at the bottom of the screen to alert you if you have not performed initialization of your connected the antenna handle set.

To initialize AntennaAdvisor

- 1 Hold your antenna handle horizontally in its upright position.
To avoid the unnecessary impact of an external magnetic field, position yourself location where the value of magnetic field strength displayed on the instrument is green.
- 2 Point the antenna to the north and tap **Setup > Initialize AntennaAdvisor**.
The message disappears, and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization was done successfully.



NOTE

It is recommended that you re-initialize the AntennaAdvisor Handle after measurements to re-calibrate the compass when you notice that the red line on the radar chart is not aligned with the north on the map, even though you are pointing the antenna to the north.

Obtaining RSSI data

Once you have connected your antenna handle set and done necessary setups, you can monitor the power level of the received signal, the amount of polarization, and elevation level real time. Using the Trigger button on the antenna handle set, you can plot the RSSI level through 360 degrees at your location.

To obtain RSSI data

- 1 When you have the green GNSS indicator, tap the **GNSS** icon on the side panel to set your current location to the center of the radar chart. The latitude and longitude information at the side of the display changes from “Unknown Position” to the obtained position information.
- 2 Tap the **Save Position** icon on the side panel to save a position to recall for triangulation in the Interference Finder mode and select one that you want to save.
- 3 Monitor the RSSI reading of the received signal. If the signal is weak, turn on the LNA switch on the antenna handle set to improve S/N.

- 4 The message disappears and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization is done successfully.



NOTE

The AntennaAdvisor Handle has a built-in low-noise amplifier (LNA) and you can turn it on and off by toggling the physical On/Off switch located on the rear side of the handle unit

- 5 Hold the antenna handle set horizontally and make the measurement.
- 6 The message disappears and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization is done successfully.
- 7 Obtain a Persistent RSSI value:
 - a Press the **Trigger button** located on the antenna handle.
Each time you press the physical button on the handle, a beep sounds and a power level of the received signal is plotted as a blue dot on the radar chart. Depending on the strength of the measured value, you may hear different tones of beeping.
 - b While panning the antenna horizontally to vary the angle of the direction, repeat pressing the TRIGGER button to obtain at least five points if you want to do the localization.
- 8 To continuously obtain Persistent RSSI values:
 - a Press and hold the TRIGGER button located on the antenna handle to start a continuous measurement.
 - b Pan the antenna handle horizontally through the angle of 360 degrees you desire. A beep is sounded repeatedly to let you know that the measurement is continuing and measured values are plotted on the radar chart.
 - c Release the TRIGGER button to stop the continuous measurement.

- 9 Tap Setup > Screen Mode Full/Map to change the display mode.



NOTE

The maximum number you can plot on the radar chart is 2500 points both in the single and continuous measurements. If your measurement reached to 500 points, you need to reset the measurement by pressing the Localization soft key twice or performing the initialization of the AntennaAdvisor Handle. Concentric circles indicate different levels of RSSI. You can use the AMP/SCALE hard to adjust the amplitude scale of the chart.

- a **Map:** Displays measured points inside the base map image. If you are in the area outside the base map and continue your measurement with the Trigger button, the instrument continues obtaining data even though the radar chart disappears from the screen. You can view obtained data when you change this display option to Full.
- b **Full:** Displays measured points without the base map image. In case that you made measurements in the area outside the map image, selecting this option moves your measured data to the center of the display so that you can view the result.

Localizing RSSI data

The Localization feature allows you to view averaged and smoothed measurement data with a bold green line on the radar chart that helps you determine the direction of the highest RSSI value. When you have five or more data points plotted on the radar chart, you can perform this localization.

To localize RSSI data


- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Localization**.
All measured points turn green and a bold green line appears, indicating the possible direction of the interference source.
- 3 Tap Localization again to clear all the data plots on the radar chart.

Figure 25 shows an example of the Radar Chart. Figure 26 shows an example of the radar chart with localized data.

Figure 25 Radar Chart



Figure 26 Radar Chart localized



Utility

The following sections describe the utility functions of the instrument.

Spectrum Replayer

The Spectrum Replayer allows you to retrieve and replay recorded spectrum analyzer traces in interference analysis mode. These traces can be played back in the spectrogram or RSSI. You can configure the limit line to create failure points when signals exceed it. The failure points are clearly displayed on the trace timeline for quick access during playback.

To replay a spectrum

- 1 Tap the **Setup** () icon on the side bar.

- 2 Tap **Spectrum Replayer**. The **File Manager** window appears.
- 3 Select a file to be loaded and then tap **Load**. The replay bar appears on the bottom of the screen, as shown in [Figure 27](#).

Figure 27 Replay bar



- 4 Tap **Play** to start playing.
- 5 Tap **FWD** or **REV** to change play direction to forward or reverse.
- 6 Tap the left or right arrow of **Speed** to select the speed option: **X1**, **X2**, **X3**, or **X4**.
- 7 Tap **Pause** to pause or stop playing data.
- 8 To move to a particular failure position directly and play from there, tap **Index Fail** and enter a value by using the on-screen keyboard.
- 9 *Optional:* Tap **Setup > Time Cursor On/Off** to display or dismiss the time cursor on the screen. This key becomes activated when you play logged data in the Spectrogram mode.



NOTE

If you connect a USB drive, do not remove it while playing to prevent freezing the USB port, which will require you to restart the instrument to get a USB drive recognized again.

PIM detection

Passive Intermodulation (PIM) Detection allows you to detect Uplink PIM across the full spectrum for any technology. When PIM is detected, the normal repair practice is to replace the offending cable, irrespective of the location of the fault.

To make a single carrier measurement

- 1 Connect the cables as instructed on the screen.
- 2 *Optional:* Check for PIM existence in red by calculation.
 - a Tap **Calculated PIM**.
 - b Check the Radio 1 Band and its information in the table.
 - c Tap **Channel Standard** and select **Technology** and **Band**.
 - d Tap the **Apply** button.
 - e Tap the **X** button to return to the previous screen.
- 3 Tap **Uplink Center Frequency** and input a value using the on-screen keyboard.
- 4 Tap **Uplink Span** and input a value using the on-screen keyboard.
- 5 Tap **Channel Standard**, select **Technology** and **Band**, and then the **Apply** button.

- 6 Tap **Channel Number** and input a value using the on-screen keyboard.
- 7 Tap the **Continue** button on the right edge to continue.
- 8 Set the parameters that appear in the table below the chart screen as needed.

Figure 28 shows an example of a single carrier PIM Detection measurement.

Figure 28 PIM detection — single carrier




To make a multi carrier measurement

- 1 Connect the cables as instructed on the screen.
- 2 *Optional:* Check for PIM existence in red by calculation.
 - a Tap **Calculated PIM**.
 - b Check the Radio 2 Band and its information in the table.
 - c Tap to switch **Mode** to **Band** or **Frequency**.
 - d If **Band** is selected:
 - Tap **Radio 1 Band** and select the technology and band from the channel list.
 - Tap **Radio 2 Band** and select the technology and band from the channel list.
 - e If **Frequency** is selected:
 - Tap **Frequency 1 Band** and select the technology and band from the channel list.
 - Tap **Frequency 2 Band** and select the technology and band from the channel list.
 - f Tap the **X** button to return to the previous screen.
- 3 Tap **Uplink Center Frequency** and input a value using the on-screen keyboard.
- 4 Tap **Uplink Span** and input a value using the on-screen keyboard.

- 5 Tap **Channel Standard**, select **Technology** and **Band**, and then the **Apply** button.
- 6 Tap **Channel Number** and input a value using the on-screen keyboard.
- 7 Tap the **Continue Step 2/4** button on the right edge to continue.
- 8 Set the parameters that appear in the table below the chart screen as needed.
- 9 Tap the **Continue Step3/4** button on the right edge to continue.
- 10 Follow the instructions on the screen and tap the **Continue Step4/4** button on the right edge to continue.
- 11 Tap to enable **Flatness**.

Figure 29 shows an example of a multi carrier PIM Detection measurement.

Figure 29 PIM detection — multi carrier



Using Real-Time Spectrum Analyzer

This chapter describes how to use the Real-Time Spectrum Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 60](#)
- [“Selecting mode and measure” on page 60](#)
- [“Conducting spectrum measurements” on page 60](#)
- [“Conducting interference analysis” on page 66](#)

Introduction

Real-time Spectrum Analysis (RTSA) is a method that leverages overlapping FFTs and high-speed memory to have a 100% probability of intercept (POI), even in extremely dense environments. Real-time bandwidth, the maximum frequency span offering gap-free overlapping FFT processing, is an important variable factor of an RTSA that can enable more detailed analysis of a spectrum, based on the type of signal content under scrutiny.

RTSA supports the following measurements:

- Spectrum Analysis
 - Persistent Spectrum
 - Persistent Spectrogram
- Interference Analysis
 - Persistent RSSI
 - Persistent Interference Finder
 - Persistent Radar Chart
- Utility
 - Real-time Spectrum Replayer

Selecting mode and measure

The following procedure describes how to select the mode and measure.

To select mode and measure

- 1 Tap **Real-time Spectrum Analyzer** on the **Mode** panel.
- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Persistent Spectrum or Persistent Spectrogram**
 - **Interference Analysis > Persistent RSSI, Persistent Interference Finder or Persistent Radar Chart**
 - **Utility > Real-Time Spectrum Replayer**



NOTE

You can choose **RF Source On** or **Off** in setup menu after tapping **CAA RF Power On** if you have **RF Source** option in your CAA (Cable and Antenna Analyzer.)

Conducting spectrum measurements


The following sections describe how to conduct spectrum measurements.

Persistent spectrum

The persistent spectrum of a signal is a time-frequency view that shows the percentage of the time that a given frequency is present in a signal. It is a histogram in power-frequency space. The longer a particular frequency persists in a signal as the signal evolves, the higher its time percentage, and thus the brighter or hotter its color in the display. The persistent spectrum is used to identify signals hidden in other signals.


Figure displays a sample persistent spectrum measurement.

Figure 30 Persistent spectrum measurement




To set measure setup for Sound Indicator

If you have configured test parameters as described in [“Configuring spectrum measurements” on page 9](#), continue to set measure setup. You can change Center Frequency and Span by tapping the icons right below the result chart screen.

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Sound Indicator**:
 - a Tap to switch the **Sound** between **On** and **Off** to enable and disable the alarm sound.
 - b Tap to switch the **Alarm Reference** to **Marker** to set the active marker position as the alarm reference.
 - c Tap to switch the **Alarm Reference** to **Line** to set the limit as the alarm reference. The Reference Line Mode menu becomes activated to be set.
 - d Select the Reference Line to specify a threshold for the reference line using the on-screen keyboard.
 - e *Optional*: To adjust the volume for alarm sound, tap **Volume** and input from 1 to 10 using the on-screen keyboard.

To set measure setup for Interference ID

The Interface ID automatically classifies interfering signals over a designated spectrum and displays the list of possible signal types corresponding to the selected signal.

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap Interference ID.
 - a Tap to switch the Interference ID between On and Off to turn the Interference ID on and off.
 - b Tap Threshold and input a value using the on-screen keyboard.

To set measure setup for POI

The interference ID automatically classifies interfering signals over a designated spectrum and displays the list of possible signal types corresponding to the selected signal.


- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **POI**. You can also access this menu using the Quick Access and Display Tab on top.
 - a Tap to switch the Mode between High and Normal. The following table shows RBW and Span setup range per Normal and High mode.

Table 16 RBW and Span setup ranges

Mode		A	B	C	D
Normal	POI	100 to 34 μ s	392 to 136.5 μ s	800.5 to 270.5 μ s	3200 to 1076 μ s
	Bandwidth	100 to 20 MHz	19 to 5 MHz	4 and 3 MHz	2 and 1 MHz
	RBW	30 kHz to 10 MHz	10 kHz to 1 MHz	3 kHz to 1 MHz	1 kHz to 300 kHz

Mode		A	B	C	D	E	F
High	POI	18.5 to 2 μ s	29.5 to 4 μ s	73.5 to 7.5 μ s	147 to 15 μ s	284 to 28 μ s	587 to 56.5 μ s
	Effective Bandwidth	122.88 MHz	61.4 MHz	30.72 MHz	15.36 MHz	7.68 MHz	3.84 MHz
	Display Bandwidth	100 MHz	50 MHz	25 MHz	14 MHz	7 MHz	3 MHz
	RBW	100 kHz to 30 MHz	100 kHz to 10 MHz	30 kHz to 10 MHz	10 kHz to 3 MHz	10 kHz to 3 MHz	3 kHz to 1 MHz

- b Tap **Speed** and input a value using the on-screen keyboard.

To set the Heatmap marker

- 1 Tap **Menu > Marker**.
The marker setting table appears.
- 2 Tap **Heatmap**.
The vertical bar and horizontal bar appear. A heatmap marker shows the hit rate of X-axis (amplitude) and Y-Axis, whereas a normal trace marker shows a value of the X-axis.
- 3 Tap the chart screen to move the heatmap marker or move the vertical bar and horizontal bar.



NOTE

If you select the heatmap marker, you can only use the Peak Search and Always Peak options. Delta pair is not available. See [“Using marker” on page 20](#) for more details.

To set bitmap

- 1 Tap **Menu > Bitmap**.
- 2 Tap **Dot Persistence Time** and input a value using the on-screen keyboard. This represents the time that accumulates heatmap data.
- 3 Tap to switch **Bitmap Scale** to **On** to enable auto scale or **Off** to disable auto scale.
If the **Bitmap Scale** is **On**, the point where the maximum hit represents maximum colors. If the **Bitmap Scale** is **Off**, the bluer color (closer to 0% of the color bar) is mapped with hit.
- 4 Tap **Bitmap Min** and input % value using the on-screen keyboard.
Bitmap Min represents unused bitmap color range. If you set it to 10%, the color matched with 10% or below does not show.
- 5 Tap **Bitmap Max** and input % value using the on-screen keyboard.
Bitmap Max represents max range of bitmap colors to be used. If you set it to 90%, the color that exceeds 90% does not show.
- 6 Tap **Hit Min** and input % value using the on-screen keyboard.
Hit Min represents the minimum number of hits not to be converted to colors. If you set it to 10%, the hit matched with 10% or below is not converted to colors.
- 7 Tap **Hit Max** and input % value using the on-screen keyboard.
Hit Max represents the maximum number of hits to be converted to colors. If you set it to 90%, the hit matched with 90% or above shows with max colors.


Persistent spectrogram

The persistent spectrogram is useful when attempting to identify periodic or intermittent signals as it captures spectrum actively over time and uses various colors to differen-

tiate spectrum power levels. When the directional antenna is used to receive the signal, you will see a change in the amplitude of the tracked signal as you change the direction of the antenna and see a change in the Spectrogram colors. The source of the signal is located in the direction that results in the highest signal strength.


Figure 31 displays a sample persistent spectrogram measurement.

Figure 31 Persistent spectrogram measurement



To set measure setup

After configuring spectrum measurement as described in “[Conducting spectrum measurements](#)” on page 60, you can set the measure setup to continue your measurement.

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Time Interval** to set the amount of time between each trace measurement using the on-screen keyboard.
- 3 Tap **Time Cursor** to **On** to set the time cursor on a specific trace position.
The Position menu becomes activated to be set. You can also move the time cursor up and down using the move bar on the left edge.
- 4 Tap **Position** to move the time cursor by inputting a value using the on-screen keyboard.
- 5 Tap **Type** to switch the chart view type to **3d Display** or **Normal**.
You can also change the cart view type using the icon on the chart screen.
- 6 Tap **POI**. You can also access this menu via Quick Access and Display Tab on top.
 - a Tap to switch the Mode between High and Normal.

The following table shows RBW and Span setup range per Normal and High Mode.

Mode		A	B	C	D
Normal	POI	100 to 34 μ s	392 to 136.5 μ s	800.5 to 270.5 μ s	3200 to 1076 μ s
	Bandwidth	100 to 20 MHz	19 to 5 MHz	4 and 3 MHz	2 and 1 MHz
	RBW	30 kHz to 10 MHz	10 kHz to 1 MHz	3 kHz to 1 MHz	1 kHz to 300 kHz

Mode		A	B	C	D	E	F
High	POI	18.5 to 2 μ s	29.5 to 4 μ s	73.5 to 7.5 μ s	147 to 15 μ s	284 to 28 μ s	587 to 56.5 μ s
	Effective Bandwidth	122.88 MHz	61.4 MHz	30.72 MHz	15.36 MHz	7.68 MHz	3.84 MHz
	Display Bandwidth	100 MHz	50 MHz	25 MHz	14 MHz	7 MHz	3 MHz
	RBW	100 kHz to 30 MHz	100 kHz to 10 MHz	30 kHz to 10 MHz	10 kHz to 3 MHz	10 kHz to 3 MHz	3 kHz to 1 MHz

b Tap **Speed** and input a value using the on-screen keyboard.

7 Tap **Reset/Restart** to start a new measurement.



NOTE

Enabling the time cursor puts the measurement on hold, allowing you to make post processing analysis for each measurement over time using the time cursor.

To set the Heatmap marker

1 Tap **Menu > Marker**.

The marker setting table appears.

2 Tap **Heatmap**.

The horizontal and vertical bars appear. A heatmap marker shows the hit rate of X-axis (amplitude) and Y-axis whereas a normal tracker marker shows a value of the x-axis.

- 3 Tap the chart screen to move the heatmap marker or move the vertical bar and horizontal bar.



NOTE

If you select the heatmap marker, you can only use Peak Search and Always Peak options. Delta pair is not available. See [“Using marker” on page 20](#) for more information.

To set bitmap

- 1 Tap **Menu > Bitmap**.
- 2 Tap **Dot Persistence Time** and input a value using the on-screen keyboard. The dot persistence time represents the time that accumulates heatmap data.
- 3 Tap to switch **Bitmap Scale** to **On** to enable auto scale or **Off** to disable auto scale. If the Bitmap Scale is On, the point where the maximum hit represents maximum colors. If the Bitmap Scale is Off, the bluer color (closer to 0% if the color bar) is mapped with a hit.
- 4 Tap **Bitmap Min** and input % value using the on-screen keyboard.
The Bitmap Min represents the unused bitmap color range. If you set it to 10%, the color matched with 10% or below does not show.
- 5 Tap **Bitmap Max** and input % value using the on-screen keyboard.
The Bitmap Max represents the maximum range of bitmap colors to be used. if you set it to 90%, the color that exceeds 90% does not show.
- 6 Tap **Hit Min** and input % value using the on-screen keyboard.
The Hit Min represents the minimum number of hits not to be converted to colors. If you set it to 10%, the hit matched with 10% or below is not converted to a color.
- 7 Tap **Hit Max** and input % value using the on-screen keyboard. The Hit Max represents the maximum number of hits to be converted to colors. If you set it to 90%, the hit matched with 90% or above shows with max colors.



NOTE

You can go to **Menu > Limit** to analyze your measurements with the reference line, multi-segment line, and channel limit table. See [“Setting limit” on page 18](#) for more information.

Conducting interference analysis

The following sections describe how to conduct interference analysis.


Persistent RSSI

The Received Signal Strength Indicator (RSSI) is a multi-signal tracking metric that is particularly useful for measuring power-level variations over time. The RSSI measure-

ment lets you assign power limit line for audible alarms and increase alarm counters every time a signal exceeds a defined limit line. For long-term analysis, the spectrogram and RSSI measurements can be automatically saved into an external USB memory.


Figure displays an example of a Persistent RSSI Measurement.

Figure 32 Persistent RSSI Measurement



After configuring spectrum measurement as described in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement.

To set measure setup

- 1 Tap the **Setup** () icon on the side bar.
- 2 Tap **Alarm** to set the alarm parameters.
- 3 Tap **Alarm at** and select the marker number from Marker 1 to Marker 6.
- 4 Tap **Reference Line** to set a threshold for the alarm and input a value using the on-screen keyboard.
- 5 Tap to switch **Alarm** to **On** or **Off** to turn the alarm feature on or off.
- 6 *Optional:* Tap **Volume** to adjust the volume from 1 to 10 using the on-screen keyboard.



NOTE

You must set the marker(s) for the alarm, as this feature uses the marker position to sound alarms. See [“Using marker” on page 20](#) for more information.


You can go to **Menu > Limit** to analyze your measurements with the display line, multi-segment line, and channel limit. See [“Setting limit” on page 18](#) for more information. Once you tap the vertical move bar and move it up and down, the reference line value changes.

Persistent interference finder

The Persistent Interference Finder is an automatic triangulation algorithm that uses GNSS coordinates to locate possible interference sources based on three measurements. The persistent interference finder calculates possible interference locations using its inscribed circle or circumscribed circle, based on measured intersection points. You can plot up to seven measurement points and select three that are more representative for triangulation. The instrument automatically logs measurement positions not to lose them while changing measurement modes. You can switch the main screen from persistent spectrum view to map view and vice versa using the icon on the persistent spectrum view screen. Before starting the Persistent Interference Finder, you need to configure spectrum measurements. See [“Configuring spectrum measurements” on page 9](#) for more information. Note that the purpose of the measurement is to monitor the intermittent and transient interfering signals.

Figure 33 shows an example of the Persistent Interference Finder.

Figure 33 Persistent Interference Finder




To make full use of the feature available in the map mode, you will need a GNSS receiver and an antenna. For more details, see [“Antenna connection”](#) below.

Antenna connection

Before starting the instrument, you need to connect the Omni or Log periodic antenna to your instrument. In the Interference Finder Mode and the Radar Chart mode, you can perform interference hunting using the optional AntennaAdvisor Handle after attaching a broadband directional antenna to it. The handle is a device that has a built-in GNSS antenna and LNA.

Figure 34 shows an example of an antenna connection.

Figure 34 Antenna connection example



To connect an antenna

- 1 Mount a broadband antenna to your AntennaAdvisor Handle.
- 2 Connect the **RF Type-N Jack** of the handle to the **RF In** port of the instrument.
- 3 Connect the GNSS SMA jack of the handle to the GNSS port of the instrument. The GNSS status indicator appears on the instrument screen.
- 4 Connect the USB plug of the handle to the USB Host port of the instrument. The device icon appears in the system status bar on the screen.



NOTE

The AntennaAdvisor Handle is an optional item. It is recommended that you use a log periodic antenna with AntennaAdvisor handle to search more exact directional information. You can use a log periodic antenna or Omni antenna alone as well.

Loading a map

To use any features related to maps, you need to download and install the maps on the instrument. The **VIavi JDMaPCreator** will help you to download maps. Ensure the JDMaPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the **Send**






to **EQP** menu in JDMapCreator. For information about how to use the JDMapCreator, see the *JDMapCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map file in .mcf file type created in JDMap-Creator.
- 2 Tap the **Load** icon on the side bar,
- 3 Navigate to the map you want to open. The **File Information** pane displays the file properties, including name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.

Once you have loaded the map, you can also control the map using the following icons on the map.

Table 17 Map control icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, the purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in the map.
	Tap to zoom out the map.
	Tap and select the area where you want to expand.

Initializing AntennaAdvisor

Once you have connected the AntennaAdvisor Handle to your instrument, antenna initialization is required to get the right azimuth data. You need to initialize the antenna handle to calibrate the built-in compass by completing the following steps. Note that you can adjust Bandwidth based on the center frequency of the interfering signal that you have identified in the Spectrum view by tapping the Measure Setup > Bandwidth. A message appears at the bottom of the screen to alert you if you have not performed initialization of your connected the antenna handle set.

To initialize AntennaAdvisor

- 1 Hold your antenna handle horizontally in its upright position.
- 2 Point the antenna to the north and tap **Measure Setup > Initialize AntennaAdvisor**.

Setting geographic location

A point is a particular location that contains information about that location. This information includes, for example, GNSS coordinates, the time of the measurement or level that has been measured. You can evaluate the Point information directly on-site or save the information for later evaluation.

With this functionality, you can mark locations where you have performed a measurement. Thus, you can analyze the geographical distribution of the received signal strength. This allows you to analyze, for example, the coverage conditions around a base station's coverage area.

In the map view, a point is displayed as a dot with a number. The straight line represents the direction you are facing.

To set the geographic location

- 1 Tap the **Point 1**, **Point 2** and **Point 3** on the map. Make sure to set three location points so that the straight lines started from the point can create three intersections.
- 2 Tap each point and use the **Degree** bar or button to change degrees.
Make sure you set three location points so that the straight lines started from the point and can create three intersections.
- 3 Tap the GNSS icon to automatically get the selected point's location information.
The instrument displays the latitude and longitude information of the signal received by the GNSS antenna. This function is only available when the GNSS antenna is connected.
- 4 Tap the Latitude and Longitude icon and enter the value using the on-screen keyboard to manually define a position.
The values should be input based on the Decimal Degrees.
- 5 Tap the Apply button.

Setting azimuth

There are three methods available for setting azimuth.

Method 1: AntennaAdvisor Handle

You can use the Antenna Advisor handle. Make sure you initialize AntennaAdvisor first to get more accurate directional information.

- 1 Press and hold the TRIGGER button on the handle and pan the antenna handle to scan through until you find the strongest RSSI value.
RSSI, polarization, elevation, and azimuth readings are continuously updated on the screen while pressing the physical button.
- 2 Release the TRIGGER button to stop scanning.

Method 2: Degree bar

The **Degree Bar** functions as a compass. You can use it to set azimuth by moving it right and left.

- 1 Tap the circle on the Degree bar and move it gently until you get the right azimuth.

Method 3: Log-periodic antenna

You can use the log-periodic antenna.

Pan your log-periodic antenna to find a signal with the highest RSSI value and measure an azimuth of the interfering signal.



NOTE

The AntennaAdvisor has a built-in low-noise amplifier (LNA) that can be turned on and off using the physical On/Off button located on the rear side of the handle unit. For example, if the received signal is weak, you can turn on the switch to improve S/N.

To save the defined position

- 1 Tap any point on the map where you want to save the position information.
- 2 Tap the **Save Position** icon.
The instrument stores the saved location points in the internal memory, allowing you to load them by using the **Load Position** icon. You can save and load up to 10 positions.

To set measure setup for POI

The Interference ID automatically classifies interfering signals over a designated spectrum and displays the list of possible signal types corresponding to the selected signal.

- 1 Tap the **Setup** () icon on the side bar.

- 2 Tap **POI**. You can also access this menu using the Quick Access and Display Tab on top.

- a Tap to switch the Mode between High and Normal. The following table shows RBW and Span setup range per Normal and High mode.

Table 18 RBW and Span setup ranges

Mode		A	B	C	D
Normal	POI	100 to 34 μ s	392 to 136.5 μ s	800.5 to 270.5 μ s	3200 to 1076 μ s
	Bandwidth	100 to 20 MHz	19 to 5 MHz	4 and 3 MHz	2 and 1 MHz
	RBW	30 kHz to 10 MHz	10 kHz to 1 MHz	3 kHz to 1 MHz	1 kHz to 300 kHz

Mode		A	B	C	D	E	F
High	POI	18.5 to 2 μ s	29.5 to 4 μ s	73.5 to 7.5 μ s	147 to 15 μ s	284 to 28 μ s	587 to 56.5 μ s
	Effective Bandwidth	122.88 MHz	61.4 MHz	30.72 MHz	15.36 MHz	7.68 MHz	3.84 MHz
	Display Bandwidth	100 MHz	50 MHz	25 MHz	14 MHz	7 MHz	3 MHz
	RBW	100 kHz to 30 MHz	100 kHz to 10 MHz	30 kHz to 10 MHz	10 kHz to 3 MHz	10 kHz to 3 MHz	3 kHz to 1 MHz

- b Tap **Speed** and input a value using the on-screen keyboard.

Setting display mode

When the triangulation is done with three location points and azimuth for each point, you can view a circumscribed circle by default. You can change the display mode to inscribed circle or double circles to view a narrower area. The center of the green-shaded circle is determined to be where the source of the interfering signal resides.

To set display mode

- 1 Tap **Measure Setup > Display**.
- 2 Select the option from the following choices:
 - **Circum**: displays a circumscribed circle that meets three vertices of the triangle.
 - **Inscribed**: displays an inscribed circle that meets the three vertices of the triangle.
 - **Double**: displays both circumscribed and inscribed circles.
- 3 Tap **Measure Setup > Screen Mode**.

- 4 Tap the **Screen Mode** to select **Map** or **Full**.
 - **Map**: displays what is inside the base map with the map image.
 - **Full**: displays three location points and defined circle without the map image.

Persistent radar chart

If you have identified an interfering signal on your spectrum view, you can move to the Radar Chart mode and measure RSSI power levels through 360° at a location received by the connected broadband directional antenna so that you can determine the direction of the source of the interference. Using a set of the AntennaAdvisor Handle that holds a broadband directional antenna is mandatory in the Radar Chart mode and its built-in compass, GNSS Antenna, and built-in low noise amplifier (LNA) help to determine the direction of the interference.

You can switch the Main screen from Spectrum view to Map view and vice versa using the icon on the spectrum view screen. Before starting the Interference Finder, you need to set Spectrum measurements. See [“Configuring spectrum measurements” on page 9](#) for more information.

For antenna connection, see [“Antenna connection” on page 68](#).

Loading a map






To use any features related to maps, you need to download and install the maps on the instrument. The **VIavi JMapCreator** will help you to download maps. Ensure the JMapCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the **Send to EQP** menu in JMapCreator. For information about how to use the JMapCreator, see the *JMapCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map file in .mcf file type created in JMapCreator.
- 2 Tap the **Load** icon on the side bar,
- 3 Navigate to the map you want to open. The **File Information** pane displays the file properties, including name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.

Once you have loaded the map, you can also control the map using the following icons on the map.

Table 19 Map control icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, the purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in the map.
	Tap to zoom out the map.
	Tap and select the area where you want to expand.

Initializing AntennaAdvisor

Once you have connected the AntennaAdvisor Handle to your instrument, antenna initialization is required to get the right azimuth data. You need to initialize the antenna handle to calibrate the built-in compass by completing the following steps. Note that you can adjust Bandwidth based on the center frequency of the interfering signal that you have identified in the Spectrum view by tapping the Setup > Bandwidth. A message appears at the bottom of the screen to alert you if you have not performed initialization of your connected the antenna handle set.

To initialize AntennaAdvisor

- 1 Hold your antenna handle horizontally in its upright position.
To avoid unnecessary impact of external magnetic field, position yourself at the location where the value of magnetic field strength displayed on the instrument is green.
- 2 Point the antenna to the north and tap **Measure Setup > Initialize AntennaAdvisor**.

The message disappears and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization is done successfully.



NOTE

It is recommended that you re-initialize the AntennaAdvisor Handle after measurements to re-calibrate the compass when you notice that the red line on the radar chart is not aligned with the north on the map even though you are pointing the antenna to the north.

Obtaining persistent RSSI data

Once you have connected your antenna handle set and done necessary setups, you can monitor the power level of the received signal, the amount of polarization, and elevation level real time. Using the Trigger button on the antenna handle set, you can plot the RSSI level through 360 degrees at your location.

To obtain Persistent RSSI data

- 1 When you have the green GNSS indicator, tap the **GNSS** icon on the side panel to set your current location to the center of the radar chart. The latitude and longitude information at the side of the display changes from “Unknown Position” to the obtained position information.
- 2 Tap the **Save Position** icon on the side panel to save a position to recall for triangulation in the Interference Finder mode and select one that you want to save.
- 3 Monitor the RSSI reading of the received signal. If the signal is weak, turn on the LNA switch on the antenna handle set to improve S/N.
- 4 The message disappears and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization is done successfully.



NOTE

The AntennaAdvisor Handle has a built-in low-noise amplifier (LNA) and you can turn it on and off by toggling the physical On/Off switch located on the rear side of the handle unit

- 5 Hold the antenna handle set horizontally and make the measurement.
- 6 The message disappears and the red line for the current antenna direction moves to the 0° line and overlaps to let you know that the initialization is done successfully.
- 7 To obtain a **Persistent RSSI** value:
 - a Press the **Trigger button** located on the antenna handle.

Each time you press the physical button on the handle, a beep sounds and a power level of the received signal is plotted as a blue dot on the radar chart. Depending on the strength of the measured value, you may hear different tones of beeping.

- b While panning the antenna horizontally to vary the angle of the direction, repeat pressing the **TRIGGER** button to obtain at least five points if you want to do the localization.
- 8 To continuously obtain **Persistent RSSI** values:
- a Press and hold the **TRIGGER** button located on the antenna handle to start a continuous measurement.
 - b Pan the antenna handle horizontally through the angle of 360 degrees you desire. A beep is sounded repeatedly to let you know that the measurement is continuing and measured values are plotted on the radar chart.
 - c Release the **TRIGGER** button to stop the continuous measurement.
- 9 Tap Setup > Screen Mode Full/Map to change the display mode.



NOTE


The maximum number you can plot on the radar chart is 2500 points both in the single and continuous measurements. If your measurement reaches 500 points, you need to reset the measurement by pressing the Localization soft key twice or performing the initialization of the AntennaAdvisor Handle. Concentric circles indicate different levels of RSSI. You can use the AMP/SCALE hard to adjust the amplitude scale of the chart.

- a **Map:** Displays measured points inside the base map image. If you are in the area outside the base map and continue your measurement with the Trigger button, the instrument continues obtaining data even though the radar chart disappears from the screen. You can view obtained data when you change this display option to Full.
- b **Full:** Displays measured points without the base map image. In case that you made measurements in the area outside the map image, selecting this option moves your measured data to the center of the display so that you can view the result.

Localizing RSSI data

The Localization feature lets you view averaged and smoothed measurement data with a bold green line on the radar chart that helps you determine the direction of the highest RSSI value. When you have five or more data points plotted on the radar chart, you can perform this localization.

To localize RSSI data

- 1 Tap the Setup () icon on the side bar.
- 2 Tap **Localization**. All the measured points turn to green color and you can view the bold green line that indicates the possible direction of the interference source.

3 Tap **Localization** again to clear all the data plots on the radar chart.

Figure shows an example of the persistent radar chart. Figure shows an example of the localized persistent radar chart.

Figure 35 Persistent Radar Chart



Figure 36 Persistent Radar Chart — localized



To set measure setup for POI

The interference ID automatically classifies interfering signals over a designated spectrum and displays the list of possible signal types corresponding to the selected signal.

1 Tap the **Setup** () icon on the side bar.

- 2 Tap **POI**. You can also access this menu using the Quick Access and Display Tab on top.
 - a Tap to switch the Mode between High and Normal. The following table shows RBW and Span setup range per Normal and High mode.

Table 20 RBW and Span setup ranges

Mode		A	B	C	D	
Normal	POI	100 to 34 μ s	392 to 136.5 μ s	800.5 to 270.5 μ s	3200 to 1076 μ s	
	Bandwidth	100 to 20 MHz	19 to 5 MHz	4 and 3 MHz	2 and 1 MHz	
	RBW	30 kHz to 10 MHz	10 kHz to 1 MHz	3 kHz to 1 MHz	1 kHz to 300 kHz	

Mode		A	B	C	D	E	F
High	POI	18.5 to 2 μ s	29.5 to 4 μ s	73.5 to 7.5 μ s	147 to 15 μ s	284 to 28 μ s	587 to 56.5 μ s
	Effective Bandwidth	122.88 MHz	61.4 MHz	30.72 MHz	15.36 MHz	7.68 MHz	3.84 MHz
	Display Bandwidth	100 MHz	50 MHz	25 MHz	14 MHz	7 MHz	3 MHz
	RBW	100 kHz to 30 MHz	100 kHz to 10 MHz	30 kHz to 10 MHz	10 kHz to 3 MHz	10 kHz to 3 MHz	3 kHz to 1 MHz

- b Tap **Speed** and input a value using the on-screen keyboard.

Utility

The following section describes the utility functions of the device.

Real-time spectrum replayer

The Real-time Spectrum Replayer allows you to retrieve and replay recorded real-time spectrum analyzer traces in interference analysis mode. These traces can be played back in the persistent spectrum, persistent spectrogram, or persistent RSSI. You can configure the limit line to create failure points when signals exceed it. The failure points are clearly displayed on the trace timeline for quick access during playback.

To replay a spectrum

- 1 Tap the **Setup** () icon on the side bar.

- 2 Tap **Spectrum Replayer**. The **File Manager** window appears.
- 3 Select a file to be loaded and then tap **Load**. The replay bar appears on the bottom of the screen, as shown in [Figure 37](#).

Figure 37 Replay bar



- 4 Tap **Play** to start playing.
- 5 Tap **FWD** or **REV** to change play direction to forward or reverse.
- 6 Tap the left or right arrow of **Speed** to select the speed option: **X1**, **X2**, **X3**, or **X4**.
- 7 Tap **Pause** to pause or stop playing data.
- 8 To move to a particular failure position directly and play from there, tap **Index Fail** and enter a value by using the on-screen keyboard.
- 9 *Optional:* Tap **Setup > Time Cursor On/Off** to display or dismiss the time cursor on the screen. This key becomes activated when you play logged data in the Spectrogram mode.



NOTE

If you connect a USB drive, do not remove it while playing to prevent freezing the USB port, which will require you to restart the instrument to get a USB drive recognized again.

Using LTE/LTE-A FDD Analyzer

This chapter describes how to use the LTE/LTE-A FDD Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 82](#)
- [“Selecting mode and measure” on page 82](#)
- [“Conducting spectrum measurement” on page 82](#)
- [“Conducting OTA measurement” on page 85](#)

Introduction

The LTE/LTE-A FDD Analyzer is the optimal portable test solution for installation and maintenance of cellular base stations and cell sites, running with external AC power or battery for the field. Its touch-based user interface has been specifically designed with customized menus and simple calibration procedures, providing service providers with accurate and reliable LTE/LTE-A FDD measurement results.

The LTE/LTE-A FDD Analyzer performs the following measurements:

- Spectrum Analysis
 - Spectrum
- RF Analysis
 - Channel Power
- OTA Analysis
 - OTA Channel Scanner
 - OTA ID Scanner
 - OTA Route Map
 - Freq/Time/Power Variation

Selecting mode and measure

The following procedure describes how to start measurement.

To start measurement

- 1 Tap **LTE/LTE-A FDD Analyzer** on the **MODE** panel.
- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Spectrum**
 - **RF Analysis > Channel Power**
 - **OTA Analysis > OTA Channel Scanner, OTA ID Scanner, OTA Route Map, or Freq/Time/Power Variation**

Conducting spectrum measurement



The following sections describe how to conduct spectrum analysis.

Spectrum

After setting test parameters as described in [“Configuring spectrum measurements” on page 9](#), your measurement is displayed on the screen as like the following example.

You can simply change Center Frequency by tapping the icons right below the result chart screen.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 3 Tap the **Center Frequency** () icon under the chart screen to set the center frequency using the on-screen keyboard.

To set trigger

- 1 Tap the **Menu > Trigger**.
- 2 Tap **Trigger** and select the options from **Internal**, **External**, or **GPS**.
- 3 Tap **Freq. Ref.**(Frequency Reference) to set the clock source.
 - **Internal**: Uses a 10 MHz internal clock
 - **External**: Uses external 10 MHz, 13 MHz, or 15 MHz clock automatically set by the instrument
 - **GPS**: Uses a built-in GPS as a frequency and timing source




NOTE

Make sure to set Frequency Reference for all measurement mode in LTE-LTE-A FDD Analyzer to sync the proper clock source.

Figure 38 shows an example of LTE/LTE-A FDD spectrum measurement.

Figure 38 LTE/LTE-A FDD spectrum measurement



Conducting RF measurement

The following sections describe how to conduct RF analysis.

Channel power





The Channel Power measurement is a common test used in the wireless industry to measure the total transmitted power of a radio within a defined frequency channel. It acquires a number of points representing the input signal in the time domain, transforms this information into the frequency domain using Fast Fourier Transform (FFT), and then calculates the channel power. The effective resolution bandwidth of the frequency domain trace is proportional to the number of points acquired for the FFT.

The channel power measurement identifies the total RF power and power spectral density (PSD) of the signal in the LTE channel bandwidth.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.

You can also tap the rectangle with value, () under the chart screen and input the value using the on-screen keyboard.
- 3 Tap the **Center Frequency** () icon under the chart screen to set the center frequency using the on-screen keyboard.
- 4 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the on-screen keyboard. The input value range is from 1 to 100.

To set limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication.
The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 Tap **Low Limit** to set the lower threshold using the on-screen keyboard.
- 5 *Optional:* Tap the **Save** hot key on the side bar and select the save option from the choices available for your measurement mode.

[Figure 39](#) shows an example of LTE/LTE-A FDD channel power measurement.

Figure 39 LTE/LTE-A FDD channel power measurement



NOTE

Channel Power measurement result shows channel power and spectrum density in a user specified channel bandwidth. The peak to average ratio (PAR) is shown at the bottom of the screen as well. The shaded area on the display indicates the channel bandwidth.

Conducting OTA measurement

The following sections describe how to conduct OTA analysis.


OTA channel scanner

The OTA Channel Scanner is a radio receiver that can automatically tune or scan two or more discrete frequencies and multi-channels, indicating when it finds a signal on one of them and then continuing scanning when that frequency goes silent.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.


To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap the **MIMO** and select **2x2** or **4x4** to select the number of antenna ports.
- 3 Tap **Amp/Scale** under **Menu** to set **Reference Level**, **Attenuation** or **External Offset** as required.
- 4 Tap **Sweep Mode** to select **Single** or **Continue**.

- 5 Tap **Trigger** to set **Internal**, **External** or **GPS** as required.
- 6 Tap **Limit** to set **Limit Line On** or **Off** and enter Limit Line value as required.
- 7 Tap the **Configuration** icon in the Detected List table.
 - a Select **Index** from 1 to 6 and the selected Index will be highlighted in purple on the table.
 - b Select **Center Frequency** to set the center frequency using the on-screen keyboard.
 - c Select **Channel Standard** to set the channel standard for the selected index using the on-screen keyboard.
 - d Select **Channel Number** to set the channel number for the selected index using the on-screen keyboard.
 - e Select **Bandwidth** from the following options: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.
 - f Tap the **Add** button to add Index or **Delete** button to delete the selected Index.

Figure 40 shows an example of OTA LTE/LTE-A FDD channel scanner measurement.

Figure 40 LTE/LTE-A FDD OTA channel scanner measurement



OTA ID Scanner

The LTE mobile receives signals from multiple base stations that all of these signals share the same spectrum and are present at the same time. Each base station has unique scrambling code assigned to the particular base station and it differentiates its signal from other base stations in the area.

The ID Scanner shows key parameters such as RSRP (Reference Signal Received Power) and RSRQ (Reference Signal Received Quality) that predict the downlink coverage quickly. RSRPs from entire cells help to rank between the different cells as

input for handover and cell reselection decisions. RSRQ provides additional information when RSRP is not sufficient to make a reliable handover or cell reselection decision.

Setting measure setup

After configuring the spectrum measurement in “[Configuring spectrum measurements](#)” on page 9, you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup


- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 3 Tap the **MIMO** and select **2x2** or **4x4Hz** to select the number of antenna ports.
- 4 To select the Cyclic Prefix, tap **Cyclic Prefix** and select **Normal** or **Extended**.
- 5 Tap to switch **Physical Cell ID** to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically
 - **Manual** sets a specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 6 If you set the Physical Cell ID to Manual, tap **Physical Cell ID** and input the value using the on-screen keyboard.
- 7 *Optional:* Tap the **Save** hot key on the side bar and select the save option from the choices available for your measurement mode.

Figure 41 shows an example of OTA LTE/LTE-A FDD ID scanner measurement.

Figure 41 LTE/LTE-A FDD OTA ID scanner measurement



OTA route map

LTE route map traces the power level of the strongest LTE signal in terms of RSRP corresponding a particular time and geographical position and presents it in a geographical map as a measurement point. All the collected measurements can be exported for post-processing purposes, including data of the strongest LTE signal for each measurement point, including its measurement time and geographical location.

Figure 42 shows an example of LTE/LTE-A FDD OTA route map measurement.

Figure 42 OTA route map with LTE/LTE-A FDD analyzer



Loading a map

To use any features related to maps, you need to download and install the maps on the instrument. The VIAVI JDMaPCreator will help you download maps. Make sure the JDMaPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JDMaPCreator. For more information on how to use the JDMaPCreator, see the *JDMaPCreator 2.0 User Guide*.

To load a map






- 1 Plug in your USB flash drive that has a map with a file type of .mcf created in JDMaPCreator.
- 2 Tap the **Load** (📁) icon on the side bar.
- 3 Navigate to the map file that you want to open.

The **File Information** pane displays the file properties, including its name, size, type, and date modified.

- 4 Tap the **Load** button on the screen.

- 5 Once you have loaded the map, you can also control the map using the following icons on the map.


Table 21 Map icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, a purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in on the map.
	Tap to zoom out on the map.
	Tap and select the area that you want to expand.

The left-most cell-site icon is activated when you import the cell-site information file.

To set measure setup

Before starting the Route Map measurement, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more information.

- 1 If required, connect a GNSS receiver to your instrument for outdoor mapping. Indoor mapping does not necessarily need a GNSS antenna.
- 2 Tap the Setup () icon on the side bar.
- 3 Tap to switch the **Plot Point** to **GNSS**, **Position**, or **Time**.
 - a To collect data/plot points automatically as you move around in a vehicle or outside, select **GNSS**, then tap to switch the **Screen Mode** between **Map** and **Full**. With the **Map** setting, you can view only the collected points that can be seen within the boundary of the loaded map. With the **Full** setting, you can view all the collected points of the route without the loaded map.
 - b To collect data/plot points manually in an indoor layout without a GNSS antenna, select **Position**.
 - c To collect data/plot points based on time, select **Time**.
- 4 Tap to switch **Plot Item** to **RSRP**, **RSRQ**, **S-SS SINR**, **S-SS RSSI**, **P-SS RSRP**, **S-SS RSRP**, **S-SS Ec/Io** or **P-SS SNR**.

- 5 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 6 Tap to switch **Physical Cell ID** to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically
 - **Manual** sets a specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 7 If you set the Physical Cell ID to Manual, tap **Physical Cell ID** and input the value using the on-screen keyboard.



NOTE

The instrument does not automatically save the collected data. It is recommended that you save the result. If not, you will lose all the collected data.

To set limit

You can set the thresholds for the two different color indicators, red and blue. The maximum value is the Limit for **Excellent**, and the minimum value is the Limit for **Poor**. See below to check the plot point color based on the Legend Color Table.

- 1 Tap the rectangle with value before color legend bar on the right panel.
- 2 Set a value for **Poor** (minimum value) using the on-screen keyboard.
- 3 Tap the rectangle with value after color legend bar on the right panel.
- 4 Set a value for **Excellent** (maximum value) using the on-screen keyboard.

Figure 43 shows a legend color table.



Figure 43 Legend color table

Red	Green	Blue	Color	
0	0	255		→ Poor
0	32	255		
0	64	255		
0	128	255		
0	255	255		
0	255	170		
0	255	85		
0	255	0		
85	255	0		
170	255	0		
255	255	0		
255	128	0		
255	64	0		
255	32	0		
255	0	0		→ Excellent

Logging data


To use any features related to maps, you need to download and install the maps on the instrument. The VIAVI JMapCreator will help you download maps. Make sure the JMapCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JMapCreator. For more information on how to use the JMapCreator, see the *JMapCreator 2.0 User Guide*.

To log data

- 1 Follow **step 1 to 3** in Setting measure setup.
- 2 Tap the **Testing** button on the right panel of the map to start plotting on the map. When you select a point on the map, a marker appears and the Information window appears on the right panel.
- 3 Tap the **Stop** () button to stop plotting.
- 4 Tap the **Pause** button() to pause plotting, then the GPS point cannot be plotted.
- 5 If you start test and select **Menu > Map > Plot Point > Position**, you can undo by tapping the **Testing** button.
- 6 If you select the **Stop** button, the Plot Stop pop-up window appears, then tap **Yes**.
- 7 Tap **Yes** when the Save pop-up window appears and the logging file to your USB.

Viewing the logging data

To view the logging data

- 1 Load the saved logging file using the **Load** () icon on the side bar. Make sure the file extension is .gomv.
- 2 Tap to switch Plot Item to **RSRP**, **RSRQ**, **RS-SINR**, **S-SS RSSI**, **P-SS Power**, **S-SS Power**, **S-SS Ec/Io** or **SNR**.
- 3 Tap the **Apply** button.
The point color of the map changes to the corresponding value, and if there is no detected LTE signal, the point will become gray color.

Importing cellsite DB

You can import the site DB by creating the 5G site information form.

To import cellsite DB

- 1 Create the 5G site information with an excel file as below.
- 2 Input the two mandatory fields: **Lat (DecDeg)** and **Long (DecDeg)**.
- 3 Input the **Azimuth** field if you want to check the direction of antenna.

- 4 Make sure to save the file as (Comma delimited) (*.csv).
- 5 Copy the file to the USB memory stick and insert it to the **USB A** or **USB B** port of the instrument.
- 6 Tap the **Load** (📁) icon on the side bar.
- 7 Import the saved file.


Once the file is loaded, the following cellsite information appears with an icon.

Figure 44 shows an example of an importing cellsite DB.

Figure 44 Importing Cellsite DB

	Mandatory field to be input		Not mandatory field to be input		Antenna direction to be shown if input
	A	B	C	D	E
Mandatory row and title	1 Site Information Form	Version	1		
	2 ID	Lat(DecDe	Long(DecD	Height	Azimuth
	3 HASRU130	29.73186	-95.3687	20	160
	4 HASRU131	29.73186	-95.3687	20	160
Site ID & example	5 HASRU140	29.73186	-95.3687	20	220
	6 HASRU141	29.73186	-95.3687	20	220
	7 HASRU150	29.72883	-95.3664	13	190
	8 HASRU151	29.72563	-95.3643	12.25	0

Figure 45 Route map measurement with site information screen



NOTE


The purple icon on the map indicates the base station (site) location and the direction of antenna. If the site is beyond the latitude and longitude of the map file, it will show.

Freq/Time/Power variation

Frequency, time, and power variation shows the frequency, time, and power error trend based on the time elapsed.

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 3 *Optional.* Tap **Physical Cell ID** and select the type **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically.
 - **Manual** sets the specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 4 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 5 *Optional.* Tap **CFI** and select the type **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually. The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 6 *Optional.* Tap **PHICH Ng** to set the number of PHICH groups (Ng): **1/6**, **1/2**, **1**, **2**, **E-1/6**, **E-1/2**, **E-1**, or **E-2**.
- 7 Tap **EVM Detection Mode** and select **Single** or **Combine**.
 - **Single**: Testing on one single antenna connected to your instrument with a cable
 - **Combine**: Testing on multiple antennas connected to your instrument with a 2x1 or 4x1 combiner or an antenna

- 8 Tap **Menu > Miscellaneous** and do the following as needed.
- To select the number of antenna ports, tap **MIMO** and select **2x2** or **4x4**. The instrument sets this option to 2x2 by default. A 2x1 or 4x1 RF combiner is also required to be able to test on MIMO channels.
 - To turn the Multimedia Broadcast Multicast Service (MBMS) feature on or off, tap to switch **MBMS** and select **On** or **Off**.
 - To set the Multicast Broadcast Single Frequency Network (MBSFN) detection automatically or manually for MBMS testing, tap **MBSFN** and select **Auto** or **Manual**. An automatically detected or manually entered MBSFN Number appears on the Top Info.
 - To select the cyclic prefix, tap **Cyclic Prefix** and select **Normal** or **Extended**.
 - Tap the **PDSCH Modulation Type**, and then select the modulation type option: **Auto**, **QPSK**, **16 QAM**, **64 QAM**, **256 QAM**, **E-TM3.3**, **E-TM3.2**, **E-TM3.1a**, **E-TM3.1**, **E-TM2a**, **E-TM2**, and **E-TM1.2**.
 - Tap **PDSCH Threshold** and input the value using the on-screen keyboard.
 - Tap **PDCCH Threshold** and input the value using the on-screen keyboard.
 - Tap **PDCCH Mode** and select **REG** to calculate EVM based on Resource Element Group or **Average** to calculate EVM after adding up all the PDCCH signals from one subframe.
 - Tap to switch **PDSCH Precoding** between **On** and **Off** to enable or disable the PDSCH precoding.
- 9 Tap **Menu > Antenna**.
- To assign an antenna port number automatically or manually, tap **Antenna Port** and select the option: **Auto**, **Antenna 0**, or **Antenna 1**.




NOTE

If you want to set the reference level and scale, tap **Menu > Amp/Scale > Reference**. You can set Reference Freq Error Offset, Scale Division (Freq Error), Reference Time Error Offset, Scale Division (Time Error), Reference Level, and Scale Division (Power) on demand using the on-screen keyboard. You can also select the unit on the keyboard.

Figure 46 shows an example of LTE/LTE-A FDD freq/time/power variation by offset.

Figure 46 LTE/LTE-A FDD freq/time/power variation by offset




NOTE

You can tap the Distance box and input the value that you want to compensate for distance. When distance is entered, the time will show the value with distance correction. Make sure the default value for Distance is 0.

Figure 47 shows an example of LTE/LTE-A FDD freq/time/power variation by power.

Figure 47 LTE/LTE-A FDD freq/time/power variation by power



Using LTE/LTE-A TDD Analyzer

This chapter describes how to use the LTE/LTE-A TDD Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 98](#)
- [“Selecting mode and measure” on page 98](#)
- [“Conducting spectrum measurement” on page 98](#)
- [“Conducting OTA measurement” on page 102](#)

Introduction

The LTE/LTE-A TDD Analyzer is the optimal portable test solution for installation and maintenance of cellular base stations and cell sites, running with external AC power or battery for the field. Its touch-based user interface has been specifically designed with customized menus and simple calibration procedures, providing service providers with accurate and reliable LTE/LTE-A TDD measurement results.

The LTE/LTE-A TDD Analyzer is the optimal solution to perform following measurements:

- Spectrum Analysis
 - Spectrum
- RF Analysis
 - Channel Power
- OTA Analysis
 - OTA Channel Scanner
 - OTA ID Scanner
 - OTA Route Map
 - Freq/Time/Power Variation

Selecting mode and measure

The following procedure describes how to start measurement.

To start measurement

- 1 Tap **LTE/LTE-A TDD Analyzer** on the **MODE** panel.
- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Spectrum**
 - **RF Analysis > Channel Power**
 - **OTA Analysis > OTA Channel Scanner, OTA ID Scanner, OTA Route Map, or Freq/Time/Power Variation**

Conducting spectrum measurement



The following sections describe how to conduct spectrum analysis.

Spectrum

After setting test parameters as described in [“Configuring spectrum measurements” on page 9](#), your measurement is displayed on the screen as like the following example.

You can simply change Center Frequency by tapping the icons right below the result chart screen.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 3 Tap the **Center Frequency** () icon under the chart screen to set the center frequency using the on-screen keyboard.
- 4 Tap **Subframe Number** and input the value from 0 to 9 using the on-screen keyboard.
- 5 Tap to switch **Physical Cell ID** to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically
 - **Manual** sets a specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 6 If you set the Physical Cell ID to Manual, tap **Physical Cell ID** and input the value using the on-screen keyboard.
- 7 *Optional:* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

To set trigger

- 1 Tap the **Menu > Trigger**.
- 2 Tap **Trigger** and select the options from **Internal**, **External**, or **GPS**.
- 3 Tap **Freq. Ref.**(Frequency Reference) to set the clock source.
 - **Internal:** Uses a 10 MHz internal clock
 - **External:** Uses external 10 MHz, 13 MHz, or 15 MHz clock automatically set by the instrument
 - **GPS:** Uses a built-in GPS as a frequency and timing source




NOTE

Make sure to set Frequency Reference for all measurement mode in LTE-LTE-A TDD Analyzer to sync the proper clock source.

Figure 48 shows an example of an LTE/LTE-A TDD spectrum measurement.

Figure 48 LTE/LTE-A TDD spectrum measurement



Conducting RF measurement

The following sections describe how to conduct RF analysis.

Channel power


The Channel Power measurement is a common test used in the wireless industry to measure the total transmitted power of a radio within a defined frequency channel. It acquires a number of points representing the input signal in the time domain, transforms this information into the frequency domain using Fast Fourier Transform (FFT), and then calculates the channel power. The effective resolution bandwidth of the frequency domain trace is proportional to the number of points acquired for the FFT.


The channel power measurement identifies the total RF power and power spectral density (PSD) of the signal in the LTE channel bandwidth.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.

You can also tap the rectangle with value, () under the chart screen and input the value using the on-screen keyboard.

- 3 Tap the **Center Frequency** (**Center 1.000 000 000 GHz**) icon under the chart screen to set the center frequency using the on-screen keyboard.
- 4 Tap **Subframe Number** and input the value from 0 to 9 using the on-screen keyboard.
- 5 Tap to switch **Physical Cell ID** to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically
 - **Manual** sets a specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 6 If you set the Physical Cell ID to Manual, tap **Physical Cell ID** and input the value using the on-screen keyboard.
- 7 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the on-screen keyboard. The input value range is from 1 to 100.

To set the Setting limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication.
The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 Tap **Low Limit** to set the lower threshold using the on-screen keyboard.
- 5 *Optional:* Tap the **Save** hot key on the side bar and select the save option from the choices available for your measurement mode.

Figure 49 shows an example of LTE/LTE-A TDD channel power measurement.

Figure 49 LTE/LTE-A TDD channel power measurement



Conducting OTA measurement

The following sections describe how to conduct OTA analysis.


OTA channel scanner

The OTA Channel Scanner is a radio receiver that can automatically tune or scan two or more discrete frequencies and multi-channels, indicating when it finds a signal on one of them and then continuing scanning when that frequency goes silent.

Setting measure setup


After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap the **MIMO** and select **2x2** or **4x4** to select the number of antenna ports.
- 3 Tap **Amp/Scale** under **Menu** to set **Reference Level**, **Attenuation** or **External Offset** as required.
- 4 Tap **Sweep Mode** to select **Single** or **Continue**.
- 5 Tap **Trigger** to set **Internal**, **External** or **GPS** as required.
- 6 Tap **Limit** to set **Limit Line On** or **Off** and enter Limit Line value as required.
- 7 Tap the **Configuration** icon in the Detected List table.
 - a Select **Index** from **1** to **6** and the selected Index will be highlighted in purple on the table.
 - b Select **Center Frequency** to set the center frequency using the on-screen keyboard.
 - c Select **Channel Standard** to set the channel standard for the selected index using the on-screen keyboard.
 - d Select **Channel Number** to set the channel number for the selected index using the on-screen keyboard.
 - e Select **Bandwidth** from the following options: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.
 - f Tap the **Add** button to add Index or **Delete** button to delete the selected Index.

[Figure 50](#) shows an example of OTA LTE/LTE-A TDD channel scanner measurement.

Figure 50 LTE/LTE-A TDD OTA channel scanner measurement



OTA ID Scanner


The LTE mobile receives signals from multiple base stations that all of these signals share the same spectrum and are present at the same time. Each base station has unique scrambling code assigned to the particular base station and it differentiates its signal from other base stations in the area.

The ID Scanner shows key parameters such as RSRP (Reference Signal Received Power) and RSRQ (Reference Signal Received Quality) that predict the downlink coverage quickly. RSRPs from entire cells help to rank between the different cells as input for handover and cell reselection decisions. RSRQ provides additional information when RSRP is not sufficient to make a reliable handover or cell reselection decision.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 3 Tap the **MIMO** and select **2x2** or **4x4** to select the number of antenna ports.
- 4 To select the Cyclic Prefix, tap **Cyclic Prefix** and select **Normal** or **Extended**.

- 5 Tap to switch **Physical Cell ID** to **Manual** or **Auto**.
- **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically
 - **Manual** sets a specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 6 If you set the Physical Cell ID to Manual, tap **Physical Cell ID** and input the value using the on-screen keyboard.
- 7 *Optional:* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Figure 51 shows an example of OTA LTE/LTE-A TDD ID scanner measurement.

Figure 51 LTE/LTE-A TDD OTA ID scanner measurement




OTA route map

LTE route map traces the power level of the strongest LTE signal in terms of RSRP corresponding a particular time and geographical position and presents it in a geographical map as a measurement point. All the collected measurements can be exported for post-processing purposes, including data of the strongest LTE signal for each measurement point, including its measurement time and geographical location.

Figure 52 shows an example of LTE/LTE-A TDD OTA route map measurement.

Figure 52 OTA route map with LTE/LTE-A TDD Analyzer



Loading a map

To use any features related to maps, you need to download and install the maps on the instrument. The VIAVI JDMaPCreator will help you download maps. Make sure the JDMaPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JDMaPCreator. For more information on how to use the JDMaPCreator, see the *JDMaPCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map with a file type of .mcf created in JDMaPCreator.
- 2 Tap the **Load** (📁) icon on the side bar.
- 3 Navigate to the map file that you want to open.
The **File Information** pane displays the file properties, including its name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.
- 5 Once you have loaded the map, you can also control the map using the following icons on the map.

Table 22 Map icons






Icon	Description
	Tap to go to your current location on the map. Once tapped, a purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.


Table 22 Map icons

Icon	Description
	Tap to zoom in on the map.
	Tap to zoom out on the map.
	Tap and select the area that you want to expand.

The left-most cell-site icon is activated when you import the cell-site information file.

To set measurement setup

Before starting the Route Map measurement, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more information.

- 1 If required, connect a GNSS receiver to your instrument for outdoor mapping. Indoor mapping does not necessarily need a GNSS antenna.
- 2 Tap the Setup () icon on the side bar.
- 3 Tap to switch the **Plot Point** to **GNSS**, **Position**, or **Time**.
 - a To collect data/plot points automatically as you move around in a vehicle or outside, select **GNSS**, then tap to switch the **Screen Mode** between **Map** and **Full**. With the **Map** setting, you can view only the collected points that can be seen within the boundary of the loaded map. With the **Full** setting, you can view all the collected points of the route without the loaded map.
 - b To collect data/plot points manually in an indoor layout without a GNSS antenna, select **Position**.
 - c To collect data/plot points based on time, select **Time**.
- 4 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 5 Tap to switch **Physical Cell ID** to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically
 - **Manual** sets a specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 6 If you set the Physical Cell ID to Manual, tap **Physical Cell ID** and input the value using the on-screen keyboard.

- 7 *Optional:* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.



NOTE

The instrument does not automatically save the collected data. It is recommended that you save the result. If not, you will lose all the collected data.

To set limit

You can set the thresholds for the two different color indicators, red and blue. The maximum value is the Limit for **Excellent**, and the minimum value is the Limit for **Poor**. See below to check the plot point color based on the Legend Color Table.

- 1 Tap the rectangle with value before color legend bar on the right panel.
- 2 Set a value for **Poor** (minimum value) using the on-screen keyboard.
- 3 Tap the rectangle with value after color legend bar on the right panel.
- 4 Set a value for **Excellent** (maximum value) using the on-screen keyboard.

Figure 53 shows a legend color table.



Figure 53 Legend color table

Red	Green	Blue	Color	
0	0	255		→ Poor
0	32	255		
0	64	255		
0	128	255		
0	255	255		
0	255	170		
0	255	85		
0	255	0		
85	255	0		
170	255	0		
255	255	0		
255	128	0		
255	64	0		
255	32	0		
255	0	0		→ Excellent

Logging data


To use any features related to maps, you need to download and install the maps on the instrument. The VIAVI JMapCreator will help you download maps. Make sure the JMapCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JMapCreator. For more information on how to use the JMapCreator, see the *JMapCreator 2.0 User Guide*.

To log data

- 1 Follow **step 1 to 3** in Setting measure setup.
- 2 Tap the **Testing** button on the right panel of the map to start plotting on the map. When you select a point on the map, a marker appears and the Information window appears on the right panel.
- 3 Tap the **Stop** () button to stop plotting.
- 4 Tap the **Pause** button () to pause plotting, then the GPS point cannot be plotted.
- 5 If you start test and select **Menu > Map > Plot Point > Position**, you can undo by tapping the **Testing** button.
- 6 If you select the **Stop** button, the Plot Stop pop-up window appears, then tap **Yes**.
- 7 Tap **Yes** when the Save pop-up window appears and the logging file to your USB.

Viewing the logging data

To view the logging data

- 1 Load the saved logging file using the **Load** () icon on the side bar. Make sure the file extension is.gomv.
- 2 Tap to switch Plot Item to **RSRP**, **RSRQ**, **S-SS-SINR**, **S-SS RSSI**, **P-SS RSRP**, **S-SS RSRP**, **S-SS Ec/Io** or **P-SS SNR**.
- 3 Tap the **Apply** button.
The point color of the map changes to the corresponding value, and if there is no detected LTE signal, the point will become gray color.

Importing cellsite DB

You can import the site DB by creating the 5G site information form.

To import cellsite DB



- 1 Create the 5G site information with an excel file as below.
- 2 Input the two mandatory fields: **Lat (DecDeg)** and **Long (DecDeg)**.
- 3 Input the **Azimuth** field if you want to check the direction of antenna.
- 4 Make sure to save the file as (Comma delimited) (*.csv).
- 5 Copy the file to the USB memory stick and insert it to the **USB A** or **USB B** port of the instrument.
- 6 Tap the **Load** () icon on the side bar.
- 7 Import the saved file.
Once the file is loaded, the following cellsite information appears with an icon.

Figure 54 shows an example of an importing cellsite DB.

Figure 54 Importing Cellsite DB

		Mandatory field to be input	Not mandatory field to be input	Antenna direction to be shown if input	
	A	B	C	D	E
Mandatory row and title	1	Site Information Form	Version	1	
	2	ID	Lat(DecDe Long(DecD	Height	Azimuth
Site ID & example	3	HASRU130	29.73186 -95.3687	20	160
	4	HASRU131	29.73186 -95.3687	20	160
	5	HASRU140	29.73186 -95.3687	20	220
	6	HASRU141	29.73186 -95.3687	20	220
	7	HASRU150	29.72883 -95.3664	13	190
	8	HASRU151	29.72563 -95.3643	12.25	0

Figure 55 Route map measurement with site information screen



Freq/Time/Power variation

Frequency, time, and power variation shows the frequency, time, and power error trend based on the time elapsed.

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.

- 2 Tap **Bandwidth** and select the value from the following choices: **1.4 MHz**, **3 MHz**, **5 MHz**, **10 MHz**, **15 MHz** or **20 MHz**.
- 3 Tap **Subframe Number** and input the value from 0 to 9 using the on-screen keyboard. For MBMS testing, this subframe number must be neither 0 nor 5 as these subframes 0 and 5 are not available for MBMS and it must be set to the MBMS transmitted channel's subframe number.
- 4 *Optional.* Tap **Physical Cell ID** and select the type **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the LTE signal automatically.
 - **Manual** sets the specific Physical Cell ID for the LTE signal manually in order to speed up the synchronization with a BTS.
- 5 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 6 *Optional.* Tap **CFI** and select the type **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually. The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 7 *Optional.* Tap **PHICH Ng** to set the number of PHICH groups (Ng): **1/6**, **1/2**, **1**, **2**, **E-1/6**, **E-1/2**, **E-1**, or **E-2**.
- 8 Tap **EVM Detection Mode** and select **Single** or **Combine**.
 - **Single**: Testing on one single antenna connected to your instrument with a cable
 - **Combine**: Testing on multiple antennas connected to your instrument with a 2x1 or 4x1 combiner or an antenna

- 9 Tap **Menu > Miscellaneous** and do the following as needed.
 - To select the number of antenna ports, tap **MIMO** and select **2x2** or **4x4**. The instrument sets this option to 2x2 by default. A 2x1 or 4x1 RF combiner is also required to able to test on MIMO channels.
 - To turn the Multimedia Broadcast Multicast Service (MBMS) feature on or off, tap to switch **MBMS** and select **On** or **Off**.
 - To set the Multicast Broadcast Single Frequency Network (MBSFN) detection automatically or manually for MBMS testing, tap **MBSFN** and select **Auto** or **Manual**. An automatically detected or manually entered MBSFN Number appears on the Top Info.
 - To select the cyclic prefix, tap **Cyclic Prefix** and select **Normal** or **Extended**.
 - Tap the **PDSCH Modulation Type**, and then select the modulation type option: **Auto**, **QPSK**, **16 QAM**, **64 QAM**, **256 QAM**, **E-TM3.3**, **E-TM3.2**, **E-TM3.1a**, **E-TM3.1**, **E-TM2a**, **E-TM2**, and **E-TM1.2**.
 - Tap **PDSCH Threshold** and input the value using the on-screen keyboard.
 - Tap **PDCCH Threshold** and input the value using the on-screen keyboard.
 - Tap **PDCCH Mode** and select **REG** to calculate EVM based on Resource Element Group or **Average** to calculate EVM after adding up all the PDCCH signals from one subframe.
 - Tap to switch **PDSCH Precoding** between **On** and **Off** to enable or disable the PDSCH precoding.
- 10 Tap **Menu > Antenna**.
 - To assign a antenna port number automatically or manually, tap **Antenna Port** and select the option: **Auto**, **Antenna 0**, **Antenna 1**, **Antenna 2**, and **Antenna 3**. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.




NOTE

If you want to set the reference level and scale, tap **Menu > Amp/Scale > Reference**. You can set Reference Freq Error Offset, Scale Division (Freq Error), Reference Time Error Offset, Scale Division (Time Error), Reference Level, and Scale Division (Power) on demand using the on-screen keyboard. You can also select the unit on the keyboard.

Figure 56 shows an example of LTE/LTE-A TDD freq/time/power variation by offset.

Figure 56 LTE/LTE-A TDD freq/time/power variation by offset




NOTE

You can tap the Distance box and input the value that you want to compensate for distance. When distance is entered, the time will show the value with distance correction. Make sure the default value for Distance is 0.

Figure 57 shows an example of LTE/LTE-A TDD freq/time/power variation by power.

Figure 57 LTE/LTE-A TDD freq/time/power variation by power



Using 5G NR Signal Analyzer

This chapter describes how to use the 5G NR Signal Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 114](#)
- [“Selecting mode and measure” on page 114](#)
- [“Conducting spectrum measurements” on page 114](#)
- [“Conducting RF measurements” on page 118](#)
- [“Conducting OTA measurement” on page 123](#)

Introduction

5G NR Signal Analyzer validates 3GPP 5G NR radio access. Its main 5G NR test functions are RF measurement, over-the-air measurement, and demodulation measurement. The RF measurement includes channel power, ACLR, SEM and occupied bandwidth based on triggered spectrum analysis. The over-the-air measurement includes beam analyzer, carrier scanner and route map. The demodulation measurement includes PDSCH EVM and constellation. The carrier scanner is measuring up to eight single component carriers' power as well as the strongest beam and its power level. The beam analyzer is assessing individual beam's ID, power level and signal to noise levels, and coverage verification including real-time coverage map as well as data available for post-processing.

The 5G NR Signal Analyzer provides following measurements for 5G NR analysis:

- Spectrum Analysis
 - Trigger Spectrum
- RF Analysis
 - Channel Power
- OTA Analysis
 - Beam Analyzer
 - Carrier Scanner
 - Route Map
 - Freq/Time/Power Variation

Selecting mode and measure

The following procedure describes how to start measurement.

To select mode and measure

- 1 Tap **5G NR Signal Analyzer** on the **MODE** panel.
- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Trigger Spectrum**
 - **RF Analysis > Channel Power**
 - **OTA Analysis > Beam Analyzer, Carrier Scanner, Route Map, or Freq/Time Error Variation**

Conducting spectrum measurements


The following sections describe how to conduct spectrum measurements.

Trigger spectrum

Setting measure setup

After configuring the spectrum measurement can configure the measurements just as in Spectrum mode. For more information, see [“Configuring spectrum measurements” on page 9](#). The measurement settings can be saved and recalled as a File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth/SSB SCS** and select the Setting in the pop-up window based on your need. SSB is abbreviation for Synchronization Signal Block or SS Block and it refers to Synchronization PBCH block since the synchronization signal and PBCH channel are packed as a single block that always moves together. SSB should be detected first in 5G NR frame. See [Table 23](#) below for the setting criteria based on the operating frequency.
- 3 Tap **Sync Raster Offset** to set the sync raster resolution to 180 kHz (FR1) or to 720 kHz (FR2) for carrier frequency center using the on-screen keyboard. See [Table 24](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 4 Tap **Sync SCS Offset** to fine-tune the offset using the SCS. See [Table 25](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 5 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 6 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64. Refer to the selection criteria based on the table in **Step 2**.

- 7 Tap **SSB Auto Search** and do the following steps:
 - a Tap **Search Type** and select from the following three options:
 - **Full-Raster**: You can search in sync raster offset unit (FR1: 180 kHz, FR2: 720 kHz).
 - **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth.
 - b Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to **Start** to search SCS, type, and the number of SSB automatically. Once **Start** is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to **Manual**.
- 8 Tap **SSB Periodicity** and select the options from **5 ms**, **10 ms**, **20 ms**, **40 ms**, **80 ms**, **160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.
- 9 Tap **Slot Formats** and input the value from 0 to 55 using the on-screen keyboard. The slot format means how to use one slot between downlink and uplink.
- 10 Tap to switch **Link** to **UL** or **DL**.
- 11 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 12 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The **PCI** switches to **Manual**.
- 13 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the onscreen keyboard. The input value range is from 1 to 100.

Table 23 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	A {2,8} +14*n	15 kHz	5 (1 ms)
< 3 GHz (FR1)	4	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
< 3 GHz (FR1)	4	C {2,8} +14*n	30 kHz	10 (0.5 ms)

Table 23 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
3 to 6 GHz (FR1)	8	A {2,8} +14*n	15 kHz	5 (1 ms)
3 to 6 GHz (FR1)	8	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	C {2,8} +14*n	30 kHz	10 (0.5 ms)
> 6 GHz (FR2)	64	D {4,8,16,20} +28*n	120 kHz	40 (0.125 ms)
> 6 GHz (FR2)	64	E {8,12,16,20,32,36,40,44} +56*n	240 kHz	80 (62.5 ms)

Table 24 Sync raster offset range per SSB SCS and sync raster resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center frequency
15	180	0 to 250	125
30	180	0 to 506	253
120	720	0 to 92	46
240	720	0 to 48	24

Table 25 Sync SCS offset range per SSB SCS and sync SCS resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center Frequency
15	15	0 to 11	0
30	30	0 to 5	0
120	120	0 to 5	0
240	240	0 to 2	0

To set trigger

- 1 Tap the **Menu > Trigger**.

- 2 Tap **Trigger** and select the options from **Internal**, **External**, or **GPS**.
- 3 Tap **Freq. Ref.**(Frequency Reference) to set the clock source.
 - **Internal**: Uses a 10 MHz internal clock
 - **External**: Uses external 10 MHz, 13 MHz, or 15 MHz clock automatically set by the instrument
 - **GPS**: Uses a built-in GPS as a frequency and timing source




NOTE

Make sure to set Frequency Reference for all measurement mode in 5G NR Signal Analyzer to sync the proper clock source.

Figure 58 shows an example of trigger spectrum measurement.

Figure 58 5G NR trigger spectrum measurement



Conducting RF measurements

The following sections describe how to conduct RF measurements.

Channel power


The Channel Power measurement is a common test used in the wireless industry to measure the total transmitted power of a radio within a defined frequency channel. It acquires a number of points representing the input signal in the time domain, transforms this information into the frequency domain using Fast Fourier Transform (FFT), and then calculates the channel power. The effective resolution bandwidth of the frequency domain trace is proportional to the number of points acquired for the FFT.

The channel power measurement identifies the total RF power, power spectral density, and Peak to Average Ratio (PAR) of the signal within the channel bandwidth.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the Save/Load icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth/SSB SCS** and select the Setting in the pop-up window based on your need. SSB is abbreviation for Synchronization Signal Block or SS Block and it refers to Synchronization PBCH block since the synchronization signal and PBCH channel are packed as a single block that always moves together. SSB should be detected first in 5G NR frame. See [Table 26](#) below for the setting criteria based on the operating frequency.
- 3 Tap **Sync Raster Offset** to set the sync raster resolution to 180 kHz (FR1) or to 720 kHz (FR2) for carrier frequency center using the on-screen keyboard. See [Table 27](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 4 Tap **Sync SCS Offset** to fine-tune the offset using the SCS. See [Table](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 5 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 6 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64. Refer to the selection criteria based on the table in **Step 2**.

- 7 Tap **SSB Auto Search** and do the following steps:
 - a Tap **Search Type** and select from the following three options:
 - **Full-Raster**: You can search in sync raster offset unit defined (FR1: 180 kHz, FR2: 720 kHz).
 - **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth.
 - b Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to **Start** to search SCS, type, and the number of SSB automatically. Once **Start** is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to **Manual**.
- 8 Tap **SSB Periodicity** and select the options from **5 ms**, **10 ms**, **20 ms**, **40 ms**, **80 ms**, **160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.
- 9 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 10 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The PCI switches to **Manual**.
- 11 Tap **EIRP Settings**.
 - a Tap **Distance** and input the value using the on-screen keyboard.
 - b Tap **Antenna Gain** and input the value using the on-screen keyboard.

- 12 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the onscreen keyboard. The input value is from 1 to 100.



NOTE

Distance and Antenna gain values are required when calculating EIRP. Effective Isotropic Radiated Power (EIRP) refers to the amount of power that a theoretical isotropic antenna (which evenly distributes power in all directions) would emit to produce the peak power density observed in the direction of maximum antenna gain. EIRP can take into account the losses in transmission line and connectors and includes the gain of the antenna. The EIRP is often stated in terms of decibels over a reference power emitted by an isotropic radiator with equivalent signal strength. The EIRP allows comparisons between different emitters regardless of type, size or form. From the EIRP, and with knowledge of a real antenna's gain, it is possible to calculate real power and field strength values.

Formula to calculate: $EIRP = Tx \text{ RF Power (dBm)} + GA \text{ (dB)} - FL \text{ (dB)}$

Tx RF Power refers to RF power measured at RF connector of the unit

GA refers to Gain Antenna

FL refers to Feeder loss (cable loss of any other loss occurred)

You can tap to switch to Channel Power or EIRP under the chart in the table, and it will show the automatically calculated value.

Table 26 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	A {2,8} +14*n	15 kHz	5 (1 ms)
< 3 GHz (FR1)	4	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
< 3 GHz (FR1)	4	C {2,8} +14*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	A {2,8} +14*n	15 kHz	5 (1 ms)
3 to 6 GHz (FR1)	8	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	C {2,8} +14*n	30 kHz	10 (0.5 ms)
> 6 GHz (FR2)	64	D {4,8,16,20} +28*n	120 kHz	40 (0.125 ms)

Table 26 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
> 6 GHz (FR2)	64	E {8,12,16,20,32,36,40,44} +56*n	240 kHz	80 (62.5 ms)

Table 27 Sync raster offset range per SSB SCS and sync raster resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center frequency
15	180	0 to 250	125
30	180	0 to 506	253
120	720	0 to 92	46
240	720	0 to 48	24

Sync SCS offset range per SSB SCS and sync SCS resolution


SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center Frequency
15	15	0 to 11	0
30	30	0 to 5	0
120	120	0 to 5	0
240	240	0 to 2	0

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication. The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 Tap **Low Limit** to set the lower threshold using the on-screen keyboard.
- 5 *Optional.* Tap the **Save** hot key on the side bar and select the save option from the choices available for your measurement mode.

Figure 59 shows an example of channel power measurement.

Figure 59 5G NR channel power measurement



Channel power measurement result shows channel power and spectrum density in a user specified channel bandwidth. The peak to average ratio (PAR) is shown at the bottom of the screen as well. The shaded area on the display indicates the channel bandwidth.

Conducting OTA measurement

The following sections describe how to conduct OTA analysis.

Beam analyzer


5G NR provides the beamforming profile of each transmission carrier, including the eight strongest beams and the corresponding power levels during its transmission period, and includes:

- **S-SS-RSRP (Secondary Synchronized Signal – Reference Signal Received Power)** — linear average over the power contributions (in Watts) of the resource elements which carry secondary synchronization signals
- **P-SS-RSRP (Primary Synchronization Signal – Reference Signal Received Power)** — average power measurement through all the primary sync signals
- **S-SS-SINR (Secondary Synchronization Signal – Signal to Interference Plus Noise Ratio)** — linear average over the power contribution (in Watts) of the resource elements carrying secondary synchronization signals divided by the linear average of the noise and interference power contribution (in Watts) over the resource elements carrying secondary synchronization signals within the same frequency bandwidth
- **SS-RSRQ (Secondary Synchronization Signal – Reference Signal Received Quality)** — ratio of $N \times \text{SS-RSRP} / \text{NR carrier RSSI}$. Here N refers to number of resource blocks in NR carrier RSSI measurement Bandwidth

Setting measure setup

Before starting the Beam Analyzer, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more details.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth/SSB SCS** and select the Setting in the pop-up window based on your need. SSB is abbreviation for Synchronization Signal Block or SS Block and it refers to Synchronization PBCH block since the synchronization signal and PBCH channel are packed as a single block that always moves together. SSB should be detected first in 5G NR frame. See [Table 28](#) below for the setting criteria based on the operating frequency.
- 3 Tap **Sync Raster Offset** to set the sync raster resolution to 180 kHz (FR1) or to 720 kHz (FR2) for carrier frequency center using the on-screen keyboard. See [Table 29](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 4 Tap **Sync SCS Offset** to fine-tune the offset using the SCS. See [Table 30](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 5 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 6 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64. Refer to the selection criteria based on the table in **Step 2**.
- 7 Tap **SSB Auto Search** and do the following steps:
 - a Tap **Search Type** and select from the following three options:
 - **Full-Raster**: You can search in sync raster offset (FR1: 180 kHz, FR2: 720 kHz).
 - **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth.
 - b Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to **Start** to search SCS, type, and the number of SSB automatically. Once **Start** is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to **Manual**.

- 8 Tap **SSB Periodicity** and select the options from **5 ms**, **10 ms**, **20 ms**, **40 ms**, **80 ms**, **160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.
- 9 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 10 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The PCI switches to **Manual**.



NOTE

You can go to **Menu > Frequency > Center Frequency List** to add frequently used center frequency using the **Add** button in the Frequency List or to delete the selected frequency using the **Delete** button. You can also apply one of the default frequencies in the Frequency List by tapping the **Apply** button.

Table 28 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	A {2,8} +14*n	15 kHz	5 (1 ms)
< 3 GHz (FR1)	4	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
< 3 GHz (FR1)	4	C {2,8} +14*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	A {2,8} +14*n	15 kHz	5 (1 ms)
3 to 6 GHz (FR1)	8	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	C {2,8} +14*n	30 kHz	10 (0.5 ms)
> 6 GHz (FR2)	64	D {4,8,16,20} +28*n	120 kHz	40 (0.125 ms)
> 6 GHz (FR2)	64	E {8,12,16,20,32,36,40,44} +56*n	240 kHz	80 (62.5 ms)

Table 29 Sync raster offset range per SSB SCS and sync raster resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center frequency
15	180	0 to 250	125
30	180	0 to 506	253
120	720	0 to 92	46
240	720	0 to 48	24

Table 30 Sync SCS offset range per SSB SCS and sync SCS resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center Frequency
15	15	0 to 11	0
30	30	0 to 5	0
120	120	0 to 5	0
240	240	0 to 2	0

Figure 60 shows an example of beam analyzer measurement.

Figure 60 5G NR beam analyzer measurement



NOTE
The undetected values in the Detected ID List table will be indicated as "--". You cannot save the measurement as a Result, instead Logging as CSV option is added.

Carrier scanner

5G Carrier Scanner provides an easy and fast response power measurements of up to eight single component carriers of 100 MHz. The power measurement for each carrier includes:

- **S-SS-RSRP (Secondary Synchronized Signal – Reference Signal Received Power)** — linear average over the power contributions (in Watts) of the resource elements which carry secondary synchronization signals
- **Channel Power** — integrated power of the entire channel bandwidth (100 MHz) during an entire transmission frame (10 ms)

Setting measure setup

Before starting the Beam Analyzer, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more details.


To set measure setup

- 1 Tap the **Configuration** icon in the Carrier Scanner table.
- 2 Tap **No** and select the carrier from 1 to 8.
- 3 Tap **Center Frequency** and input the required center frequency using the on-screen keyboard.
- 4 Tap **Channel Standard** and select the required channel standard from the pop-up window.
- 5 Tap **Channel Number** and input the required channel number using the on-screen keyboard.
- 6 Tap **Bandwidth/SCS** and select the required setting from the pop-up window.
 - a If you go with FR1, select the following:
 - SCS 15 kHz: 5, 10, 15, 20, 25, 30, 40, 50 MHz
 - SCS 30 kHz: 5, 10, 15, 20, 25, 30, 40, 50, 60, 70, 80, 90, 100 MHz
 - SCS 60 kHz: 10, 15, 20, 25, 30, 40, 50, 60, 70, 80, 90, 100 MHz
 - b If you go with FR2, select the following:
 - SCS 60, 120 kHz: 50, 100 MHz
 - SCS 240 kHz: 100MHz
- 7 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 8 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64.
- 9 Tap **SSB Periodicity** and select the options from **5 ms, 10 ms, 20 ms, 40 ms, 80 ms, 160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.

- 10 Tap to switch **PCI Mode** to **Manual** or **Auto**.
- 11 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The PCI switches to **Manual**.
- 12 Tap **Search Type** and select from the following three options:
 - a **Full-Raster**: You can search in sync raster offset unit that SPA06MA-O defines (FR1: 180 kHz, FR2: 720 kHz).
 - b **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - c **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/ purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth.
- 13 Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - a **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - b **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to **Start** to search SCS, type, and the number of SSB automatically. Once **Start** is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to **Manual**.
- 14 Tap **SSB Auto Search** between **Start** and **Stop**.
 - a **Start**: to search SCS, type, and the number of SSB automatically. Once **Start** is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to **Manual**.
 - b **Stop**: to set the SSB periodicity based on the base station.

Setting beam analyzer mode

To set up

- 1 Tap the **Search** icon of the selected carrier in the carrier scanner table to set the limit. This enables you to check the beam information without changing the measurement mode to Beam Analyzer. The beam information pops up for the selected carrier.
 - a Select the **Limit** () icon to set **SS-RSRP Line** and **SS-SINR Line** to **On** or **Off**. When selecting on, set the limit using the on-screen keyboard. You can also set limits moving the SS-RSRP Line Limit (default: blue) bar on the

left edge and SS-SINR Line Limit (default: orange) bar on the right edge. If the setting value is smaller than the limit, the line bar color and the result text color of the table become red.




- b Select the **Quick Save** () icon to capture the current screen.
- c Select the **Close** () icon to close the Beam Information window.

Figure 61 shows an example of a beam information screen.

Figure 61 Beam information



Setting sweep speed

To set up

- 1 Tap **Menu > Sweep**.
- 2 Tap **Sweep Speed** between **Fast** and **Normal**.
- 3 *Optional.* Tap **Sweep Once** to get a new measurement.

Figure 62 shows an example of carrier scanner measurement.

Figure 62 5G NR carrier scanner measurement



NOTE

You can toggle between Constellation and MIB next to the bar chart, Constellation shows PBCH quality, the more vivid the constellation is, the higher the value of EVM is. MIB shows the MIB summary within PBCH for the detected carrier.

Route map

5G route map traces the power level of the strongest beam corresponding a particular time and geographical position and presents it in a geographical map as a measurement point. All the collected measurements can be exported for post-processing purposes, including data of the eight strongest beams for each measurement point, including its measurement time and geographical location.

Figure 63 shows an example of 5G NR OTA route map measurement.


Figure 63 OTA route map with 5G NR Signal Analyzer



Loading a map






To use any features related to maps, you need to download and install the maps on the instrument. The **VIAXI JDMapCreator** will help you to download maps. Ensure the JDMapCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the **Send to EQP** menu in JDMapCreator. For information about how to use the JDMapCreator, see the *JDMapCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map file in .mcf file type created in JDMap-Creator.
- 2 Tap the **Load** () icon on the side bar.
- 3 Navigate to the map file that you want to open.
The **File Information** pane displays the file properties, including its name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.

Once you have loaded the map, you can also control the map using the following icons on the map.


Table 31 Map control icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, the purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in the map.
	Tap to zoom out the map.
	Tap and select the area where you want to expand.

The left-most cell-site icon is activated when you import the cell-site information file.

To set measurement setup

Before starting the Route Map measurement, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more information.

- 1 If required, connect a GNSS receiver to your instrument for outdoor mapping. Indoor mapping does not necessarily need a GNSS antenna.
- 2 Tap the Setup () icon on the side bar.
- 3 Tap **Map Config** to configure the map setting.
 - a Tap to switch the **Plot Point** to **GNSS**, **Position**, or **Time**.
 - To collect data/plot points automatically as you move around in a vehicle or outside, select **GNSS**.
 - To collect data/plot points manually in an indoor layout without a GNSS antenna, select **Position**.
 - To collect data/plot points based on time, select **Time**.
 - b Tap to switch **Plot Item** to **P-SS-RSRP**, **S-SS-RSRP**, **S-SS-RSRQ** or **S-SS-SINR**.
 - c Tap to switch the **Screen Mode** between **Map** and **Full**.
 - With the **Map** setting, you can view only the collected points that can be seen within the boundary of the loaded map.
 - With the **Full** setting, you can view all the collected points of the route without the loaded map
- 4 Tap **Bandwidth/SSB SCS** and select the Setting in the pop-up window based on your need. SSB is abbreviation for Synchronization Signal Block or SS Block and it refers to Synchronization PBCH block since the synchronization signal and PBCH channel are packed as a single block that always moves together. SSB should be detected first in 5G NR frame. See [Table 32](#) below for the setting criteria based on the operating frequency.
- 5 Tap **Sync Raster Offset** to set the sync raster resolution to 180 kHz (FR1) or to 720 kHz (FR2) for carrier frequency center using the on-screen keyboard. See [Table 33](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 6 Tap **Sync SCS Offset** to fine-tune the offset using the SCS. See [Table 34](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 7 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 8 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64. Refer to the selection criteria based on the table in **Step 4**.

- 9 Tap **SSB Auto Search** and do the following steps:
 - a Tap **Search Type** and select from the following three options:
 - **Full-Raster**: You can search in sync raster offset unit.
 - **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth.
 - b Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to Start to search SCS, type, and the number of SSB automatically. Once Start is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to Manual.
- 10 Tap **SSB Periodicity** and select the options from **5 ms, 10 ms, 20 ms, 40 ms, 80 ms, 160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.
- 11 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 12 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The PCI switches to **Manual**.

Table 32 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	A {2,8} +14*n	15 kHz	5 (1 ms)
< 3 GHz (FR1)	4	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
< 3 GHz (FR1)	4	C {2,8} +14*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	A {2,8} +14*n	15 kHz	5 (1 ms)
3 to 6 GHz (FR1)	8	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)

Table 32 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
3 to 6 GHz (FR1)	8	C {2,8} +14*n	30 kHz	10 (0.5 ms)
> 6 GHz (FR2)	64	D {4,8,16,20} +28*n	120 kHz	40 (0.125 ms)
> 6 GHz (FR2)	64	E {8,12,16,20,32,36,40,44} +56*n	240 kHz	80 (62.5 ms)

Table 33 Sync raster offset range per SSB SCS and sync raster resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center frequency
15	180	0 to 250	125
30	180	0 to 506	253
120	720	0 to 92	46
240	720	0 to 48	24

Table 34 Sync SCS offset range per SSB SCS and sync SCS resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center Frequency
15	15	0 to 11	0
30	30	0 to 5	0
120	120	0 to 5	0
240	240	0 to 2	0

To set limit


You can set the thresholds for the two different color indicators, red and blue. The maximum value is the Limit for **Excellent**, and the minimum value is the Limit for **Poor**. See below to check the plot point color based on the Legend Color Table.

- 1 Tap the rectangle with value before color legend bar on the right panel.
- 2 Set a value for **Poor** (minimum value) using the on-screen keyboard.
- 3 Tap the rectangle with value after color legend bar on the right panel.

- 4 Set a value for **Excellent** (maximum value) using the on-screen keyboard.

Figure 64 shows a legend color table.

Figure 64 Legend color table



Logging data


To use any features related to maps, you need to download and install the maps on the instrument. The VIAVI JDMAPCreator will help you download maps. Make sure the JDMAPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JDMAPCreator. For more information on how to use the JDMAPCreator, see the *JDMAPCreator 2.0 User Guide*.

To log data

- 1 Follow **step 1 to 3** in Setting measure setup.
- 2 Tap the **Testing** button on the right panel of the map to start plotting on the map. When you select a point on the map, a marker appears and the Information window appears on the right panel.
- 3 Tap the **Stop** (■) button to stop plotting.
- 4 Tap the **Pause** button (||) to pause plotting, then the GPS point cannot be plotted.
- 5 If you start test and select **Setup > Map Config > Plot Point > Position**, you can undo by tapping the **Testing** button.
- 6 If you select the **Stop** button, the Plot Stop pop-up window appears, then tap **Yes**.
- 7 Tap **Yes** when the Save pop-up window appears and the logging file to your USB.

Viewing the logging data

To view the logging data

- 1 Load the saved logging file using the **Load** () icon on the side bar. Make sure the file extension is .gomv.
- 2 If the **PCI** is set to **Auto**, the point on the map appears with a color representing the largest **S-SS-RSRP** value. When you select a point on the map, a marker appears and the Information window appears on the right panel.
- 3 Set the **PCI** to **Manual** and tap the **Select** button.
The Select PCI window appears.
- 4 Select PCI on the left and then the corresponding Beam Index appeared on the right.
- 5 Tap the **Apply** button.
The point color of the map changes to the corresponding SS-RSRP value, and if there is no detected Beam Index, the point will be hidden.

Importing cellsite DB

You can import the site DB by creating the 5G site information form.

To import cellsite DB


- 1 Create the 5G site information with an excel file as below.
- 2 Input the two mandatory fields: **Lat (DecDeg)** and **Long (DecDeg)**.
- 3 Input the **Azimuth** field if you want to check the direction of antenna.
- 4 Make sure to save the file as (Comma delimited) (*.csv).
- 5 Copy the file to the USB memory stick and insert it to the **USB A** or **USB B** port of the instrument.
- 6 Tap the **Load** () icon on the side bar.
- 7 Import the saved file.
Once the file is loaded, the following cellsite information appears with an icon.

Figure 65 shows an example of an importing cellsite DB.

Figure 65 Importing Cellsite DB

		Mandatory field to be input		Not mandatory field to be input	Antenna direction to be shown if input
		A	B	C	D
Mandatory row and title	1	Site Information Form	Version	1	
	2	ID	Lat(DecDe	Long(DecD	Height
Site ID & example	3	HASRU130	29.73186	-95.3687	20
	4	HASRU131	29.73186	-95.3687	20
	5	HASRU140	29.73186	-95.3687	20
	6	HASRU141	29.73186	-95.3687	20
	7	HASRU150	29.72883	-95.3664	13
	8	HASRU151	29.72563	-95.3643	12.25
					0

Figure 66 Route map measurement with site information screen







Figure 65 shows an example of OTA route map measurement with Plot Point to Time.

Figure 67 OTA route map measurement with Plot Point to Time



NOTE

When you setup Plot Point to Time and tap the start/testing button, you can't touch the screen to active. After the waiting indicator( Waiting) stops, the active indicator( 00 Data) shows up.


Freq/Time/Power variation

Frequency, time, and power variation shows the frequency, time, and power error trend based on the time elapsed.

After configuring the spectrum measurement in “[Configuring spectrum measurements](#)” on page 9, you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

Setting measure setup

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth/SSB SCS** and select the Setting in the pop-up window based on your need. SSB is abbreviation for Synchronization Signal Block or SS Block and it refers to Synchronization PBCH block since the synchronization signal and PBCH channel are packed as a single block that always moves together. SSB should be detected first in 5G NR frame. See [Table 35](#) below for the setting criteria based on the operating frequency.

- 3 Tap **Sync Raster Offset** to set the sync raster resolution to 180 kHz (FR1) or to 720 kHz (FR2) for carrier frequency center using the on-screen keyboard. See [Table 36](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 4 Tap **Sync SCS Offset** to fine-tune the offset using the SCS. See [Table 37](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 5 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 6 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64. Refer to the selection criteria based on the table in **Step 2**.
- 7 Tap **SSB Auto Search** and do the following steps:
 - a Tap **Search Type** and select from the following three options:
 - **Full-Raster**: You can search in sync raster offset unit (FR1: 180 kHz, FR2: 720 kHz).
 - **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth.
 - b Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to Start to search SCS, type, and the number of SSB automatically. Once Start is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to Manual.
- 8 Tap **SSB Periodicity** and select the options from **5 ms, 10 ms, 20 ms, 40 ms, 80 ms, 160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.
- 9 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 10 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The PCI switches to **Manual**.

Table 35 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	A {2,8} + 14*n	15 kHz	5 (1 ms)

Table 35 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
< 3 GHz (FR1)	4	C {2,8} +14*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	A {2,8} +14*n	15 kHz	5 (1 ms)
3 to 6 GHz (FR1)	8	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	C {2,8} +14*n	30 kHz	10 (0.5 ms)
> 6 GHz (FR2)	64	D {4,8,16,20} +28*n	120 kHz	40 (0.125 ms)
> 6 GHz (FR2)	64	E {8,12,16,20,32,36,40,44} +56*n	240 kHz	80 (62.5 ms)

Table 36 Sync raster offset range per SSB SCS and sync raster resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center frequency
15	180	0 to 250	125
30	180	0 to 506	253
120	720	0 to 92	46
240	720	0 to 48	24

Table 37 Sync SCS offset range per SSB SCS and sync SCS resolution


SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center Frequency
15	15	0 to 11	0
30	30	0 to 5	0
120	120	0 to 5	0
240	240	0 to 2	0

NOTE

If you want to set the reference level and scale, tap **Menu > Amp/Scale > Reference**. You can set Reference Freq Error Offset, Scale Division (Freq Error), Reference Time Error Offset, Scale Division (Time Error), Reference Level, and Scale Division (Power) on demand using the on-screen keyboard. You can also select the unit on the keyboard.

Figure 68 shows an example of 5G NR freq/time/power variation by offset.

Figure 68 5G NR freq/time/power variation by offset




NOTE

You can tap the Distance box and input the value that you want to compensate for distance. When distance is entered, the time will show the value with distance correction. Make sure the default value for Distance is 0.

Figure 69 shows an example of 5G NR freq/time/power variation by power.

Figure 69 5G NR freq/time/power variation by power



Using 5G DSS Signal Analyzer

This chapter describes how to use the 5G NR Signal Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 144](#)
- [“Selecting mode and measure” on page 144](#)
- [“Conducting spectrum measurements” on page 144](#)
- [“Conducting RF measurements” on page 146](#)
- [“Conducting OTA measurement” on page 152](#)

Introduction

Dynamic Spectrum Sharing (DSS) Signal Analyzer allows the deployment of both 4G LTE and 5G NR in the same frequency band and dynamically allocates spectrum resources between the two technologies based on user demand.

The module provides following measurements for 5G DSS analysis:

- Spectrum Analysis
 - Spectrum
- RF Analysis
 - Channel Power
 - Occupied Bandwidth
- Power vs Time
 - Power vs Time (Frame)
 - Power vs Time (Slot)
- OTA Analysis
 - OTA Channel Scanner
 - OTA ID Scanner
 - OTA Multipath Profile
 - OTA Control Channel
 - OTA Route Map
 - Freq/Time/Power Variation

Selecting mode and measure

The following procedure describes how to start measurement.

To select mode and measure

- 1 Tap **5G DSS Signal Analyzer** on the **MODE** panel.
- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Spectrum**
 - **RF Analysis > Channel Power, Occupied Bandwidth**
 - **Power vs Time > Power vs Time (Frame), Power vs Time (Slot)**
 - **OTA Analysis > OTA Channel Scanner, OTA ID Scanner, OTA Multipath Profile, OTA Control Channel, OTA Route Map, or Freq/Time Error Variation**

Conducting spectrum measurements


The following sections describe how to conduct spectrum measurements.

Spectrum

Setting measure setup

After configuring the spectrum measurement can configure the measurements just as in Spectrum mode. For more information, see [“Configuring spectrum measurements” on page 9](#). The measurement settings can be saved and recalled as a File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** from the following choices: **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.
- 3 Tap to switch **Signal Tech Type** to **TDD** or **FDD**.

To set trigger

- 1 Tap the **Menu > Trigger**.
- 2 Tap **Trigger** and select the options from **Internal**, **External**, or **GPS**.
- 3 Tap **Freq. Ref.**(Frequency Reference) to set the clock source.
 - **Internal**: Uses a 10 MHz internal clock
 - **External**: Uses external 10 MHz, 13 MHz, or 15 MHz clock automatically set by the instrument
 - **GPS**: Uses a built-in GPS as a frequency and timing source




NOTE

Make sure to set Frequency Reference for all measurement mode in 5G DSS Signal Analyzer to sync the proper clock source.

[Figure 70](#) shows an example of spectrum measurement.

Figure 70 5G DSS spectrum measurement



Conducting RF measurements

The following sections describe how to conduct RF measurements.

Channel power


The Channel Power measurement is a common test used in the wireless industry to measure the total transmitted power of a radio within a defined frequency channel. It acquires a number of points representing the input signal in the time domain, transforms this information into the frequency domain using Fast Fourier Transform (FFT), and then calculates the channel power. The effective resolution bandwidth of the frequency domain trace is proportional to the number of points acquired for the FFT.

The channel power measurement identifies the total RF power, power spectral density, and Peak to Average Ratio (PAR) of the signal within the channel bandwidth.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** from the following choices: **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.

- 3 Tap to switch **Signal Tech Type** to **TDD** or **FDD**.
- 4 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the on-screen keyboard.
The input value range is from 1 to 100.

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication. The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 Tap **Low Limit** to set the lower threshold using the on-screen keyboard.
- 5 *Optional.* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Figure 71 shows an example of channel power measurement.

Figure 71 5G DSS channel power measurement



Channel power measurement result shows channel power and spectrum density in a user specified channel bandwidth. The peak to average ratio (PAR) is shown at the bottom of the screen as well. The shaded area on the display indicates the channel bandwidth.


Occupied bandwidth

The Occupied Bandwidth measures the percentage of the transmitted power within a specified bandwidth. The percentage is typically 99%.

Setting measure setup

After configuring the spectrum measurement in “[Configuring spectrum measurements](#)” on page 9, you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** from the following choices: **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.
- 3 Tap to switch **Signal Tech Type** to **TDD** or **FDD**.
- 4 Tap **Menu > BW/AVG > Average** to set the number of measurements to be averaged using the on-screen keyboard.
The input value range is from 1 to 100.

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap to switch the **Test Limits** to **On** or **Off** to enable or disable Pass/Fail indication. The result table color for Pass is green, and the result table color for Fail is red.
- 3 Tap **High Limit** to set the upper threshold using the on-screen keyboard.
- 4 *Optional.* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

[Figure 72](#) shows an example of occupied bandwidth measurement.

Figure 72 5G DSS occupied bandwidth measurement



The Occupied Bandwidth measurement shows both of power across the band and power bandwidth in a user specified percentage to determine the amount of spectrum

used by a modulated signal. Occupied bandwidth is typically calculated as the bandwidth containing 99% of the transmitted power.

Conducting Power vs Time measurements

The following sections describe how to conduct Power vs Time measurements.


Power vs Time (Frame)

The Power vs. Time (Frame) measures the modulation envelope in the time domain, showing the power of each time slot in a DSS signal.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** from the following choices: **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.
- 3 Tap to switch **Signal Tech Type** to **TDD** or **FDD**.
- 4 Tap **Subframe Number** from 0 to 9.
- 5 Tap to switch PCI (Physical Cell ID) to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the DSS signal automatically.
 - **Manual** sets the specific Physical Cell ID for the DSS signal manually in order to speed up the synchronization with a BTS.
- 6 Tap **PCI** and input a value from 0 to 503 using the on-screen keyboard.
The **PCI** switches to **Manual**.
- 7 Tap **Antenna Port** to assign an antenna port number automatically or manually, and select from **Auto**, **Antenna 0**, **Antenna 1**, **Antenna 2**, or **Antenna 3**.
If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
- 8 Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports.
- 9 Select **Cyclic Prefix** between **Normal** and **Extended**.
Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap the test items and set the limits depending on your selected measurement mode:

To set the limit for	Set
Subframe Power	Test limits On/Off, High Limit/Low Limit using the on-screen keyboard
Frame Average Power	Test limits On/Off, High Limit/Low Limit using the on-screen keyboard
Time Error	Test limits On/Off, High Limit/Low Limit using the on-screen keyboard
IQ Origin Offset	Test limits On/Off, High Limit using the on-screen keyboard

- 3 *Optional.* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Figure 73 shows an example of Power vs Time (Frame) measurement.

Figure 73 5G DSS Power vs Time (Frame) measurement



Power vs Time (Slot)

The Power vs. Time (Frame) measures the modulation envelope in the time domain, showing the power of each time slot in a DSS signal.




NOTE

In this measurement, desirable level of the input power is lower than -10 dBm. If the input power to be measured is -10 dBm or higher, it is highly recommended that you use an external attenuator.

Setting measure setup

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth** from the following choices: **5 MHz**, **10 MHz**, **15 MHz**, or **20 MHz**.
- 3 Tap to switch **Signal Tech Type** to **TDD** or **FDD**.
- 4 Tap **Subframe Number** from 0 to 9.
- 5 Tap to switch PCI (Physical Cell ID) to **Manual** or **Auto**.
 - **Auto** lets the instrument detect the Physical Cell ID for the DSS signal automatically.
 - **Manual** sets the specific Physical Cell ID for the DSS signal manually in order to speed up the synchronization with a BTS.
- 6 Tap **PCI** and input a value from 0 to 503 using the on-screen keyboard.
The **PCI** switches to **Manual**.
- 7 Tap **Antenna Port** to assign an antenna port number automatically or manually, and select from **Auto**, **Antenna 0**, **Antenna 1**, **Antenna 2**, or **Antenna 3**.
If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
- 8 Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports.
- 9 Select **Cyclic Prefix** between **Normal** and **Extended**.
Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap the test items and set the limits depending on your selected measurement mode:

To set the limit for	Set
Slot Average Power	Test limits On/Off, High Limit/Low Limit using the on-screen keyboard
Off Power	Test limits On/Off, High Limit/Low Limit using the on-screen keyboard
Transition Period	Test limits On/Off, High Limit/Low Limit using the on-screen keyboard

3 *Optional.* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Figure 74 shows an example of Power vs Time (Slot) measurement.

Figure 74 5G DSS Power vs Time (Slot) measurement



Conducting OTA measurement

The following sections describe how to conduct OTA analysis.


OTA Channel Scanner

The Channel Scanner is a radio receiver that can automatically tune or scan two or more discrete frequencies and multi-channels, indicating when it finds a signal on one of them and then continuing scanning when that frequency goes silent.

Setting measure setup

After configuring spectrum measurement in “[Configuring spectrum measurements](#)” on [page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bars.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap to switch **Radio Config** and set **Duplex Type** (FDD/TDD), **DSS Type** (Co-channel) and **Technology** (LTE/NR) and other related parameters as below:
You can select Co-channel to find NR frequency based on the LTE operating frequency in co-channel and select Adjacent channel to search both LTE and NR frequency. Note that Adjacent channel will be available in the next release.
 - When **LTE** is selected as **Technology**, do the following steps:
 - Select **Bandwidth** (MHz) from the following choices: **20**, **15**, **10**, or **5**.
 - Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
 - Select **Cyclic Prefix** between **Normal** and **Extended**. Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread
 - Select **PHICH Ng** between **Normal** and **Extended** and then to set the number of PHICH groups (Ng): 1/6, 1/2, 1, or 2. The PHICH group value/Ng is decided based on the number of PHICH groups per subframe. PHICH duration is a higher layer parameter configured either as Normal or Extended that says the demodulator how many symbols per subframe are used by PHICH.
 - **Normal**: There are 8 PHICH sequences in one PHICH group (4 symbols).
 - **Extended**: There are 4 PHICH sequences in one PHICH group (2 symbols)
 - When **NR** is selected as **Technology**, do the following steps:
 - Select sub-Carrier Spacing as 15 kHz (Case A). The standard for NR SCS is 15 kHz. The instrument supports 15 kHz of sub-carrier spacing.
- 3 Tap to switch **CFI** to **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually. The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 4 Tap **CFI** and input a value from 1 to 3 as desired using the on-screen keyboard.
- 5 Tap **SSB frequency** and input the value using the on-screen keyboard.

- 6 Tap GSCN and input the value from 2 to 26639 using the on-screen keyboard. If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that CellAdvisor 5G supports.



NOTE

Based on the GSCN input frequency, the SSB Frequency is automatically changed.

General setting

You can configure trigger setting in the general setting section.

- 1 Tap the **Configuration** icon in the detected list table or **Setup > Configuration**.
- 2 Tap Trigger to set **Internal**, **External** or **GPS** as required.
 - **Internal**: when starting a signal processing using the internal reference clock and creating a trigger
 - **External**: when starting a signal processing based on the external input trigger
 - **GPS**: When synchronizing the signal processing via the GPS receiver

Carrier setting

You can configure up to three carriers in the carrier setting section.

- 1 Tap the **Index** box. You can select up to 3 carriers.

- 2 Select the carrier number from 1 to 3 and set the following:
 - a Tap the **Center Frequency** box and input the value using the on-screen keyboard.



NOTE

If you input the center frequency, the instrument automatically searches SSB frequency and displays the searched NR frequency in the Detected List table.

- b Tap the **Channel Standard** box and choose one from the pop-up window and tap the Apply button.
- c Tap the **Channel Number** box and input the value using the on-screen keyboard.
- d Tap the **Bandwidth** box and input the value using the on-screen keyboard.
- e Tap the **Add** button to add more carriers and set from step a to d.
- f Tap the **External Offset** box and input the value using the on-screen keyboard and tap to switch the external offset to **On** (green) or **Off** (gray) as desired.
- g Tap the **Attenuation** box and input the value using the on-screen keyboard if you want to set it manually (**Manual**). Or tap it to set **Auto**.
- h Tap to switch the **Preamp** box 1 to **On** (green) or **Off** (gray).

To set the limit

- 1 Tap **Menu > Limit**.
- 2 Tap to select **Limit Line** to **on** or **off**.
- 3 Enter the **Limit Line** value using the on-screen keyboard as required once limit line is on.

Figure 75 shows an example of OTA Channel Scanner measurement.

Figure 75 5G DSS OTA Channel Scanner measurement



NOTE
OTA Channel Scanner displays LTE signal with RS channel and NR signal with SS channel during its transmission period.

OTA ID Scanner

The LTE mobile receives signals from multiple base stations that all these signals share the same spectrum and are present at the same time. Each base station has unique scrambling code assigned to the particular base station and it differentiates its signal from other base stations in the area.

The ID Scanner shows key parameters such as RSRP (Reference Signal Received Power) and RSRQ (Reference Signal Received Quality) that predict the downlink coverage quickly. RSRPs from entire cells help to rank between the different cells as input for handover and cell reselection decisions. RSRQ provides additional information when RSRP is not sufficient to make a reliable handover or cell reselection decision.

Setting measure setup

After configuring spectrum measurement in “Configuring spectrum measurements” on page 9, you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bars.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.

- 2 Tap **Carrier Auto Search** and set the following:
 - a Tap **Center Frequency** and input a value using the on-screen keyboard.
 - b Tap the **Search** button.



NOTE

If searching is unavailable, the instrument displays a pop-up message saying that it fails to detect NR (SSB) frequency.

- c Once searched, tap the **Apply** button.



NOTE

If you know the LTE center frequency, the instrument automatically searches SSB frequency.

- 3 Tap to switch **Radio Config** and set **Duplex Type** (FDD/TDD), **DSS Type** (Co-channel), and **Technology** (LTE/NR) and other related parameters as below.
You can select Co-channel to find NR frequency based on the LTE operating frequency in co-channel and select Adjacent channel to search both LTE and NR frequency. Note that Adjacent channel will be available in the next release.
- When **LTE** is selected as **Technology**, do the following steps:
 - Select **Bandwidth** (MHz) from the following choices: **20**, **15**, **10**, or **5**.
 - Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
 - Select **Cyclic Prefix** between **Normal** and **Extended**. Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread
 - Select **PHICH Ng** between **Normal** and **Extended** and then to set the number of PHICH groups (Ng): 1/6, 1/2, 1, or 2. The PHICH group value/Ng is decided based on the number of PHICH groups per subframe. PHICH duration is a higher layer parameter configured either as Normal or Extended that says the demodulator how many symbols per subframe are used by PHICH.
 - **Normal**: There are 8 PHICH sequences in one PHICH group (4 symbols).
 - **Extended**: There are 4 PHICH sequences in one PHICH group (2 symbols)
- When **NR** is selected as **Technology**, do the following steps:
 - Select sub-Carrier Spacing as 15 kHz (Case A). The standard for NR SCS is 15 kHz. The instrument supports 15 kHz of sub-carrier spacing.

- 4 Tap to switch **CFI** to **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually. The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 5 Tap **CFI** and input a value from 1 to 3 as desired using the on-screen keyboard.
- 6 Tap **SSB frequency** and input the value using the on-screen keyboard.
- 7 Tap **GSCN** and input the value from 2 to 26639 using the on-screen keyboard. If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that CellAdvisor 5G supports.



NOTE

Based on the GSCN input frequency, the SSB Frequency is automatically changed.

- 8 Tap **PCI** (Physical Cell ID) and select between **LTE PCI** and **NR PCI**.
 - a Tap to switch **LTE PCI Mode** to **Manual** or **Auto** and input a value from 0 to 503.
The **PCI** switches to **Manual**.
 - b Tap **NR PCI Mode** to **Manual** or **Auto** and input a value from 0 to 1007.
The **PCI** switches to **Manual**.



NOTE

You can set Auto to let the instrument detect the Physical Cell ID for the LTE/ NR signal automatically and Manual to set the specific Physical Cell ID for the LTE/NR signal manually in order to speed up the synchronization with a BTS.

Figure 76 shows an example of OTA ID Scanner measurement.

Figure 76 5G DSS OTA ID Scanner measurement



NOTE

OTA ID Scanner displays LTE signal with RS channel and NR signal with SS channel during its transmission period. You can select signals between RSRQ/ S-SS Ec/Io and S-SS SINR based on your need by tapping the down arrow button on the graph chart.

OTA Multipath Profile

The Multipath Profile enables you to determine RF environmental conditions of testing area. It indicates the amount of power of the dominant pilot signal that is dispersed outside the main correlation peak due to multipath echoes that are expressed in dB. This value should be very small ideally.

The Multipath Profile is the result of portions of the original broadcast signal arriving at the receiving antenna out of phase. This can be caused by the signal being reflected off objects such as buildings or being refracted through the atmosphere differently from the main signal.

Setting measure setup

After configuring spectrum measurement in “[Configuring spectrum measurements](#)” on [page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bars

To set measure set up

- 1 Tap the **Setup** () icon in the side bar.

- 2 Tap **Carrier Auto Search** and set the following:
 - a Tap **Center Frequency** and input a value using the on-screen keyboard.
 - b Tap the **Search** button.



NOTE

If searching is unavailable, the instrument displays a pop-up message saying that it fails to detect NR (SSB) frequency.

- c Once searched, tap the **Apply** button.



NOTE

If you know the LTE center frequency, the instrument automatically searches SSB frequency.

- 3 Tap to switch **Radio Config** and set **Duplex Type** (FDD/TDD), **DSS Type** (Co-channel), and **Technology** (LTE/NR) and other related parameters as below.
You can select Co-channel to find NR frequency based on the LTE operating frequency in co-channel and select Adjacent channel to search both LTE and NR frequency. Note that Adjacent channel will be available in the next release.
- When **LTE** is selected as **Technology**, do the following steps:
 - Select **Bandwidth** (MHz) from the following choices: **20**, **15**, **10**, or **5**.
 - Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
 - Select **Cyclic Prefix** between **Normal** and **Extended**. Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread
 - Select **PHICH Ng** between **Normal** and **Extended** and then to set the number of PHICH groups (Ng): 1/6, 1/2, 1, or 2. The PHICH group value/Ng is decided based on the number of PHICH groups per subframe. PHICH duration is a higher layer parameter configured either as Normal or Extended that says the demodulator how many symbols per subframe are used by PHICH.
 - **Normal**: There are 8 PHICH sequences in one PHICH group (4 symbols).
 - **Extended**: There are 4 PHICH sequences in one PHICH group (2 symbols)
- When **NR** is selected as **Technology**, do the following steps:
 - Select sub-Carrier Spacing as 15 kHz (Case A). The standard for NR SCS is 15 kHz. The instrument supports 15 kHz of sub-carrier spacing.

- 4 Tap to switch **CFI** to **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually. The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 5 Tap **CFI** and input a value from 1 to 3 as desired using the on-screen keyboard.
- 6 Tap **SSB frequency** and input the value using the on-screen keyboard.
- 7 Tap **GSCN** and input the value from 2 to 26639 using the on-screen keyboard. If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that CellAdvisor 5G supports.



NOTE

Based on the GSCN input frequency, the SSB Frequency is automatically changed.

- 8 Tap **PCI** (Physical Cell ID) and select between **LTE PCI** and **NR PCI**.
 - a Tap to switch **LTE PCI Mode** to **Manual** or **Auto** and input a value from 0 to 503.
The **PCI** switches to **Manual**.
 - b Tap **NR PCI Mode** to **Manual** or **Auto** and input a value from 0 to 1007.
The **PCI** switches to **Manual**.




NOTE

You can set Auto to let the instrument detect the Physical Cell ID for the LTE/ NR signal automatically and Manual to set the specific Physical Cell ID for the LTE/NR signal manually in order to speed up the synchronization with a BTS.

Figure 77 shows an example of OTA Multipath Profile measurement.

Figure 77 OTA Multipath Profile measurement



OTA Control Channel

DL RS power is the resource element power of Downlink Reference Symbol. The absolute DL RS power is indicated on the BCH. The absolute accuracy is defined as the maximum deviation between the DL RS power indicated on the BCH and the DL RS power at the BS antenna connector.

The OTA Control Channel provides summary of all control channels including RS power trend over time. GPS coordinates (latitude and longitude) will be displayed on the screen if a GPS antenna is connected and locked to the GPS satellites.

Setting measure setup

After configuring spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bars

To set measure set up

- 1 Tap the **Setup** () icon in the side bar.

- 2 Tap **Carrier Auto Search** and set the following:
 - a Tap **Center Frequency** and input a value using the on-screen keyboard.
 - b Tap the **Search** button.



NOTE

If searching is unavailable, the instrument displays a pop-up message saying that it fails to detect NR (SSB) frequency.

- c Once searched, tap the **Apply** button.



NOTE

If you know the LTE center frequency, the instrument automatically searches SSB frequency.

- 3 Tap to switch **Radio Config** and set **Duplex Type** (FDD/TDD), **DSS Type** (Co-channel), and **Technology** (LTE/NR) and other related parameters as below.
You can select Co-channel to find NR frequency based on the LTE operating frequency in co-channel and select Adjacent channel to search both LTE and NR frequency. Note that Adjacent channel will be available in the next release.
 - When **LTE** is selected as **Technology**, do the following steps:
 - Select **Bandwidth** (MHz) from the following choices: **20**, **15**, **10**, or **5**.
 - Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
 - Select **Cyclic Prefix** between **Normal** and **Extended**. Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread
 - Select **PHICH Ng** between **Normal** and **Extended** and then to set the number of PHICH groups (Ng): 1/6, 1/2, 1, or 2. The PHICH group value/Ng is decided based on the number of PHICH groups per subframe. PHICH duration is a higher layer parameter configured either as Normal or Extended that says the demodulator how many symbols per subframe are used by PHICH.
 - **Normal**: There are 8 PHICH sequences in one PHICH group (4 symbols).
 - **Extended**: There are 4 PHICH sequences in one PHICH group (2 symbols)
 - When **NR** is selected as **Technology**, do the following steps:
 - Select sub-Carrier Spacing as 15 kHz (Case A). The standard for NR SCS is 15 kHz. The instrument supports 15 kHz of sub-carrier spacing.
- 4 Tap **Antenna Port** to assign an antenna port number automatically or manually, and select from **Auto**, **Antenna 0**, **Antenna 1**, **Antenna 2**, or **Antenna 3**.
If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.

- 5 Tap to switch **MIMO** to **4x4** or **2x2**.
- 6 Tap to switch **CFI** to **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually.
 - The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 7 Tap **CFI** and input a value from 1 to 3 as desired using the on-screen keyboard.
- 8 Tap **SSB frequency** and input the value using the on-screen keyboard.
- 9 Tap **GSCN** and input the value from 2 to 26639 using the on-screen keyboard. If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that CellAdvisor 5G supports.



NOTE

Based on the GSCN input frequency, the SSB Frequency is automatically changed.

- 10 Tap **PCI** (Physical Cell ID) and select between **LTE PCI** and **NR PCI**.
 - a Tap to switch **LTE PCI Mode** to **Manual** or **Auto** and input a value from 0 to 503.
The **PCI** switches to **Manual**.
 - b Tap **NR PCI Mode** to **Manual** or **Auto** and input a value from 0 to 1007.
The **PCI** switches to **Manual**.



NOTE

You can set Auto to let the instrument detect the Physical Cell ID for the LTE/ NR signal automatically and Manual to set the specific Physical Cell ID for the LTE/NR signal manually in order to speed up the synchronization with a BTS.

To set limit

- 1 Tap **Menu > Limit**.
- 2 If you want to set the NR limit, tap **NR Limit** and set the limits depending on your selected measurement mode:

To set the limit for	Set
P-SS EVM (Primary Synchronization Signal Error Vector Magnitude)	Test limits On/Off, High Limit using the on-screen keyboard

To set the limit for	Set
S-SS EVM (Secondary Synchronization Signal Error Vector Magnitude)	Test limits On/Off, High Limit using the on-screen keyboard

3 Tap **LTE Limit** and set the limits depending on your selected measurement mode:

To set the limit for	Set
RS EVM (Root Mean Square (RMS) average of the reference signal for data error vector magnitude)	Test limits On/Off, High Limit using the on-screen keyboard
P-SS EVM (Primary Synchronization Signal Error Vector Magnitude)	Test limits On/Off, High Limit using the on-screen keyboard
S-SS EVM (Secondary Synchronization Signal Error Vector Magnitude)	Test limits On/Off, High Limit using the on-screen keyboard
Frequency Error	Test limits On/Off, High/Low Limit using the on-screen keyboard
Time Error	Test limits On/Off, High/Low Limit using the on-screen keyboard
Time Alignment Error	Test limits On/Off, High Limit using the on-screen keyboard

4 *Optional.* Tap the **Save** icon on the side bar and select the save option from the choices available for your measurement mode.

Figure 78 shows an example of OTA Control Channel measurement.

Figure 78 5G DSS OTA Control Channel measurement



OTA Route Map

5G route map traces the power level of the strongest beam corresponding a particular time and geographical position and presents it in a geographical map as a measurement point. All the collected measurements can be exported for post-processing purposes, including data of the eight strongest beams for each measurement point, including its measurement time and geographical location.

Figure 79 shows an example of 5G DSS OTA Route Map measurement.

Figure 79 OTA Route Map with 5G DSS Signal Analyzer




Loading a map

To use any features related to maps, you need to download and install the maps on the instrument. The **VIavi JDMaPCreator** will help you to download maps. Ensure the JDMaPCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the **Send**






to **EQP** menu in JMapCreator. For information about how to use the JMapCreator, see the *JMapCreator 2.0 User Guide*.

To load a map

- 1 Plug in your USB flash drive that has a map file in .mcf file type created in JMapCreator.
- 2 Tap the **Load** () icon on the side bar.
- 3 Navigate to the map file that you want to open.
The **File Information** pane displays the file properties, including its name, size, type, and date modified.
- 4 Tap the **Load** button on the screen.

Once you have loaded the map, you can also control the map using the following icons on the map.


Table 38 Map control icons

Icon	Description
	Tap to go to your current location on the map. Once tapped, the purple icon appears on the map, indicating your current location.
	Tap to switch to the full screen map view.
	Tap to zoom in the map.
	Tap to zoom out the map.
	Tap and select the area where you want to expand.

The left-most cell-site icon is activated when you import the cell-site information file.

To set measurement setup

Before starting the Route Map measurement, you need to set Spectrum measurements displayed on the quick access and display tab. See [“Configuring spectrum measurements” on page 9](#) for more information.

- 1 If required, connect a GPS receiver to your instrument for outdoor mapping. Indoor mapping does not necessarily need a GPS antenna.
- 2 Tap the Setup () icon on the side bar.
- 3 Tap **Map Config** to configure the map setting.
 - a Tap to switch the **Plot Point** to **GPS**, **Position**, or **Time**.
 - To collect data/plot points automatically as you move around in a vehicle or outside, select **GPS**.
 - To collect data/plot points manually in an indoor layout without a GNSS antenna, select **Position**.
 - To collect data/plot points based on time, select **Time**.
 - b Tap to switch **Plot Item DSS** to **RSRP**, **RSRQ**, **SINR**, or **SNR**.
 - c Tap to switch the **Screen Mode** between **Map** and **Full**.
 - With the **Map** setting, you can view only the collected points that can be seen within the boundary of the loaded map.
 - With the **Full** setting, you can view all the collected points of the route without the loaded map
- 4 Tap **Carrier Auto Search** and set the following:
 - a Tap **Center Frequency** and input a value using the on-screen keyboard.
 - b Tap the **Search** button.



NOTE

If searching is unavailable, the instrument displays a pop-up message saying that it fails to detect NR (SSB) frequency.

- c Once searched, tap the **Apply** button.



NOTE

If you know the LTE center frequency, the instrument automatically searches SSB frequency.

- 5 Tap to switch **Radio Config** and set **Duplex Type** (FDD/TDD), **DSS Type** (Co-channel), and **Technology** (LTE/NR) and other related parameters as below.
You can select Co-channel to find NR frequency based on the LTE operating frequency in co-channel and select Adjacent channel to search both LTE and NR frequency. Note that Adjacent channel will be available in the next release.

- When **LTE** is selected as **Technology**, do the following steps:
 - Select **Bandwidth** (MHz) from the following choices: **20**, **15**, **10**, or **5**.
 - Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
 - Select **Cyclic Prefix** between **Normal** and **Extended**. Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread
 - Select **PHICH Ng** between **Normal** and **Extended** and then to set the number of PHICH groups (Ng): 1/6, 1/2, 1, or 2. The PHICH group value/Ng is decided based on the number of PHICH groups per subframe. PHICH duration is a higher layer parameter configured either as Normal or Extended that says the demodulator how many symbols per subframe are used by PHICH.
 - **Normal**: There are 8 PHICH sequences in one PHICH group (4 symbols).
 - **Extended**: There are 4 PHICH sequences in one PHICH group (2 symbols)
 - When **NR** is selected as **Technology**, do the following steps:
 - Select sub-Carrier Spacing as 15 kHz (Case A). The standard for NR SCS is 15 kHz. The instrument supports 15 kHz of sub-carrier spacing.
- 6** Tap to switch **CFI** to **Manual** or **Auto**.
- **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually. The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 7** Tap **CFI** and input a value from 1 to 3 as desired using the on-screen keyboard.
- 8** Tap **SSB frequency** and input the value using the on-screen keyboard.
- 9** Tap **GSCN** and input the value from 2 to 26639 using the on-screen keyboard. If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that CellAdvisor 5G supports.



NOTE

Based on the GSCN input frequency, the SSB Frequency is automatically changed.

- 10** Tap **PCI** (Physical Cell ID) and select between **LTE PCI** and **NR PCI**.
- a** Tap to switch **LTE PCI Mode** to **Manual** or **Auto** and input a value from 0 to 503.

The **PCI** switches to **Manual**.

- b** Tap **NR PCI Mode** to **Manual** or **Auto** and input a value from 0 to 1007.

The **PCI** switches to **Manual**.



NOTE

You can set Auto to let the instrument detect the Physical Cell ID for the LTE/NR signal automatically and Manual to set the specific Physical Cell ID for the LTE/NR signal manually in order to speed up the synchronization with a BTS.

To set limit

You can set the thresholds for the two different color indicators, red and blue. The maximum value is the Limit for **Excellent**, and the minimum value is the Limit for **Poor**. See below to check the plot point color based on the Legend Color Table.

- 1 Tap the rectangle with value before color legend bar on the right panel.
- 2 Set a value for **Poor** (minimum value) using the on-screen keyboard.
- 3 Tap the rectangle with value after color legend bar on the right panel.
- 4 Set a value for **Excellent** (maximum value) using the on-screen keyboard.

Figure 80 shows a legend color table.




Figure 80 Legend color table

Red	Green	Blue	Color	
0	0	255		→ Poor
0	32	255		
0	64	255		
0	128	255		
0	255	255		
0	255	170		
0	255	85		
0	255	0		
85	255	0		
170	255	0		
255	255	0		
255	128	0		
255	64	0		
255	32	0		
255	0	0		→ Excellent

Logging data


To use any features related to maps, you need to download and install the maps on the instrument. The VIAVI JMapCreator will help you download maps. Make sure the JMapCreator application on your computer is connected to the instrument via LAN. You can send a map file with a single layer to the instrument directly by using the Send to EQP menu in JMapCreator. For more information on how to use the JMapCreator, see the *JMapCreator 2.0 User Guide*.

To log data

- 1 Follow **step 1 to 3** in Setting measure setup.
- 2 Tap the **Testing** () button on the right panel of the map to start plotting on the map. When you select a point on the map, a marker appears and the Information window appears on the right panel.
- 3 Tap the **Stop** () button to stop plotting.
- 4 Tap the **Pause** button () to pause plotting, then the GPS point cannot be plotted.
- 5 If you start test and select **Setup > Map Config > Plot Point > Position**, you can undo by tapping the **Testing** button.
- 6 If you select the **Stop** button, the Plot Stop pop-up window appears, then tap **Yes**.
- 7 Tap **Yes** when the Save pop-up window appears and the logging file to your USB.

Viewing the logging data

To view the logging data

- 1 Load the saved logging file using the **Load** () icon on the side bar. Make sure the file extension is .gomv.
- 2 If the **PCI** is set to **Auto**, the point on the map appears with a color representing the largest **S-SS-RSRP** value. When you select a point on the map, a marker appears and the Information window appears on the right panel.
- 3 Set the **PCI** to **Manual** and tap the **Select** button.
The Select PCI window appears.
- 4 Select PCI on the left and then the corresponding Beam Index appeared on the right.
- 5 Tap the **Apply** button.
The point color of the map changes to the corresponding SS-RSRP value, and if there is no detected Beam Index, the point will be hidden.

Importing cellsite DB

You can import the site DB by creating the 5G site information form.

To import cellsite DB

- 1 Create the 5G site information with an excel file as below.
- 2 Input the two mandatory fields: **Lat (DecDeg)** and **Long (DecDeg)**.
- 3 Input the **Azimuth** field if you want to check the direction of antenna.
- 4 Make sure to save the file as (Comma delimited) (*.csv).


- 5 Copy the file to the USB memory stick and insert it to the **USB A** or **USB B** port of the instrument.
 - 6 Tap the **Load** (📁) icon on the side bar.
 - 7 Import the saved file.
- Once the file is loaded, the following cellsite information appears with an icon.

Figure 81 shows an example of an importing cellsite DB.

Figure 81 Importing Cellsite DB

	Mandatory field to be input			Not mandatory field to be input	Antenna direction to be shown if input
	A	B	C	D	E
Mandatory row and title	1 Site Information Form	Version	1		
Site ID & example	2 ID	Lat(DecDe	Long(DecDe	Height	Azimuth
	3 HASRU130	29.73186	-95.3687	20	160
	4 HASRU131	29.73186	-95.3687	20	160
	5 HASRU140	29.73186	-95.3687	20	220
	6 HASRU141	29.73186	-95.3687	20	220
	7 HASRU150	29.72883	-95.3664	13	190
	8 HASRU151	29.72563	-95.3643	12.25	0

Figure 82 Route map measurement with site information screen



NOTE

If the Plot Point is set to Position, you can tap the estimated area by point. If you tap incorrectly, you can tap Undo icon on the map, and then it will delete the point you have tapped incorrectly.


Freq/Time/Power Variation

Frequency, time, and power variation shows the frequency, time, and power error trend based on the time elapsed.

After configuring the spectrum measurement in [“Configuring spectrum measurements” on page 9](#), you can set the measure setup to continue your measurement. The measurement settings can be saved and recalled as a file by selecting File Type as Setup and load the file onto the instrument using the **Save/Load** icons on the side bar.

Setting measure setup

To set measure set up

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Carrier Auto Search** and set the following:
 - a Tap **Center Frequency** and input a value using the on-screen keyboard.
 - b Tap the **Search** button.



NOTE

If searching is unavailable, the instrument displays a pop-up message saying that it fails to detect NR (SSB) frequency.

- c Once searched, tap the **Apply** button.



NOTE

If you know the LTE center frequency, the instrument automatically searches SSB frequency.

- 3 Tap to switch **Radio Config** and set **Duplex Type** (FDD/TDD), **DSS Type** (Co-channel), and **Technology** (LTE/NR) and other related parameters as below.
You can select Co-channel to find NR frequency based on the LTE operating frequency in co-channel and select Adjacent channel to search both LTE and NR frequency. Note that Adjacent channel will be available in the next release.

- When **LTE** is selected as **Technology**, do the following steps:
 - Select **Bandwidth** (MHz) from the following choices: **20**, **15**, **10**, or **5**.
 - Select **MIMO** between **2x2** and **4x4** to set the number of antenna ports. If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
 - Select **Cyclic Prefix** between **Normal** and **Extended**. Cyclic prefix works as a buffer region or guard interval to protect the OFDM signals from inter symbol interference.
 - **Normal**: Intended to be sufficient for the majority of scenarios
 - **Extended**: Intended for scenarios with particularly high delay spread
 - Select **PHICH Ng** between **Normal** and **Extended** and then to set the number of PHICH groups (Ng): 1/6, 1/2, 1, or 2. The PHICH group value/Ng is decided based on the number of PHICH groups per subframe. PHICH duration is a higher layer parameter configured either as Normal or Extended that says the demodulator how many symbols per subframe are used by PHICH.
 - **Normal**: There are 8 PHICH sequences in one PHICH group (4 symbols).
 - **Extended**: There are 4 PHICH sequences in one PHICH group (2 symbols)
- When **NR** is selected as **Technology**, do the following steps:
 - Select sub-Carrier Spacing as 15 kHz (Case A). The standard for NR SCS is 15 kHz. The instrument supports 15 kHz of sub-carrier spacing.
- 4 Tap **Antenna Port** to assign an antenna port number automatically or manually, and select from **Auto**, **Antenna 0**, **Antenna 1**, **Antenna 2**, or **Antenna 3**.
If the MIMO is set to 2x2, the antenna ports 2 and 3 are disabled.
- 5 Tap to switch **MIMO** to **4x4** or **2x2**.
- 6 Tap to switch **CFI** to **Manual** or **Auto**.
 - **Auto** lets the instrument set the number of OFDM symbols used for transmitting PDCCHs in a subframe.
 - **Manual** sets the number of OFDM symbols manually.
 - The set of OFDM symbols that can be used for PDCCH in a subframe is given by 0, 2, 3 or 4 in 1.4 MHz bandwidth and 1, 2 or 3 in other bandwidths.
- 7 Tap **CFI** and input a value from 1 to 3 as desired using the on-screen keyboard.
- 8 Tap **SSB frequency** and input the value using the on-screen keyboard.
- 9 Tap **GSCN** and input the value from 2 to 26639 using the on-screen keyboard. If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that CellAdvisor 5G supports.



NOTE

Based on the GSCN input frequency, the SSB Frequency is automatically changed.

- 10 Tap **PCI** (Physical Cell ID) and select between **LTE PCI** and **NR PCI**.
 - a Tap to switch **LTE PCI Mode** to **Manual** or **Auto** and input a value from 0 to 503.
The **PCI** switches to **Manual**.
 - b Tap **NR PCI Mode** to **Manual** or **Auto** and input a value from 0 to 1007.
The **PCI** switches to **Manual**.


➤ **NOTE**
You can set Auto to let the instrument detect the Physical Cell ID for the LTE/NR signal automatically and Manual to set the specific Physical Cell ID for the LTE/NR signal manually in order to speed up the synchronization with a BTS.

- 11 Tap **Menu > Display** and select Reset to refresh your measurement.

➤ **NOTE**
If you want to set the reference level and scale, tap Menu > Amp/Scale > Reference. You can set Reference Freq Error Offset, Scale Division (Freq Error), Reference Time Error Offset, Scale Division (Time Error), Reference Level, and Scale Division (Power) on demand using the on-screen keyboard. You can also select the unit on the keyboard.

Figure 83 shows an example of 5G DSS Freq/Time/Power Variation by offset.


Figure 83 5G DSS Freq/Time/Power Variation by offset



➤ **NOTE**
You can tap the Distance box and input the value that you want to compensate for distance. When distance is entered, the time will show the value with distance correction. Make sure the default value for Distance is 0.

Figure 84 shows an example of 5G DSS Freq/Time/Power Variation by power.

Figure 84 5G DSS Freq/Time/Power Variation by power



Using RFoCIPRI Analyzer

This chapter describes how to use the RFoCIPRI Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 178](#)
- [“Connecting cables” on page 179](#)
- [“Selecting network technology” on page 186](#)
- [“Configuring Rx parameters” on page 186](#)
- [“Setting measure setup” on page 188](#)
- [“Conducting spectrogram” on page 191](#)
- [“Using the spectrum replayer” on page 192](#)

Introduction



NOTE

The RFoCIPRI Analyzer is only available on the SPA06MA-O.

Cell sites today have a distributed architecture of the radio that consists of the radio equipment control (REC) or base band unit (BBU) installed at the bottom of the tower and the radio equipment (RE) or the remote radio head (RRH) installed at the top of the tower. These two elements communicate with each other via the Common Public Radio Interface (CPRI) protocol; over fiber links.

This distributed architecture provides the benefit of replacing coax-based feeders with fiber-based feeders, significantly reducing the problems of signal loss and reflections. However, as all the RF interfaces reside on the RRH, and RY maintenance or troubleshooting requires climbing to the top of the tower to access the RRH, increasing operational cost and unnecessary safety issues.

The RFoCPRI Analyzer allows you to perform RF maintenance and troubleshooting activities on the ground using the fiber interfaces at the BBU, significantly reducing maintenance time and operational expenses. You can verify the CPRI control signals and extracts the IQ data transmitted between the BBU and RRH to monitor and analyze the uplink interfaces and the downlink signals.

You can also monitor current and historic CPRI alarm status for LOS and LOF displayed on the interface measurement screen.

RFoCPRI testing provides the following measurements:

- Spectrum Analysis
 - Spectrum
 - Spectrogram
 - Spectrum Replayer

Selecting mode and measure

The following procedure describes how to start measurement.

To start measurement

- 1 Tap **RFoCPRI** on the **MODE** panel.

- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Spectrum**
 - **Spectrum Analysis > Spectrogram**
 - **Spectrum Analysis > Spectrum Replayer**



NOTE


If you have **RF Source** as an option in your Cable and Antenna Analyzer (CAA), you can choose **RF Source On** or **Off** in the Setup menu after tapping **CAA RF Power On**.

Connecting cables

You can connect cables with or without a tap, as shown in [Figure 85](#). If you have connected cables directly from RRH and BBU without using the nTap, you must turn on the through mode (Thru) in the CPRI parameter settings.

An SFP/SFP+ transceiver that is connected to your ONA-800 must be compatible with your DUT, and you must have your module information such as line rate, wavelength, and mode (MM or SM) handy.


Figure 85 Connection diagram for interface analysis



Selecting port

RFoCIPRI. Each port can generate up to four different waveforms, both selectively and simultaneously. You can select the port to use for the measurement in any measurement mode of RF-CPRI mode.

To select the port

- 1 Tap the **Setup** () icon on the side bar of each measurement mode and choose **Rx Settings** or **Port Configuration**.
- 2 Select **Port 1** or **Port 2** in **Select Port**.

Configuring test parameters

Configuration of test parameters described in this section is used in the RFoCIPRI mode including spectrum, spectrogram, and spectrum replayer measurements.

Setting frequency

You can set the frequency with either frequency or channel number. If a frequency to be set matches to the frequency corresponding to the selected channel standard, the instrument calculates its channel number and updates the screen with it automatically.

To set the frequency with center frequency

- 1 Tap **Menu > Frequency**.
- 2 Tap **Center Frequency** and enter a value using the on-screen keyboard.
- 3 Select a unit from **GHz**, **MHz**, **kHz**, or **Hz** and tap **Apply**.

To set the frequency with channel number

- 1 Tap **Menu > Channel**.
- 2 Select the standard channel:
 - a Tap **Channel Standard**. The standard channel window appears.
 - b Tap the band to be measured.
- 3 Tap **Link** between **Uplink** and **Downlink**.
- 4 Tap **Channel Number**.
- 5 Enter a value by using the on-screen keyboard and tap **Apply**.

The ONA-800 automatically displays the corresponding frequency value for the selected channel number.

Setting reference level

You can set the reference level automatically or manually to optimize the display of the traces measured.

To automatically set the reference level

- 1 Tap **Menu > Amp/Scale**.
- 2 Tap **Auto Scale**.
Each time you tap, the Y-axis scale changes to be optimized with some margin.

To manually set the reference level

- 1 Tap **Menu > Amp/Scale**.
- 2 Set the maximum reference value on the Y-axis:
 - a Tap **Reference Level**.
 - b Enter a value using the on-screen keyboard and tap **Apply**.

To change the scale unit (optional)

- 1 Select **Menu > Amp/Scale > Scale Unit**.
- 2 Select the unit of the display scale from: **dBm**, **dBV**, **dBmV**, **dBuV**, **V**, or **W**.
The scale unit on the screen changes accordingly.

Setting scale per division

You can use the Scale Division feature to change the scale per division, representing the value of one division on the horizontal scale. The default setting is 10 dB per division and the maximum value can be set up to 20 dB.

To set scale per division.

- 1 Tap **Menu > Amp/Scale > Scale Division**.
- 2 Enter a value between 1 and 20 by using the on-screen keyboard and tap **Apply**.

Setting external offset

You can turn the External Offset on and manually set the external offset value. An offset consists of a cable loss and a user offset, and the measurement result shows the value reflecting both offset values. When the external offset value is set at 40 dB, the measurement result compensates 40 dB.

- 1 Tap **External Offset Mode to On** under **Amp/Scale**.
- 2 Tap **External Offset**.
- 3 Enter a value by using the on-screen keyboard and tap **Apply**.
- 4 To turn the external offset off, tap **External Offset Mode to Off**.

Enabling auto leveling

It is normal to see higher levels of RSSI in CPRI spectrum than you have seen in RF spectrum, as the digital signal has a different gain level from RF's. If you use the Auto Leveling feature and enter the Noise Figure (NF) for the system to be tested, the instrument calculates an offset that compensates the digital gain of RRH and applies it to the spectrum automatically to displace the level of spectrum to a known RSSI power even though its accuracy cannot be guaranteed. Offset calculation for Auto Leveling is based on the following:

$$\text{Auto Level offset} = (\text{Noise Floor of RFoCPRI}) - (\text{Ideal Noise Floor of RRH})$$

$$\text{where (Idea Noise Floor)} = N.F \text{ (RRH)} + \text{Thermal Noise} + 10\log \text{ (RBW)}$$

To enable auto leveling



NOTE

Having the noise figure factored in the offset calculation for Auto Leveling will enable you to view the CPRI spectrum closer to what you view in the RF spectrum. If you do not know the noise figure, you can skip this noise figure setting.

- 1 Tap **Menu > Amp/Scale > Auto leveling**.
A calculated level of offset without NF is applied as the external offset and the user input field is activated for entry of the noise figure value.
- 2 Enter a noise figure value using the on-screen keyboard.
- 3 Tap **Apply** to complete the entry.
A new external value offset value appears in the **External Offset** menu box.
- 4 Tap **External Offset** to **Off**. **Auto Leveling** is turned off.

[Figure 86](#) and [Figure 87](#) show an example of before and after Auto Leveling is enabled.

Figure 86 Before enabling Auto Leveling





Figure 87 After enabling Auto Leveling



Setting RBW

You can set the RBW and VBW in the Spectrum and Spectrogram modes. The RBW range is limited as per the bandwidth of the signal under test.

- 1 Tap **Menu > BW/AVG**.
- 2 Tap **RBW** to set the resolution bandwidth.

- 3 Choose one of the following options: **100 kHz**, **30 kHz**, **10 kHz**, or **7.5 kHz**.
 - For signal bandwidths 1.4 MHz and 3 MHz: RBW from 1 kHz to 30 kHz
 - For signal bandwidths 5 MHz, 10 MHz, 15 MHz, and 20 MHz: RBW from 1 kHz to 100 kHz
- 4 Tap **VBW** to **set** the video bandwidth and choose one of the following options: **100 kHz**, **30 kHz**, **10 kHz** or **7.5 kHz**.

Setting average

You can set the number of measurements to be averaged for the trace presentation in the Spectrum and Spectrogram modes. A maximum of 100 times of averaging can be set. When the averaging reaches your setting, a new measurement value replaces the measurement value in sequence from the earliest.

To set average

- 1 Tap **Menu > Sweep**.
- 2 Select the desired sweep run mode by tapping the **Sweep Mode** between **Single** and **Continue**
 - **Single**: The instrument performs a single sweep and waits for further entries.
 - **Continue** (default): The instrument is continually measuring and updating results.
- 3 *Optional*: In Single Mode, tap **Sweep Once** to get a new measurement.

Setting sweep mode

Different sweep settings are available for RFoCIPRI Spectrum and Spectrogram measurement modes for better measurement, including the sweep run mode (**Single**, **Continue**).

To set sweep mode

- 1 Tap **Menu > Sweep**.
- 2 Select the desired sweep run by tapping the **Sweep Mode** between **Single** and **Continue**:
 - **Single**: The instrument performs a single sweep and waits for further entries.
 - **Continue** (default): The Instrument is continuously measuring and updating the result.
- 3 *Optional*: In **Single** mode, tap **Sweep Once** to get a new measurement.

Setting trace

You can display up to six traces on the measurement chart simultaneously.

To set trace

- 1 Tap **Menu > Trace**.
- 2 Tap **Select Trace** and select the trace number: **Trace 1**, **Trace 2**, **Trace 3**, **Trace 4**, **Trace 5**, or **Trace 6**.
- 3 Complete one of the following by tapping Trace Type:
 - **Clear Write**: Clear current data and display with new measurements
 - **Max**: Display the input signal's maximum response only (unlimited or for a certain amount of time)
 - **Min**: Display the input signal's minimum response only (unlimited or for a certain amount of time)
 - **Capture**: Capture the selected trace and compare traces
 - **Load**: Load a saved trace
 - **Trace View to Off**: Hide the displayed trace
 - **Trace Set Max/Min**: To set Trace 1, Trace 2, and Trace 3 to Clear Write, Max, and Min (only available in spectrum mode)
- 4 To remove all the traces and initialize the trace settings, tap **Trace Clear All**.



NOTE

For the **Max** and **Min**, your instrument compares newly acquired data with the active trace and displays larger maximum values or smaller minimum values on the screen.

- 5 Tap **Detectors** and select the detection option:
 - **Normal**: Displays "Random noise better than the peak without missing signals"
 - **Peak**: Displays "The highest value in each data point."
 - **RMS**: Displays "The root mean squared average power across the spectrum."
 - **Negative Peak**: Displays "The lowest value in each data point."
 - **Sample**: Displays "The center value in each data point."
- 6 *Optional*: Select **Trace Info**, and then select the trace number to view the trace's parameter setting information stored at the time of measurement, or **None** to hide the information display.




NOTE

To be able to load a trace, the trace to be overlaid must be saved in the same measurement mode and frequency setting as the current measurement.

Selecting network technology

Before starting the interference analysis, you need to choose a network technology to analyze.

To select network technology


- 1 Tap the **Setup** () icon on the side bar of each measurement mode.
- 2 Tap **Rx Settings > Technology** and select a desired network technology from the menu bar: **LTE** (default), **WCDMA**

Depending on the network technology you selected, the settings on the Rx Parameter menu change accordingly.

Configuring Rx parameters

As each network technology requires different Rx parameter settings, you need to configure the Rx parameters for the network technology you selected.

To configure the Rx parameters for LTE, WCDMA

- 1 Tap the Setup () icon on the side bar of each measurement mode.
- 2 Tap **Rx Settings**.
- 3 Set the antenna per carrier group by tapping one of the **Map Position (AxC 0 to AxC7)** boxes and enter a value using the on-screen keyboard.



NOTE

Maximum number of the AxC Group is determined by the factors of link rate, sample width, oversampling, and signal bandwidth.

- 4 To set the I and Q sample widths, tap **IQ Sample Width** and enter a value between 4 and 20 by using the on-screen keyboard.



NOTE

According to the CPRI specification, the IQ sample width shall be between 4 and 20 bits for I and Q in the uplink and between 8 and 20 bits in the downlink.

- 5 Tap **Stuffing Bit** and enter a value between 0 and 20, using the on-screen keyboard.

- 6 To set the first bit position of each **AxC Container** in the IQ data block of a basic frame, complete the following steps:
 - a Tap **Map Position**.
 - b Select the **AxC Container** number you want to set from: **AxC 0**, **AxC 1**, **AxC 2**, **AxC 3**, **AxC 4**, **AxC 5**, **AxC 6**, or **AxC 7**. Not all of these are activated, depending on the bandwidth setting of the network technology you selected.
 - c Enter a value by using the on-screen keyboard.



NOTE

The Antenna-Carrier (AxC) is the amount of digital baseband (IQ) U-plane data necessary for either reception or transmission of one carrier at one independent antenna element. The number of required AxC Container for a basic frame are two AxCs for 5 MHz, four AxCs for 10 MHz, and eight AxCs for 20 MHz.

- 7 Set the bandwidth of the downlink signal:
 - a Tap **Bandwidth**
 - b Select the bandwidth among **3 MHz**, **5 MHz**, **10 MHz (3 AxC)**, **10 MHz (4 AxC)**, **15 MHz (4 AxC)**, **15 MHz (5 AxC)**, **15 MHz (6 AxC)**, **20 MHz (5 AxC)**, or **20 MHz (6 AxC)**, **20 MHz (7 AxC)**, **20 MHz (8 AxC)**. The RBW range changes depending on the bandwidth you selected. Required number of AxC containers may vary depending on the bandwidth you selected.
- 8 To use the pre-configured settings for **NEM**, select one of: **None** (no pre-configuration), **Alcatel-Lucent (UL/DL)**, **Samsung (UL/DL)**, **Huawei > Huawei (UL)**, or **Huawei (DL)** and **ZTE (UL/DL)**.



NOTE

If you have selected a NEM, the instrument sets the Map Position and other related settings automatically based on the selected NEM and you cannot edit the map position setting. The pre-configured information may be subject to changes at any times by NEMs.

- 9 To choose **Uplink** or **Downlink** and **Band** to be tested, tap More and select your preferred band after tapping **Channel Standard**.

Figure shows an example of Rx Settings with the RFoCIPRI Analyzer. Figure shows an example of Rx settings for AxC mode.

- 2 To set the CPRI line bit rate, tap **Link Rate** under **Port Configuration** and select the CPRI link rate option from **614.4 Mbps**, **1228.8 Mbps**, **2457.6 Mbps**, **3072.0 Mbps**, **4915.2 Mbps**, **6144.0 Mbps**, **9830.4 Mbps** or **10137.6 Mbps**.



NOTE

It is important that you set the link rate correctly to avoid any misleading LOS and LOF alarms displayed on the screen.

- 3 To turn **Through Mode** on or off, tap **On** or **Off** in **Thru** line.
- 4 To set the **Tx Clock**, tap **Recovered** (default) in the **Clock** box.
- 5 Tap **Port Type** to **Slave** (default).


Figure 90 Port Configuration with RFoCPRI Analyzer

Conducting spectrum measurement


After setting test parameters as described in [“Configuring test parameters” on page 180](#), you can perform spectrum measurements with an audible indicator. You can also turn on the interference ID.

[Figure 91](#) shows an example of an RFoCPRI spectrum measurement.

Figure 91 RFoCPRI spectrum measurement



To perform spectrum measurements

- 1 Tap the **Setup** () icon on the side bar of **Spectrum Measurement** mode.
- 2 Set the sound indicator:
 - a Tap **Sound Indicator > Alarm Reference**, then choose either **Marker** or **Line**.
 - **Marker**: Sets the active marker position as the alarm reference if you have enabled a marker on the spectrum.
 - **Line**: Makes the reference line as the alarm reference.
 - b If you have set the alarm reference to **Line**, tap the **Reference line** to set a threshold for an alarm.
 - c Enter a value by tapping + or -, and tap **Apply**.
 - d Tap **Sound** either **On** or **Off** to turn on/off the alarm sound.
 - e *Optional*: Tap **Volume** to adjust the alarm sound volume.



NOTE

The Sound Indicator is used to identify interfering signals with an alarm sound. This is useful for locating interferer sources with a directional antenna.

- 3 Set the interference ID:
 - a Tap **Interference ID** and **Threshold**.
 - b Enter a value and tap the **dBm**.
 - c Tap **Interference ID** and choose either **On** or **Off** to turn the Interference ID on or off.



NOTE


The Interference ID automatically classifies interfering signals over a designated spectrum and displays a list of possible signal types corresponding to the selected signal.

- 4 To clear the current (C) and history (H) status of CPRI alarms on LOS and LOF and start a new monitoring, tap **Setup > Port Configuration > History Reset**.
- 5 *Optional:* Tap the **Save** icon on the side bar, and then select the save option from the choices available for your measurement mode.

Conducting spectrogram

The Spectrogram is particularly useful when attempting to identify periodic or intermittent signals as it captures spectrum activity over time and uses various color to differentiate spectrum power levels. When the directional antenna is used to receive the signal, you will see a change in the amplitude of the tracked signal as you change the location of the antenna and see a change in the Spectrogram colors. The source of the signal is located in the direction that results in the highest signal strength.

To conduct spectrogram

- 1 Tap the **Setup** () icon on the side bar of **Spectrogram Measure** mode.
- 2 Tap **Time Interval** and enter a value by using the on-screen keyboard to set the amount of time between each trace measurement.
- 3 Set the time cursor on a specific trace position:
 - a Tap Time Cursor to On
 - b Tap Position to enter a value. You can also use the move bar (up and down arrows) in the lower left screen to move the time cursor.
 - c To turn the time cursor off, tap **Time Cursor** to **Off**.



NOTE

Enabling the Time Cursor puts the measurement on hold, allowing you to make post-processing analysis for each measurement over time using the time cursor.

- 4 Tap **Reset/Restart** to start a new measurement.

- 5 Tap **Setup > Port Configuration > History Reset** to clear current (C) and history (H) status of CPRI alarms on LOS and LOF and start a new monitoring.
- 6 *Optional:* Tap the **Save** icon on the side bar and select a desired save option for your measurement mode.

Using the spectrum replayer

The Spectrum Replayer allows you to retrieve and replay recorded spectrum analyzer traces in interference analysis mode. These traces can be played back in the spectrogram or RSSI. You can configure the limit line to create failure points when signals exceed it. The failure points are clearly displayed on the trace timeline for quick access during playback.

Figure 92 shows an example of the RFoCPRI spectrum replay.

Figure 92 RFoCPRI spectrum replay



To replay a spectrum

- 1 Select a file to be loaded, and then tap **Load**. The measure setup menu appears below on the screen.
- 2 Tap **FWD** or **REV** to change play direction to forward or reverse.
- 3 Tap the left or right arrow of Speed to select the speed option: **X1**, **X2**, **X3**, or **X4**.
- 4 Tap **Play** to start playing.
- 5 Tap **Pause** to pause or stop playing data.
- 6 To move to a particular failure position directly and play from there, tap **Index Fail** and enter a value by using the on-screen keyboard.

- 7 *Optional:* Tap **Setup > Time Cursor On/Off** to display or dismiss the time cursor on the screen. This key becomes activated when you play logged data in the Spectrogram mode.



NOTE

If you connect a USB drive, do not remove it while playing to prevent freezing the USB port, which will require you to restart the instrument to get a USB drive recognized again.

Setting display

You can select the display option to view data in a different mode.

To set display

- Select the display option from Spectrum or Spectrogram in the lower right screen.

Using EMF Analyzer

This chapter describes how to use the EMF Analyzer. Topics covered in this chapter include:

- [“Introduction” on page 196](#)
- [“Selecting mode and measure” on page 198](#)
- [“Conducting spectrum measurement” on page 198](#)
- [“Conducting signal measurement” on page 203](#)

Introduction

Base stations emit electro-magnetic fields (EMF) of high frequency, which varies between wireless technologies and countries. As personal exposure to high frequency fields from base stations can provoke health effect, the International Commission on Non-Ionizing Radiation Protection (ICNIRP) has provided general guidelines on limitations regarding high frequency exposure. Using the EMF Analyzer in JD700B series with an isotropic antenna connected, you can now measure the level of EMF onsite in the field in order to verify if the level of emission from of your base station is compliant with the guidelines.

The EMF Analyzer can perform the following measurement and analysis:

- Spectrum Analysis
 - Spectrum
- Signal Analysis
 - 5G NR Beam Analysis

Connecting antenna

In the EMF Analyzer mode, connecting an isotropic antenna (omni antenna) or a log-periodic antenna (yagi antenna) is mandatory. Using these antennas, you can make three-dimensional measurements.

To connect an isotropic antenna

- 1 Connect the **RF Type-N** connector of the isotropic antenna to the **RF In port** of the instrument.
- 2 Connect the **USB plug** of the isotropic antenna to the **USB Host port** of the instrument. The device icon appears in the system status bar on the screen.

[Figure 93](#) shows an example of an isotropic antenna connection.

Figure 93 Connecting an isotropic antenna



To connect a log-periodic antenna

- 1 Mount a broadband antenna to your AntennaAdvisor Handle.
- 2 Connect the **RF Type-N Jack** of the handle to the **RF In port** of the instrument.
- 3 Connect the **GNSS SMA** jack of the handle to the **GNSS port** of the instrument. The GNSS status indicator appears on the instrument screen.
- 4 Connect the **USB plug** of the handle to the **USB Host port** of the instrument. The device icon appears in the system status bar on the screen.




NOTE

The AntennaAdvisor Handle is an optional item. It is recommended that you use a log periodic antenna with AntennaAdvisor handle to search more exact directional information. You can use a log periodic antenna or Omni antenna alone as well.

Figure 94 shows an example of a log-periodic antenna connection.

Figure 94 Connecting a log-periodic antenna



Selecting mode and measure

The following procedure describes how to start measurement.

To start measurement

- 1 Tap **EMF Analyzer** on the **MODE** panel.
- 2 Tap any measurement mode from the following choices:
 - **Spectrum Analysis > Spectrum**
 - **Signal Analysis > 5G NR Beam Analysis**


Conducting spectrum measurement

The following sections describe how to conduct spectrum analysis.

Spectrum

After setting test parameters as described in [“Configuring spectrum measurements” on page 9](#), you can start your EMF measurements.

To set measure setup



- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Test Configuration**.
 - a Tap to switch **Auto Range** to **On** or **Off**.
When you set Auto Range On, the instrument scans to-be-measured bandwidth for EMF in advance and sets appropriate Attenuation and Preamp based on the different received signal level for the choice of axis.
 - b Tap **Dwell Time** to specify the amount of measurement time that you want the instrument to stay for on each axis and input the value from 1 to 60 (second) using the on-screen keyboard.
 - c Tap **Measurement Time** to specify the amount of measurement time that you want the instrument to stay for on all three axes in order to display current and accumulated EMF power and set this up to 60 minutes using the on-screen keyboard.



NOTE

If you set the measurement time, the count which means the number of EMF measurements on the right panel of the measurement screen is changed corresponding to the measurement time you have set.

- 3 Tap to switch **Axis** to **Manual** or **Auto**.
If you set it to **Manual**, Axis setting is available and if you set it to **Auto**, Axis setting is unavailable.
 - **Manual**: When using isotropic EMF antenna, you can manually set x, y, and z axis.
 - **Auto**: Each axis of antenna is automatically changed and measured.
- 4 Tap **Axis** and select from: **X**, **Y**, or **Z**.
- 5 Tap **Move to RtSA** to view the real-time spectrum measurement mode.

- 6 Tap **Antenna List EMF** and select the required antenna from the pop-up window. Based on the antenna list you selected, you need to check the Axis mode and do the following:
 - a When selecting Omni antenna and Axis to Auto, the Current on the measurement screen indicates as x, y, or z automatically and the Isotropic EMF Power is measured.
 - b When selecting Yagi antenna and Axis to Auto, the Current on the measurement screen indicates YAGI and the EMF Power is measured.
 - c When selecting Omni antenna and Axis to Manual, the Current on the measurement screen indicates as your choice (x, y, or z) and the EMF Power is measured.
- 7 On the right panel of the screen, do the following steps:
 - a Tap the **Testing** () button to start the measurement.
The instrument displays measurement results on the screen.
 - b Tap the **Hold** icon on the side bar to hold the display.
 - c Tap the **Hold** icon again to release the display.
 - d Tap the **Stop** () button to stop the measurement.
The alert message pops up to confirm whether you want to stop now or not.
 - e Tap **Spectrum** to check Isotropic EMF Power and Accumulated Isotropic EMF Power.

The Isotropic EMF Power is RMS average power measured with three axes for the specified dwell time for the axis while the Accumulated Isotropic EMF Power is the average, maximum, and minimum power taken from the counts of measurements.
 - f Tap **Integrated** to check Integrated Power, Integrated BW, and Integrated Isotropic EMF Power.

This directs you to channel power of the current displayed signal and the measurement screen also changes.

To set trace

- 1 Tap **Menu > Trace** in the side bar.
- 2 Tap **Select Trace** from 1 to 4.
 - **T1**: Maximum trace
 - **T2**: Minimum trace
 - **T3**: Isotropic EMF trace
 - **T4**: Accumulated Isotropic EMF Trace
- 3 Tap to switch **Trace View** to **On** or **Off**.
If you set the Trace from 1 to 4 to off, the trace information in Top Info will indicate it as F (false).

- 4 Tap to switch **Detectors** to **RMS** or **Peak**.
 - a Tap **RMS** to display 'The root mean squared average power across the spectrum'.
 - b Tap **Peak** to display 'The highest value in each data point'.
- 5 Tap **Trace Clear All** to clear Min/Max/Isotropic EMF/Accumulated Isotropic EMF traces.



NOTE

Trace Clear All resets traces you have set and it also affects overall measurement (Max, Min, etc...) and measurement result. Therefore, you need to be cautious when using this function.

To set limit

- 1 Tap **Menu > Limit** in the side bar.
- 2 Tap **Display Line**, and then enter a value that you want to set as a reference. The unit will vary depending on your selection of the unit in the Units setting in Amp/Scale.

You can also scroll up and down the purple bar on the measurement screen.
- 3 Tap to switch **Display Line Mode** to **On** or **Off**.

If you set it to On, the display line will appear with the purple bar on the measurement screen and set it to Off, the display line will disappear with the purple bar on the measurement screen.
- 4 Tap to switch **Standard Line Mode** to **On** to display the standard line on the screen or **Off** to hide the standard line on the screen.
- 5 Tap **Standard Line** and select from the following options:

Standard Line is displayed on the screen based on the pre-defined standard. If you select Occupational or General Public, the Standard Line is automatically displayed with automatically calculated value defined in the ICNIRP guideline. Make sure you change the Scale Unit to V/m in this case to follow the guideline.

- a Tap **Occupational** and **Apply** if you are under impact on EMF power for an occupational purpose.
- b Tap **General Public** and **Apply** if you are under impact on EMF power as general public.
- c Tap **Custom Limit** and then tap the **Configuration** icon if you want to customize setting and measure EMF power based on your need.
 - A **Standard** window appears.
 - Tap **Lower Frequency** and input a desired value using the on-screen keyboard.
 - Tap **Upper Frequency** and input a desired value using the on-screen keyboard.
 - Tap **Value for Frequency Range** and input a desired value using the on-screen keyboard.
 - Tap **Formula** and select from the following choices: f^n , $1/f^n$, **NA**
 - Tap **Exponent Value** and input a desired value using the on-screen keyboard.
 - Tap the **Save** button if you want to save the setting.
 - *Optional.* Tap the **Add** button to add Custom Limit.
 - *Optional.* Tap the **Delete** button to delete the defined Custom Limit.



NOTE

If you set Formula to f^n or $1/f^n$, you can define the limit line as frequency of function. If you set it to NA, you can define the limit line as a constant.

Figure 95 shows an example of EMF spectrum measurement.

Figure 95 EMF spectrum measurement





Figure 96 shows an example of integrated EMF power measurement.

Figure 96 Integrated EMF power (channel power) measurement



Conducting signal measurement

The following sections describe how to conduct signal analysis.


5G NR beam analysis

5G NR beam analysis in EMF Analyzer shows the strength of RSRP for each carrier with the trend of Extrapolated Isotropic EMF Power, Extrapolated Accumulated EMF Power (Average, Maximum, and Minimum).

Setting measure setup

After configuring the spectrum measurement in “Configuring spectrum measurements” on page 9, you can set the measure setup to continue your measurement.

To set measure setup

- 1 Tap the **Setup** () icon in the side bar.
- 2 Tap **Bandwidth/SSB SCS** and select the Setting in the pop-up window based on your need. SSB is abbreviation for Synchronization Signal Block or SS Block and it refers to Synchronization PBCH block since the synchronization signal and PBCH channel are packed as a single block that always moves together. SSB should be detected first in 5G NR frame. See Table 39 below for the setting criteria based on the operating frequency.

- 3 Tap **Sync Raster Offset** to set the sync raster resolution to 180 kHz (FR1) or to 720 kHz (FR2) for carrier frequency center using the on-screen keyboard. See [Table 40](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 4 Tap **Sync SCS Offset** to fine-tune the offset using the SCS. See [Table 41](#) below for the sync raster offset range per SSB SCS and sync raster resolution.
- 5 Tap **SSB Center Frequency** and input the value using the on-screen keyboard.
- 6 Tap **L** to set the maximum number of SS-PBCH blocks within a single SS burst set (A set of SS being transmitted in 5 ms window of SS transmission) among 4, 8 and 64. Refer to the selection criteria based on the table in **Step 2**.
- 7 Tap **SSB Auto Search** and do the following steps:
 - a Tap **Search Type** and select from the following three options:
 - **Full-Raster**: You can search in sync raster offset unit that SPA06MA-O defines (FR1: 180 kHz, FR2: 720 kHz).
 - **Full-Raster & SCS**: You can search in SCS unit for the selected SSB (FR1: 15K or 30K, FR2: 120K or 240K).
 - **GSCN**: If you need to search SSB based on ARFCN raster, it would take too long time since ARFCN raster is very narrow. Therefore, it is recommended that you define a SSB searching frequency in wider steps. This is the usage/purpose of GSCN. You can search the frequency corresponding to GSCN in maximum 100 MHz bandwidth of ARFCN that SPA06MA-O supports.
 - b Tap **SSB Auto Search Mode** between **Manual** and **Auto**.
 - **Manual**: You can search SSB automatically with current Preamp and Attenuation setting.
 - **Auto**: You can search SSB and change Preamp and Attenuation automatically based on input signal level.
 - c Tap to switch **SSB Auto Search** to **Stop** to set the SSB periodicity based on the base station or to **Start** to search SCS, type, and the number of SSB automatically. Once **Start** is selected, the progress bar appears. If it fails to perform the auto search, a fail message appears and the SSB switches to **Manual**.
- 8 Tap **SSB Periodicity** and select the options from **5 ms**, **10 ms**, **20 ms**, **40 ms**, **80 ms**, **160 ms**. The SS burst period (SSB periodicity) is defined by each base station and network configurable. 20 ms is the default for the initial cell selection.
- 9 Tap to switch **PCI (Physical Cell ID)** to **Manual** or **Auto**.
- 10 Tap **PCI** and input a value from 0 to 1007 using the on-screen keyboard. The PCI switches to **Manual**.



NOTE

You can go to **Menu > Frequency > Center Frequency List** to add frequently used center frequency using the **Add** button in the Frequency List or to delete the selected frequency using the **Delete** button. You can also apply one of the default frequencies in the Frequency List by tapping the **Apply** button.

11 Tap Test Configuration.

- a** Tap to switch **Auto Range** to **On** or **Off**.
If you want to set Auto Scale and Preamplifier to Auto. You can set it to On.
- b** Tap **Dwell Time** to specify the amount of measurement time that you want the instrument to stay for on each axis and input the value from 1 to 60 (second) using the on-screen keyboard.
- c** Tap **Measurement Time** to specify the amount of measurement time that you want the instrument to stay for on all three axes in order to display current and accumulated EMF power and set this up to 60 minutes using the on-screen keyboard.



NOTE

If you set the measurement time, the count which means the number of EMF measurements on the right panel of the measurement screen is changed corresponding to the measurement time you have set.

12 Tap to switch Axis to Manual or Auto.

If you set it to **Manual**, Axis setting is available and if you set it to **Auto**, Axis setting is unavailable.

- **Manual:** When using isotropic EMF antenna, you can manually set x, y, and z axis.
- **Auto:** Each axis of antenna is automatically changed and measured.

13 Tap Axis and select from: X, Y, or Z.

14 Tap UL and input the value using the on-screen keyboard.

15 Tap DL and input the value using the on-screen keyboard.

16 Tap Move to RtSA to view the real-time spectrum measurement mode.


17 Tap Antenna List EMF and select the required antenna from the pop-up window. Based on the antenna list you selected, you need to check the EMF mode and do the following:

- a** When selecting Omni antenna and Axis to Auto, the Current on the measurement screen indicates as x, y, or z automatically and the Isotropic EMF Power is measured.
- b** When selecting Yagi antenna and Axis to Auto, the Current on the measurement screen indicates YAGI and the EMF Power is measured.
- c** When selecting Omni antenna and Axis to Manual, the Current on the measurement screen indicates as your choice (x, y, or z) and the EMF Power is measured.

18 On the right panel of the screen, do the following steps:

- a** Tap the **Testing** () button to start the measurement.

The instrument displays measurement results on the screen.

- b** Tap the **Hold** icon on the side bar to hold the display.
- c** Tap the **Hold** icon again to release the display.
- d** Tap the **Stop** () button to stop the measurement.

The alert message pops up to confirm whether you want to stop now or not.

Table 39 Setup per operating frequency

Operating frequency	L	Case	SCS	Slots in a burst period
< 3 GHz (FR1)	4	A {2,8} +14*n	15 kHz	5 (1 ms)
< 3 GHz (FR1)	4	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
< 3 GHz (FR1)	4	C {2,8} +14*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	A {2,8} +14*n	15 kHz	5 (1 ms)
3 to 6 GHz (FR1)	8	B {4,8,16,20} +28*n	30 kHz	10 (0.5 ms)
3 to 6 GHz (FR1)	8	C {2,8} +14*n	30 kHz	10 (0.5 ms)
> 6 GHz (FR2)	64	D {4,8,16,20} +28*n	120 kHz	40 (0.125 ms)
> 6 GHz (FR2)	64	E {8,12,16,20,32,36,40,44} +56*n	240 kHz	80 (62.5 ms)

Table 40 Sync raster offset range per SSB SCS and sync raster resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center frequency
15	180	0 to 250	125
30	180	0 to 506	253
120	720	0 to 92	46
240	720	0 to 48	24

Table 41 Sync SCS offset range per SSB SCS and sync SCS resolution

SSB SCS (kHz)	Sync Raster Resolution (kHz)	Sync Raster Offset Range	SSB Frequency = Center Frequency
15	15	0 to 11	0
30	30	0 to 5	0
120	120	0 to 5	0
240	240	0 to 2	0

To set limit

- 1 Tap **Menu > Limit** in the side bar.
- 2 Tap **Standard Line** and select from the following options:

Standard Line is displayed on the screen based on the pre-defined standard. If you select Occupational or General Public, the Standard Line is automatically displayed with automatically calculated value defined in the ICNIRP guideline. Make sure you change the Scale Unit to V/m in this case to follow the guideline.

 - a Tap **Occupational** and **Apply** if you are under impact on EMF power for an occupational purpose.
 - b Tap **General Public** and **Apply** if you are under impact on EMF power as general public.
 - c Tap **Custom Limit** and then tap the **Configuration** icon if you want to customize setting and measure EMF power based on your need.
 - A **Standard** window appears.
 - Tap **Lower Frequency** and input a desired value using the on-screen keyboard.
 - Tap **Upper Frequency** and input a desired value using the on-screen keyboard.
 - Tap **Value for Frequency Range** and input a desired value using the on-screen keyboard.
 - Tap **Formula** and select from the following choices: f^n , $1/f^n$, **NA**
 - Tap **Exponent Value** and input a desired value using the on-screen keyboard.
 - Tap the **Save** button if you want to save the setting.
 - *Optional.* Tap the **Add** button to add Custom Limit.
 - *Optional.* Tap the **Delete** button to delete the defined Custom Limit.



NOTE


If you set Formula to f^n or $1/f^n$, you can define the limit line as frequency of function. If you set it to NA, you can define the limit line as a constant.

To set sweep

- 1 Tap **Menu > Sweep** in the side bar.
- 2 Tap to switch **Sweep Speed** to **Fast** or **Normal**.
 - a If you set it to Normal, it displays the strongest PCI's beam with beam ID.
 - b If you set it to Fast, it displays multi-PCI beam.
- 3 Tap to switch Sweep mode to **Continue** or **Single**.

Figure 97 shows an example of EMF 5G NR beam analyzer measurement.

Figure 97 EMF 5G NR beam analyzer measurement



Physical specifications

Table 42 Physical specifications

Parameter	Specification
Dimensions	
Height	170 mm (6.7 in)
Width	269 mm (10.6 in)
Depth	41 mm (1.6 in)
Weight	1.4 kg (3.0 lb)
Environment	
Maximum humidity	95% RH non-condensing
Shock and vibration	MIL-PRF-28800F
Drop	MIL-PRF-28800F
Storage temperature	-20 to 60°C (-4 to 140°F)



Viavi Solutions

North America: 1.844.GO VIAVI / 1.844.468.4284

Latin America +52 55 5543 6644

EMEA +49 7121 862273

APAC +1 512 201 6534

All Other Regions: viavisolutions.com/contacts

email TAC@viavisolutions.com

Address 6001 America Center Drive, San Jose, CA 95002

**SPA06MA-O User's
Guide 22145360 R004
December 2020
English**